

ATC MAINTENANCE

MAINTENANCE MODE : OFF/ON

ATC RECOVERY : OFF/ON

SPINDLE TOOL POT : 0

MAGAZINE INDEX POT : 0