



Hook the Warning Sign onto the
Emergency Stop switch on the main
operation panel