



Hook the Warning Sign onto the  
Emergency Stop switch on the main  
operation panel



将此警告标签挂在  
主操作盘上  
的[紧急停止]开关。