


Oil-Air Piping  
(Rear Bearing)



Oil-Air Piping  
(Front Bearings)

## Oil - Air Supply Distributor

Oil-Air Piping  
(To Spindle Rear Bearing)

Oil-Air Piping  
(To Spindle Front Bearing)

Air Piping  
(From Air Unit)

Oil Piping  
(From Oil-Air Supply Unit)

