

PARTS CATALOGUE


INVERTER GASOLINE GENERATOR
Pro3600Si

BOLIY POWER
Parts & Accessories

Pro3600Si
PARTS CATALOGUE
E2007 By BOLIY POWER
1st Edition, Feb. 2007
All rights reserved.

Any reprinting or unauthorized use
without the written permission of
ZHONGGU MOULD CO., LTD.
is expressly prohibited.

Printed in China



FOREWORD

This Parts Catalogue is related to the parts for the model(s) in the below frame. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the BOLIY Parts News.

It is advisable that you make necessary corrections to the Parts Catalogue according to the BOLIY Parts News.

2. Number of component for assembly

The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.


EXAMPLE

NO.	DESCRIPTION	Q'TY	REMARKS
1	CYLINDER HEAD	1	
2	BOLT STUD	1	

3. Applicable Starting Serial No. and Color Code

MODEL NAME	MODEL TYPE	DESTINATION	FRAME NO.
Pro3600Si	INVETRER		

Engine Serial No.




4. Note that the illustrations for reference in finding parts numbers, not to be used for assembling. When assembling, please use the applicable service manual.

5. The asterisk (*) before a reference number indicates modification items after the first edition.

CONTENTS


CONTENTS	B1
<A>CYLINDER	B2
CRANKSHAFT & PISTON	B3
<C>CAMSHAFT & VALVE	B4
<D>AIR SHROUD & STARTER	B5
<E>AIR STRAINER & CARBURETOR.....	B6
<F>EXHAUST.....	B7
<G>CRANKCASE	B8
<H>BOTTOM CASE.....	B9
<I>FUEL TANK.....	B10
<J>MAGNETO.....	B11
<K>GENERATOR	B12
<L>CONTROL SYSTEM.....	B13
<M>PANEL ASSEMBLY	B14
<N>PANELS	B15
<O>LABELS	B16
<P>ELECTRICAL CASE &PLUG	B17

MODULE<A>: CYLINDER




NO	DESCRIPTION	QUANTITY	REMARK
A 1	CYLINDER HEAD	1	
A 2	BOLT STUD	2	
A 3	BOLT STUD	2	
A 4	GASKET CYLINDER HEAD	1	
A 5	FLANGE BOLT	2	
A 6	FLANGE BOLT	2	
A 7	DOWEL PIN	2	
A 8	SPARK PLUG	1	
A 9	CYLINDER HEAD COVER	1	
A 10	BREATHER ASSY	1	
A 11	HOSE	1	
A 12	CYLINDER HEAD GASKET*INNER*	1	
A 13	CYLINDER HEAD GASKET*OUTER*	1	
A 14	FLANGE BOLT	4	

MODULE: CRANKSHAFT & PISTON




NO	DESCRIPTION	QUANTITY	REMARK
B1	CRANKSHAFT	1	
B2	CONNECTING ROD	1	
B3	CONNECTING ROD BOLT	2	
B4	PISTON	1	
B5	PISTON RING	3	
B6	PISTON PIN	1	
B7	CIRCLIP	2	

MODULE<C>: CAMSHAFT & VALVE




NO	DESCRIPTION	QUANTITY	REMARK
C1	CAMSHAFT	1	
C2	RIVET	1	
C3	DECOMPRESSION SPRING	1	
C4	INTAKE VALVE	1	
C5	EXHAUST VALVE	1	
C6	LIFTER VALVE	2	
C7	COMPRESSION SPRING	2	
C8	VALVE SPRING RETAINER	2	
C9	VALVE CLAMPING RING	2	
C10	VALVE ROCKER	2	
C11	ROCKER PIVOT	2	
C12	BOLT	2	
C13	NUT	2	
C14	GUIDANCE BOARD	1	
C15	VALVE PUSH ROD	2	
C16	VALVE OIL SEAL	1	

MODULE<D>: AIR SHROUD & STARTER




NO	DESCRIPTION	QUANTITY	REMARK
D1	FAN CASE	1	
D2	FLANGE BOLT	4	
D3	AIR SHROUD OF CYLINDER	1	
D4	FLANGE BOLT	1	
D5	BOLT	2	
D6	FIXED BOLSTER	1	
D7	FLANGE NUT	2	
D8	FLANGE BOLT	2	
D9	FLANGE NUT	2	
D10	STARTER ASSY	1	
D11	STARTER COVERING	1	
D12	DRUM SHEAVE	1	
D13	STARTER SPRING	1	
D14	PAWL	2	
D15	DRUM SHEAVE COVER	1	
D16	FRICITION SPRING	1	
D17	PRESSURE SPRING	2	
D18	SET SCREW	1	
D19	STARTER STRING	1	
D20	STARTER HANDER	1	
D21	FLANGE BOLT	3	
D22	AXLE SLEEVE	1	
D23	FLANGE BOLT	2	
D24	DEAD PLATE	1	

MODULE<E>: AIR SHROUD & CARBURETOR




NO	DESCRIPTION	QUANTITY	REMARK
E1	CARBURETOR JOINT	1	
E2	GASKET(EXPORT)	2	
E3	CARBURETOR	1	
E4	STEP MOTOR PEDESTAL	1	
E5	STEP MOTOR	1	
E6	CARBURETOR ASSY	1	
E7	CHOKE HANDLE	1	
E8	GASKET(IMPORT)	1	
E9	AIR STRAINER CASE	1	
E10	AIR STRAINER COVER	1	
E11	CHOKE PLATE	1	
E12	AIR FILTER	1	
E13	SCREW	2	
E14	STRAINER FLANGE	1	
E15	FLANGE NUT	2	
E16	FLANGE BOLT	1	

MODULE<F>: EXHAUST




NO	DESCRIPTION	QUANTITY	REMARK
F1	MUFFLE COVER	1	
F2	MUFFLE	1	
F3	EXHAUST COVER	1	
F4	WIRE NETTING	1	
F5	COLLAR CLAMP	1	
F6	BOLT	1	
F7	EXHAUST PIPE GASKET	1	
F8	FAN MUFFLE CASE	1	
F9	FAN COVER	1	
F10	FAN	1	
F11	FAN SHAFT	1	

MODULE<G>: CRANKCASE




NO	DESCRIPTION	QUANTITY	REMARK
G1	CRANKCASE	1	
G2	BEARING	1	
G3	OIL SEAL	1	
G4	FLANGE BOLT(OIL DRAIN)	1	
G5	GASKET	1	
G6	DOWEL PIN	2	
G7	CRANKCASE COVER	1	
G8	BEARING	1	
G9	OIL SEAL	1	
G10	CRANKCASE GASKET	1	
G11	FLANGE BOLT	6	
G12	OIL PLUG	1	
G13	GASKET	1	

MODULE<H>: BOTTOM CASE




NO	DESCRIPTION	QUANTITY	REMARK
H1	BUFFER A(LONG SCREW)	1	
H2	BUFFER B	3	
H3	PRESS PIECE	1	
H4	DAMPING CUSHION A	3	
H5	DAMPING CUSHION B	1	
H6	TOOLS BAG	1	
H7	RUBBER PLUG	1	
H8	CIRCULAR CUSHION	2	
N4	BOTTOM CASE	1	

MODULE<I>: FUEL TANK




NO	DESCRIPTION	QUANTITY	REMARK
I1	FUEL TANK HAT	1	
I2	PROTECTIVE SLEEVE	1	
I3	FUEL TANK	1	
I4	FUEL PIPE CLIP	1	
I5	PIPE STRAINER	1	
I6	STRAINER	1	
I7	FUEL LEVEL GAUGE	1	
M14	FUEL PIPE	2	

MODULE<J>: MAGNETO




NO	DESCRIPTION	QUANTITY	REMARK
J1	NUT	1	
J2	WASHER	1	
J3	WOODRUFF KEY	1	
J4	HIGH-PRESSURED CAP	1	
J5	ENGINE OIL LEVEL GAUGE	1	
J6	FLANGE BOLT	3	
J7	CONTROLLER	1	
J8	IGNITION COIL	1	
J9	FLANGE BOLT	1	
J10	TRIGGER COIL	1	
J11	SCRWE	2	
J12	WASHER	2	
J13	RUBBER RING	1	
J14	AC IGNITION	1	
J15	INVERTER	1	

MODULE<K>: GENERATOR




NO	DESCRIPTION	QUANTITY	REMARK
K1	STATOR	1	
K2	ROTOR	1	
K3	GENERATOR FAN	1	
K4	FLANGE BOLT	3	
K5	FLANGE BOLT	4	
K6	DOWEL PIN	2	
K7	BINDING STRING	1	
K8	FIXED BOLSTER	1	
K9	FLAT HEAD SCREW	4	

MODULE<L>: CONTROL SYSTEM




NO	DESCRIPTION	QUANTITY	REMARK
L1	BINDING STRING	1	
L2	WIRE GROUP	1	
L3	WIRE GROUP	1	
L4	ENGINE OIL WARNING INDICATOR	1	
L5	TAPPING SCREW	1	
L6	WASHER	1	
L7	FLANGE BOLT	1	
L8	SCREW	1	
J7	CONTROLLER	1	
J15	INVERTER	1	

MODULE<M>: PANEL ASSEMBLY




NO	DESCRIPTION	QUANTITY	REMARK
M1	CARRY RAIL	2	
M2	CHOKE HANDLE	1	
M3	PREVENT RUB	1	
M4	FRONT DOOR	1	
M5	OIL KNOB	1	
M6	FRONT CASE	1	
M7	SUPPORT CASE	4	
M8	RUBBER CUSHION	2	
M9	CONNECT A	3	
M10	CONNECT B	3	
M11	BACK DOOR	1	
M12	BACK CASE	1	
M13	FUEL VALVE ASSY	1	
M14	FUEL PIPE	2	
M15	RUBBER CUSHION	2	
I4	FUEL PIPE CLIP	1	
I5	PIPE STRAINER	1	

MODULE<N>: PANELS




NO	DESCRIPTION	QUANTITY	REMARK
N1	TOP CASE	1	
N2	RIGHT CASE	1	
N3	LEFT CASE	1	
N4	BOTTOM CASE	1	
N5	SEAL STRIP	1	
M6	FRONT CASE	1	
M12	BACK CASE	1	
I3	FUEL TANK	1	

MODULE<O>: LABELS



NO	DESCRIPTION	QUANTITY	REMARK
O1	SERIAL NO	1	
O2	OIL LABEL	1	
O3	TYPE	1	
O4	CAUTION (CREEPAGE)	1	
O5	EPA / CE / E-MARK	1	
O6	WARNING	1	
O7	CAUTION (HOT)	1	
O8	EMBLEM (BOLIY)	1	

MODULE<P>: ELECTRICAL CASE &PLUG



Socket Type & Electric Accessories

North America 120V			Europe 230V	Australia 230V	Others		
RV 5-30R	L5-30R	5-20R	RG-02	RA-02R	T DC 12V 8A	Switch 1	Switch2
1Unit	1Unit	1Unit	1Unit	1Unit	1Unit	1Unit	1Unit
P1	P2	P3	P4	P5	P6	P7	P8

NO	DESCRIPTION	QUANTITY	REMARK
P1	RECEPTACLE	1	
P2	RECEPTACLE	1	
P3	RECEPTACLE	1	
P4	RECEPTACLE	1	
P5	RECEPTACLE	1	
P6	RECEPTACLE	1	
P7	SWITCH 1	1	
P8	SWITCH 2	1	
P9	CONTROL PANEL(E)	1	
P10	DC PANEL(E)	1	