COMPUTER NETWORKS

- Chapter 2. The Physical Layer 2

王昊翔 WANG Haoxiang hxwang@scut.edu.cn

School of Computer Science & Engineering 国家双语教学试点项目 广东省精品课





• Development of telephone system




Outline

- Structure of the Telephone System
- The Local Loop: Modems, ADSL and Wireless
- Trunks and Multiplexing 中继&多路复用
- Switching



Structure of the Telephone System

• The **PSTN** (Public Switched Telephone Network) is the world's collection of interconnected voice-oriented public telephone networks. It's also referred to as the **POTS** (Plain Old Telephone Service).




(b) Centralized switch.

(c) Two-level hierarchy.

Structure of the Telephone System

A typical circuit route for a medium-distance call.





Components of the Telephone System

Local loops

 Analog twisted pairs going to houses and businesses

Trunks


- Digital fiber optics connecting the switching offices
- Switching offices
 - Where calls are moved from one trunk to another



The Local Loop

- Transmission lines suffer from three major problems:
 - Attenuation
 - Delay distortion
 - Noise
- The square waves used in digital signals have a wide frequency spectrum (usually, high frequency) and thus are subject to strong attenuation and delay distortion.

 The use of both analog and digital transmissions for a computer to computer call. Conversion is done by the modems and codecs.





- The modulation is introduced to solve this problem.
 - Amplitude: two different amplitudes are used to represent o and 1.
 - Frequency: different tones are used.
 - Phase: the wave is systematically shifted (45, 135, 225, or 315°).
- A **modem** (modulator-demodulator) is a device that modulates outgoing digital signals to analog signals.



Terms


- Data element, bits, a signal binary o or 1
- Data rate, bits per second, the rate at which data elements are transmitted.
- Signal elements/Symbol
- Signal rate or modulation rate, signal elements per second (baud), the rate at which signal elements are transmitted.

Basic Encoding Techniques

- Digital data to analog signal
 - Amplitude-shift keying (ASK)
 - Amplitude difference of carrier frequency
 - Frequency-shift keying (FSK)
 - Frequency difference near carrier frequency
 - Phase-shift keying (PSK)
 - Phase of carrier signal shifted



Modulation of analog signals



- (a) A binary signal
- (b) Amplitude modulation


- (c) Frequency modulation
- (d) Phase modulation







- The number of samples/symbols per second is measured in **baud**.
- In quadrature phase-shift keying (QPSK四相/正交相移键控), the four angles, usually out of phase by 90°, are used to transmit 2 bits/symbol. The bit rate is twice the baud rate.
- **QAM-64** (Quadratrue Amplitude Modulation正 交幅度调制-64) allows 64 different combinations, so 6 bits can be transmitted per symbol.



Constellation Diagrams:

- (a) QPSK.
- (b) QAM-16.
- (c) QAM-64.


- A connection that allows traffic in both directions simultaneously is called **full duplex**.
- A connection that allows traffic either way, but only one way at a time is called **half duplex**.
- A connection that allows traffic only one way is called simplex.



Trunks and Multiplexing

- Two categories of multiplexing schemes are used to multiplex many conversations over a single physical trunk:
 - In FDM (Frequency Division multiplexing), the frequency spectrum is divided into frequency bands.
 For fiber optic channels, WDM (Wavelength Division Multiplexing) is used.
 - In **TDM** (**Time Division Multiplexing**), the entire bandwidth is used for a chunk of time period.

Frequency Division Multiplexing



- (a) The original bandwidths.
- (b) The bandwidths raised in frequency.
- (b) The multiplexed channel.







Wavelength Division

Multiplexing

Wavelength division multiplexing.








Time Division Multiplexing

Multiplexing T1 streams into higher carriers.






Switching

- **Circuit switching** seek out a physical path from sender to receiver. An end-to-end path must be (conceptually) established before data is sent.
- **Message switching** no path is established in advance. The message is stored in the first switching office and forwarded later one hop at a time.
 - Example: store-and-forward network
 - Problem: No restriction of block size
- **Packet switching** place a restriction on block size, to allow packets to be buffered in main memory at the switching office.
 - Advantages:
 - Well-suited for interactive traffic
 - Improved response time and throughput





Circuit Switching




- (a) Circuit switching.
- (b) Packet switching.





Message Switching



(a) Circuit switching (b) Message switching (c) Packet switching





Packet Switching

ltem	Circuit-switched	Packet-switched
Call setup	Required	Not needed
Dedicated physical path	Yes	No
Each packet follows the same route	Yes	No
Packets arrive in order	Yes	No
Is a switch crash fatal	Yes	No
Bandwidth available	Fixed	Dynamic
When can congestion occur	At setup time	On every packet
Potentially wasted bandwidth	Yes	No
Store-and-forward transmission	No	Yes
Transparency	Yes	No
Charging	Per minute	Per packet

A comparison of circuit switched and packet-switched networks.





Presentation

• Mobile telephone system

