## How to print it via USB connecting to computer

#### 1. Connecting USB to computer and Install the driver




After you finished your installation, you will find the correct "COM port" under the "Computer"- "Device Manager", maybe "COM 3" or "5" or others.


USB-SERIAL CH340 (COM3)


### 2. Slice and print

 Open your Cura 4.8 software,load one STL file,for example,load the whistle.Make sure your setting is ok,then slice it.




 Click "print via USB", it will show printing page, and you will find the COM port, as "COM 3"






 After both the temperature of extruder and build plate rise up to the setting value, the print will start to work.



# (Note:Make sure your have insert the filament well and leveling well before printing)



If you meet any questions or issues, please contact to our support,

#### Email:support@huafast3d.com

Thank you!