

CAPL Exercise

The scope of this exercise is to simulate a part of the environment that communicates with IPC ECU.

1. Create a CANoe/CANalyzer configuration and add the *P332BEV_BH-CAN_R1_20200902_E2A_plus_CR14698-14830-14888.dbc* you can find in the folder (see CANalyzer/CANoe lessons).
2. Insert a Program/Network node and write a CAPL that is able to:
 - Send for the entire measurement duration, with the period you can find in the .dbc, **STATUS_UBSS_BH** message;
 - Send **TELEMATIC_VEHICLE_SETUP2** message with **PowerLevelReq** signal value equal to 0x3 when “2” key is pressed;
 - Increase a counter **Count1** each time **PowerLevel** signal in **IPC_VEHICLE_SETUP** message is NOT equal to **PowerLevelReq**, when **IPC_VEHICLE_SETUP** is received;
 - Decrease **Count1** each time **PowerLevel** signal in **IPC_VEHICLE_SETUP** message is equal to **PowerLevelReq**, when **IPC_VEHICLE_SETUP** is received (the counter can not assume negative values);
 - Stop sending **STATUS_UBSS_BH** if Bus Off condition occurs;
 - Print on the Write window the sentence “PowerLevel signal value has been different from PowerLevelReq one ... times” (replace ... with **Count1** value) at the end of the measurement.