

Exercise 3 - CANalyzer/IG

For each of the following steps insert a screenshot to explain the results.

- Create one TRACE block for each CAN channel (Trace BH and Trace C1)
- In the trace BH create a filter that shows only the messages transmitted and received related to IPC
- In the trace C1 create a filter that stops the messages transmitted from the BSM
- Using the IG block, simulate the following signals:
- **AIRBAG1.AirBagFailSts** = 1 (Fail_not_Present_Lamp_Flashing)
- **BRAKE1.VehicleSpeedVSOSignal** = 40Km/h
- **BCM_COMMAND.CmdIgnSts** = RUN
- **ENGINE1.PowertrainPrplsnActv** = 1

With a GRAPHIC window verify that all previous signals are set accordingly to the IG block specifications.

With the IG Block simulate **AIRBAG1.AirBagFailSts** = 0 and verify with a graph that the IPC sends the signal **CLUSTER2.AirBagLamp_FailSts** = 0.

With the IG Block simulate **AIRBAG1.AirBagFailSts** = 1 and verify with a graph that the IPC sends the signal **CLUSTER2.AirBagLamp_FailSts** = 3.

With the IG Block simulate **BRAKE8. ABSFailSts** = 1 and verify with a graph that the IPC sends the signal **CLUSTER2.ABSLamp_FailSts** = 2.

Choose 10 signals to change from the IG block (each signal from a different message), create a log with only the signals that you selected and change them while you are logging.

Use the previous log in *offline mode* to analyze the instant of time where you changed each signal.