

CAN GATEWAY

1. Write a CAPL in order to create a gateway between two CANs from IPC (single or multiple messages).

Preliminary actions

- Set 2 CAN and add the relative DBC to the two CAN Networks (attached in this folder).
- Insert a Programming Node to create the gateway.

Code goal

- Open CAPL to write the code to copy a message from one CAN to the other.

Check

- Look into the Trace if the code has been written correctly

2. Modify the message through gateway

- Modify one byte of the DATA message sent using CAPL; look from the CANdb+ Editor what kind of configuration is used for the message's bytes you want to modify (MOTOROLA: byte starts from left to right; INTEL: opposite)

ex. MOTOROLA - change byte 6

	DATA
BEFORE	68 82 00 00 04 41 00 00
AFTER	68 82 00 00 04 41 FF 00

- Modify a signal value of the message that is exchanged between the 2 Networks.
- Create a new message "TEST" in the DBC of CAN 2 and modify the CAPL in order to copy in TEST the information about one message of the CAN 1. (add ID information)
- In order to read the same signals of the chosen message in the TEST message, add these signals in the DBC of the CAN 2.

Ex. CLUSTER2 (CAN1): chosen message, TEST (CAN 1)

Message 'CLUSTER2 (0x256)'

Definition Signals Tran:

Signal

- ABSLamp_FailSts
- AirBagLamp_FailSts
- DistanceUnit
- EBDLamp_FailSts
- EPBAutoAppReqSts
- EPBLamp_FailSts
- EPBMaintenanceReqSts
- ESCLamp_FailSts
- FSFCWPlusActivationMode
- FSFCWPlusSetting
- PassiveEntry
- PowerModeSts_IPC
- PsngBagRequestSts
- RemoteDoorUnlock
- TPICalibrationReqSts

Message 'TEST (0xFF)'

Definition Signals Tran:

Signal

- ABSLamp_FailSts
- AirBagLamp_FailSts
- DistanceUnit
- EBDLamp_FailSts
- EPBAutoAppReqSts
- EPBLamp_FailSts
- EPBMaintenanceReqSts
- ESCLamp_FailSts
- FSFCWPlusActivationMode
- FSFCWPlusSetting
- PassiveEntry
- PowerModeSts_IPC
- PsngBagRequestSts
- RemoteDoorUnlock
- TPICalibrationReqSts