
# آشنایی با زبان اسمبلی AVR زیرروالها


Dr. Aref Karimiafshar A.karimiafshar@ec.iut.ac.ir



## دستورات پرش

- In the sequence of instruction to be executed, it is often necessary to transfer program control to a different location.
- Instruction in AVR to achieve this:
  - Branches (JUMP)
  - CALL





## فراخوانی زیرروال (CALL)

- Is used to call a subroutine
- Subroutines
  - To perform tasks that need to be performed frequently
- Advantages
  - Makes a program more structured
  - Saving memory space

## فراخوانی زیرروال (CALL)

- Four instructions for call subroutine:
  - CALL (long call)
  - RCALL (relative call)
  - ICALL (indirect call to Z)
  - EICALL (extended indirect call to Z)

 The choice of which one to use depends on the target address

### **CALL** – Long Call to a Subroutine

Calls to a subroutine within the entire Program memory. The return address (to the instruction after the CALL) will be stored onto the Stack. The Stack Pointer uses a post-decrement scheme during CALL.

#### Operation:

- (i) PC ← k Devices with 16-bit PC, 128KB Program memory maximum.
- (ii) PC ← k Devices with 22-bit PC, 8MB Program memory maximum.

|      | Syntax: | Operands:   | Program Counter:  | Stack:                           |
|------|---------|-------------|-------------------|----------------------------------|
| (i)  | CALL k  | 0 ≤ k < 64K | $PC \leftarrow k$ | STACK ← PC+2                     |
|      |         |             |                   | SP ← SP-2, (2 bytes,<br>16 bits) |
| (ii) | CALL k  | 0 ≤ k < 4M  | PC ← k            | STACK ← PC+2                     |
|      |         |             |                   | SP ← SP-3 (3 bytes,<br>22 bits)  |

### CALL - Long Call to a Subroutine

#### 32-bit Opcode:

| 1001 | 010k | kkkk | 111k |
|------|------|------|------|
| kkkk | kkkk | kkkk | kkkk |

#### Status Register (SREG) and Boolean Formula

| I | Т | Н | S | V | N | Z | С |
|---|---|---|---|---|---|---|---|
| - | _ | _ | _ | _ | - | _ | _ |

Words 2 (4 bytes)

Cycles 4 devices with 16-bit PC

5 devices with 22-bit PC

### RCALL - Relative Call to Subroutine

Relative call to an address within PC - 2K + 1 and PC + 2K (words).
The return address (the instruction after the RCALL) is stored onto
the Stack. For AVR microcontrollers with Program memory not
exceeding 4K words (8KB) this instruction can address the entire
memory from every address location. The Stack Pointer uses a
post-decrement scheme during RCALL.

|      | Operation:                 | Comment:                |   |                                   |  |  |  |  |
|------|----------------------------|-------------------------|---|-----------------------------------|--|--|--|--|
| (i)  | $PC \leftarrow PC + k + 1$ | Devices with 16-bit PC, | Devices with 16-bit PC, 128KB Program memory maximum. |                                   |  |  |  |  |
| (ii) | $PC \leftarrow PC + k + 1$ | Devices with 22-bit PC, | 8MB Program memory m                                  | aximum.                           |  |  |  |  |
|      | Syntax:                    | Operands:               | Program Counter:                                      | Stack:                            |  |  |  |  |
| (i)  | RCALL k                    | -2K ≤ k < 2K            | $PC \leftarrow PC + k + 1$                            | $STACK \leftarrow PC + 1$         |  |  |  |  |
|      |                            |                         |   | SP ← SP - 2 (2 bytes,<br>16 bits) |  |  |  |  |
| (ii) | RCALL k                    | -2K ≤ k < 2K            | $PC \leftarrow PC + k + 1$                            | $STACK \leftarrow PC + 1$         |  |  |  |  |
|      |                            |                         |   | SP ← SP - 3 (3 bytes, 22 bits)    |  |  |  |  |

### RCALL - Relative Call to Subroutine

#### 16-bit Opcode:

| 1101 | kkkk | kkkk | kkkk |
|------|------|------|------|
|      |      |      |      |

#### Status Register (SREG) and Boolean Formula

| I | Т | Н | S | V | N | Z | С |
|---|---|---|---|---|---|---|---|
| _ | _ | _ | _ | _ | - | _ | - |

Words 1 (2 bytes)

Cycles 3 devices with 16-bit PC

4 devices with 22-bit PC

### ICALL - Indirect Call to Subroutine

Calls to a subroutine within the entire 4M (words) Program memory.
The return address (to the instruction after the CALL) will be stored
onto the Stack. The Stack Pointer uses a post-decrement scheme
during CALL.

|      | Operation:                    | Comment:                | Comment:  |                                   |  |  |  |
|------|-------------------------------|-------------------------|---|-----------------------------------|--|--|--|
| (i)  | $PC(15:0) \leftarrow Z(15:0)$ | Devices with 16-bit PC, | Devices with 16-bit PC, 128KB Program memory maximum. |                                   |  |  |  |
| (ii) | $PC(15:0) \leftarrow Z(15:0)$ | Devices with 22-bit PC, | 8MB Program memory m                                  | aximum.                           |  |  |  |
|      | PC(21:16) ← 0                 |                         |   |                                   |  |  |  |
|      | Syntax:                       | Operands:               | Program Counter:                                      | Stack:                            |  |  |  |
| (i)  | ICALL                         | None                    | See Operation   | $STACK \leftarrow PC + 1$         |  |  |  |
|      |                               |                         |   | SP ← SP - 2 (2 bytes,<br>16 bits) |  |  |  |
| (ii) | ICALL                         | None                    | See Operation   | $STACK \leftarrow PC + 1$         |  |  |  |
|      |                               |                         |   | SP ← SP - 3 (3 bytes, 22 bits)    |  |  |  |

### ICALL - Indirect Call to Subroutine

#### 16-bit Opcode:

| 1001 | 0101 | 0000 | 1001 |
|------|------|------|------|
|      |      |      |      |

#### Status Register (SREG) and Boolean Formula

| 1 | Т | Н | S | V | N | Z | С |
|---|---|---|---|---|---|---|---|
| _ | _ | _ | - | _ | - | _ | - |

Words 1 (2 bytes)

Cycles 3 devices with 16-bit PC

4 devices with 22-bit PC

### **EICALL – Extended Indirect Call to Subroutine**

Indirect call of a subroutine pointed to by the Z (16 bits) Pointer
Register in the Register File and the EIND Register in the I/O space.
This instruction allows for indirect calls to the entire 4M (words)
Program memory space. The Stack Pointer uses a post-decrement scheme during EICALL.

#### Operation:

(i)  $PC(15:0) \leftarrow Z(15:0)$ 

PC(21:16) ← EIND

Syntax: Operands: Program Counter: Stack:

(i) EICALL None See Operation STACK ← PC + 1

 $SP \leftarrow SP - 3$  (3 bytes,

22 bits)

### **EICALL – Extended Indirect Call to Subroutine**

#### 16-bit Opcode:

| 1001 | 0101 | 0001 | 1001 |
|------|------|------|------|
|      |      |      |      |

#### Status Register (SREG) and Boolean Formula

| 1 | Т | Н | S | V | N | Z | С |
|---|---|---|---|---|---|---|---|
| - | _ | _ | - | _ | - | _ | - |

Words 1 (2 bytes)

Cycles 4 (only implemented in devices with 22-bit PC)

### **RET – Return from Subroutine**

- Every subroutine needs RET as the last instruction.
- Returns from subroutine. The return address is loaded from the STACK. The Stack Pointer uses a pre-increment scheme during RET.

|      | Operation:       | Comment:  |                      |   |  |  |
|------|------------------|---|----------------------|---|--|--|
| (i)  | PC(15:0) ← STACK | Devices with 16-bit PC,                             | 128KB Program memory | maximum.                                    |  |  |
| (ii) | PC(21:0) ← STACK | Devices with 22-bit PC, 8MB Program memory maximum. |                      |   |  |  |
|      | Syntax:          | Operands:   | Program Counter:     | Stack:                                      |  |  |
| (i)  | RET              | None  | See Operation        | SP ← SP + 2, (2 bytes,<br>16 bits)          |  |  |
| (ii) | RET              | None  | See Operation        | $SP \leftarrow SP + 3$ , (3 bytes, 22 bits) |  |  |

### **RET – Return from Subroutine**

#### 16-bit Opcode:

| 1001 | 0101 | 0000 | 1000 |
|------|------|------|------|
|      |      |      |      |

#### Status Register (SREG) and Boolean Formula

| I | Т | Н | S | V | N | Z | С |
|---|---|---|---|---|---|---|---|
| _ | _ | _ | - | _ | - | _ | - |


Words 1 (2 bytes)

Cycles 4 devices with 16-bit PC

5 devices with 22-bit PC

### **Stack**

- Stack is a section of RAM used by CPU to store information temporarily
  - Data
  - Address
- CPU needs this storage area because there are only a limited number of registers
- There is a register in CPU to point to stack
  - Called Stack Pointer (SP) register
    - Two register in I/O memory space
      - SPL: Low byte of SP
      - SPH: High byte of SP



### **Operation on the Stack**

#### PUSH

- Storing information on the Stack
  - SP points to top of the stack (TOS)
  - As we push data, the data are saved where SP points
  - SP is decrement by one

Syntax: Operands: Program Counter: Stack:

(i) PUSH Rr  $0 \le r \le 31$  PC  $\leftarrow$  PC + 1 SP  $\leftarrow$  SP - 1

#### POP

- Loading stack contents back into a CPU register
  - POP is the opposite process of PUSH
  - SP is incremented
  - Top location of stack is copied back to the register

Syntax: Operands: Program Counter: Stack:

(i) POP Rd  $0 \le d \le 31$  PC  $\leftarrow$  PC + 1 SP  $\leftarrow$  SP + 1

### **Initializing the Stack Pointer**

- The SP register contains the value 0
  - When the AVR is powered on
- We must initialize the SP at the beginning of the program
  - Stack grows from higher memory Location to the lower memory location
  - It is common to initialize SP to uppermost memory location
    - Different AVRs have different amounts of RAM
    - In the AVR assembler, RAMEND represents the address of the last RAM location
    - To initialize SP
      - Load RAMEND into SP

### CALL\RET instructions and the role of Stack

- When a subroutine is called
  - CPU saves the address of the instruction just bellow the CALL instruction on the stack
    - To know where to resume when it returns from called subroutine PUSH (instruction bellow CALL) onto the stack
- When RET instruction at the end of the subroutine is executed
  - The top location of stack copied back to PC
  - SP is incremented

POP (instruction bellow CALL) into the PC

### مثال

Toggle all the bits of Port B by sending to it the values \$55 and \$AA continuously. Put a time delay between each issuing of data to Port B.

```
.INCLUDE "M32DEF.INC"

.ORG 0

LDI R16,HIGH(RAMEND) ;load SPH

OUT SPH,R16

LDI R16,LOW(RAMEND) ;load SPL

OUT SPL,R16
```

**Initialization of SP** 

```
Main program
```

```
BACK:

LDI R16,0x55 ;load R16 with 0x55
OUT PORTB,R16 ;send 55H to port B
CALL DELAY ;time delay
LDI R16,0xAA ;load R16 with 0xAA
OUT PORTB,R16 ;send 0xAA to port B
CALL DELAY ;time delay
RJMP BACK ;keep doing this indefinitely
```

```
this is the delay subroutine
      .ORG 0x300
                        ;put time delay at address 0x300
DELAY:
      LDI
           R20,0xFF ; R20 = 255, the counter
AGAIN:
                        ;no operation wastes clock cycles
      NOP
      NOP
     DEC
           R20
      BRNE AGAIN
                        repeat until R20 becomes 0
      RET
                        return to caller
```

**Delay subroutine** 

### Macros vs. Subroutine

Macros and subroutines are useful in writing assembly programs, but each has limitations. Macros increase code size every time they are invoked. For example, if you call a 10-instruction macro 10 times, the code size is increased by 100 instructions; whereas, if you call the same subroutine 10 times, the code size is only that of the subroutine instructions. On the other hand, a function call takes 3 or 4 clocks and the RET instruction takes 4 clocks to get executed. So, using functions adds around 8 clock cycles. The subroutines use stack space as well when called, while the macros do not.

## **AVR Timer Delay**

- Delay subroutine
  - How to generate various time delays
  - How to calculate exact delays for AVR
- Two factors that can affect the accuracy of the delay
  - The crystal frequency
  - The AVR design

### **AVR Timer Delay**

- Machine cycle
  - Certain amount of time for the CPU to execute an instruction
  - More instructions take no more than one or two machine cycles
  - The length of machine cycle depends on the frequency of the oscillator
  - One machine cycle consist of one oscillator period
    - To calculate the machine cycle
      - We take the inverse of the oscillator frequency


The following shows the crystal frequency for four different AVR-based systems. Find the period of the instruction cycle in each case.

- (a) 8 MHz (b) 16 MHz (c) 10 MHz (d) 1 MHz

- (a) instruction cycle is 1/8 MHz =  $0.125 \mu s$  (microsecond) = 125 ns (nanosecond)
- (b) instruction cycle =  $1/16 \text{ MHz} = 0.0625 \,\mu\text{s} = 62.5 \,\text{ns}$  (nanosecond)
- (c) instruction cycle =  $1/10 \text{ MHz} = 0.1 \mu \text{s} = 100 \text{ ns}$
- (d) instruction cycle = 1/1 MHz =  $1 \mu s$

## **Pipelining**

Overlapping of fetch and execution



## **Branch Penalty**

- For the concept of pipelining to work
  - We need a buffer or queue
    - Which an instruction is prefetched and ready to be executed
- When a branch instruction is executed
  - CPU starts to fetch codes from new location
    - The code in the queue that was fetched previously is discarded
    - In this case, the execution unit must wait until the fetch unit fetches the new instruction
      - Called branch penalty

## مثال

For an AVR system of 1 MHz, find how long it takes to execute each of the following instructions:

(a) LDI

- (b)
- DEC

(c) LD

(d) ADD

(e) NOP

(f) JMP

(g) CALL

(h) BRNE

(i) .DEF

The machine cycle for a system of 1 MHz is 1  $\mu$ s,

| Instr | uction | Instruction cycles   | Time to execute                                       |
|-------|--------|--|---|
| (a)   | LDI    | 1  | $1 \times 1 \mu s = 1 \mu s$                          |
| (b)   | DEC    | 1  | $1 \times 1 \mu s = 1 \mu s$                          |
| (c)   | OUT    | 1  | $1 \times 1 \mu s = 1 \mu s$                          |
| (d)   | ADD    | 1  | $1 \times 1 \mu s = 1 \mu s$                          |
| (e)   | NOP    | 1  | $1 \times 1 \mu s = 1 \mu s$                          |
| (f)   | JMP    | 3  | $3 \times 1 \mu s = 2 \mu s$                          |
| (g)   | CALL   | 4  | $4 \times 1 \mu s = 4 \mu s$                          |
| (h)   | BRNE   | and the second s | s taken, 1 µs if it falls cough)                      |
| (i)   | .DEF   | •  | ective instructions do not luce machine instructions) |

## مثال

Find the size of the delay of the code snippet below if the crystal frequency is 10 MHz:

|        |          |           |      | Instruction | Cycles |
|--------|----------|-----------|------|-------------|--------|
|        | .DEF COU | UNT = R20 |      | 0           |        |
| DELAY: | LDI      | COUNT,    | 0xFF | 1           |        |
| AGAIN: | NOP      |           |      | 1           |        |
|        | NOP      |           |      | 1           |        |
|        | DEC      | COUNT     |      | 1           |        |
|        | BRNE     | AGAIN     |      | 2/1         |        |
|        | RET      |           |      | 4           |        |

Therefore, we have a time delay of  $[1 + ((1 + 1 + 1 + 2) \times 255) + 4] \times 0.1 \,\mu s = 128.0 \,\mu s$ . Notice that BRNE takes two instruction cycles if it jumps back, and takes only one when falling through the loop. That means the above number should be 127.9  $\mu s$ .

## **Delay Calculation for AVR**

- Delay subroutine consists of two parts
  - Setting the counter
  - A loop
- Most of the time delay is performed by the body of the loop
- Very often
  - We calculate the time delay based in the instructions inside the loop
  - Ignore the clock cycles associated with the instructions outside of the loop

## مثال

Find the size of the delay in the following program if the crystal frequency is 1 MHz:

```
.INCLUDE "M32DEF.INC"
.ORG 0
        LDI R16, HIGH (RAMEND) ; initialize SP
        OUT SPH, R16
        LDI R16, LOW (RAMEND)
        OUT SPL.R16
BACK:
        LDI R16,0x55 ;load R16 with 0x55
        OUT PORTB, R16 ; send 55H to port B
        RCALL DELAY ; time delay
        LDI R16,0xAA ;load R16 with 0xAA
        OUT PORTB, R16 ; send 0xAA to port B
        RCALL DELAY ; time delay
                           ; keep doing this indefinitely
        RJMP BACK
; -----this is the delay subroutine
        ORG 0x300
                     ;put time delay at address 0x300
DELAY: LDI R20,0xFF ; R20 = 255, the counter
AGAIN:
        NOP
                           ;no operation wastes clock cycles
        NOP
        DEC R20
        BRNE AGAIN
                           ;repeat until R20 becomes 0
        RET
                           return to caller
```

## مثال

we have the following machine cycles for each instruction of the DELAY subroutine:

|        |              | Instruction | Cycles |
|--------|--------------|-------------|--------|
|        |              |             |        |
| DELAY: | LDI R20,0xFF | 1           |        |
| AGAIN: | NOP          | 1           |        |
|        | NOP          | 1           |        |
|        | DEC R20      | 1           |        |
|        | BRNE AGAIN   | 2/1         |        |
|        | RET          | 4           |        |

Therefore, we have a time delay of  $[1 + (255 \times 5) - 1 + 4] \times 1 \mu s = 1279 \mu s$ .

## پایان

موفق و پیروز باشید