به نام خدا

حديث غفورى 9825413

سوال 1

```
;timer clock = 8MHz / 64 = 125kHz => timer period = 1/125 kHz = 8us
;timer value = 1920us / 8us = 240
;Timer2 delay
DELAY: LDI
           R20,-240
                            ;R20=0x10
      OUT
           TCNT2,R20
                            ;load Timer2
      LDI
            R20,0x04
      OUT
           TCCR2,R20
                            ;Timer2 , normal mode,int clk,prescaler 64
AGAIN: IN
            R20,TIFR
                            ;read TIFR
      SBRS R20, TOV2
                            ;if TOV2 is set skip next instructin
      RJMP AGAIN
      LDI
           R20,0x0
      OUT
           TCCR2,R20
                            ;stop Timer2
      LDI
            R20, 1<<TOV2
      OUT
           TIFR,R20
                            ;clear TOV2 flag
      RET
```

سوال 2

```
;we should use prescaler = 256 since we cannot use a decimal point
;to wait 250clocks we should load OCR2 with 250-1 = 249
; TIMER2 DELAY
DELAY: LDI
            R20,0
      OUT
           TCNT2,R20
                            ;TCNT2 =0
      LDI
           R20,249
                            ;OCR2 = 249
      OUT
           OCR2,R20
           R20,0x0E
      LDI
      OUT
           TCCR2,R20
                            ;Timer2 , CTC mode, prescaler = 256
AGAIN: IN
            R20,TIFR
                            ;read TIFR
      SBRS R20,0CF2
                            ;if OCF2 is set skip next inst.
      RJMP AGAIN
      LDI
            R20,0x0
      OUT
            TCCR2,R20
                            ;stop Timer2
      LDI
            R20,1<<0CF2
     OUT
            TIFR,R20
                            ;clear OCF2 flag
      RET
```

```
#include <avr/io.h>
int main(void)

{

PORTB = 0x01; // activate pull-up of PB0
DDRC = 0xFF; // PORTC is output
DDRD = 0xFF; // PORTD is output

TCCR1A = 0x00; // output clock source
TCCR1B = 0x07; // output clock source

TCNT1H = 0x00; // set count to 0
TCNT1L = 0x00; // set count to 0

##include <a href="#">TCNT1H = 0x00; // activate pull-up of PB0
DDRC = 0xFF; // PORTD is output

##include <a href="#">TCNT1H = 0x00; // portC = 1 count to 0 count to 0
```