

VCC GPIO14 GPIO12 GPIO13 GPIO15 GPIO2 GPIO0




WIFI_ANT
CH_PD
GPIO18
URXD
UTXD
NC
GND

Label	Signal
VCC	3.3V (3.6V max) supply voltage
GND	Ground
UTXD	Transmit Data (3.3V level)
URXD	Receive Data (3.3V level!)
CH_PD	Chip Power down: (LOW = power down active)
GPI00	General Purpose I / O 0
GPIO2	General Purpose I / O 2
GPIO12	General Purpose I / O 12
GPIO13	General Purpose I / O 13
GPIO14	General Purpose I / O 14
GPIO15	General Purpose I / O 15
GPIO18	General Purpose I / O 18
WIFI_ANT	WiFi Antenna
RST	Reset (reset = LOW active)







RXSET

ADC

CH_PD

GPIO 16

GPIO 14

GPIO 12

GPIO 13

VCC



TXD

RXD

GPIO14

GPIO 5

GPIO 0

GPIO 2

GPIO15

GND