## Set up with Losant:

1. Go to:

https://accounts.losant.com/create-account
And create an account.

2. Go to:

https://docs.losant.com/devices/overview/

And Create a device

- 3. Set device attributes:
  - a. tempC
  - b. humidity
  - c. realfeel
- 4. Generate secret (certificate) and key (cert-key pair). Make sure to copy the info in a text file.