Libraries and Dependency Setup:

- 1. Go to Arduino -> Sketch -> Include Library -> Manage Libraries.

 And install the following libraries:
 - a. PubSubClient (Latest Version)
 - b. ArduinioJson (Version: 5.13.4)
 - c. Adafruit Unified Sensor (Latest Version)
 - d. DHT22 by Adafruit (Latest Version)
- 2. Now go to:

https://github.com/Losant/losant-mqtt-arduino

- 3. Download the library.
- 4. Go to Arduino -> Sketch -> Include Library -> Add Zip and select the library downloaded.
- 5. Restart the Arduino IDE

Sample Json Payload:

```
{
    "deviceId": "575ecf887ae143cd83dc4aa2",
    "key": "this_would_be_the_key",
    "secret": "this_would_be_the_secret"
}
```