Copyright©

System Requirements for CD/DVD-ROM Playback

Hardware

· A CD/DVD-ROM drive

· A 1024 × 768 pixels or more monitor

Software

OS: Microsoft® Windows® 98/ NT4.0/2000/XP

Recommended Browser: Microsoft® Internet Explorer 6.0 or later / Mozilla Firefox 2.0

Plug-ins: Adobe® Reader® 6.0 or later, Adobe® Flash Player® 7.0 or later

Caution:

We do not guarantee proper operation when using specification combinations or versions other than those indicated above.

· Microsoft, Windows 98, Windows NT, Windows 2000 and Windows XP are the trademarks or registered trademarks of Microsoft Corporation in the USA and other countries.

· Adobe, Reader and Flash Player are the trademarks or registered trademarks of Adobe Systems Incorporated in the USA and other countries.

CD/DVD-ROM Startup and Operating Method

**Insert the CD/DVD into the CD/DVD drive. "TOP MENU" starts automatically.**

For details about the subsequent operations, click "How to read" on the lower right of "TOP MENU".

Caution:

· **If the CD/DVD does not start automatically after a short time, click [Top] folder → "TopPage.html" in the CD/DVD.**

· **To restart the CD/DVD, remove it from the CD/DVD drive and then reinsert it.**

TOP MENU

When the CD/DVD is inserted into the CD/DVD drive, this "TOP MENU" starts automatically.
The underlined blue words are links. Click on a link to display the corresponding screen.

Screen Description:

A   Display Language Tabs

Click one of the Display Language tabs to switch the operation buttons and table headers into the selected language.

Display Language Example: (French Display)

B   CD/DVD Title

Displays applicable models covered by this CD/DVD.

C   Model Selection

Displays a model list to select the applicable manual.

D   VIN Search

Displays a screen to search a model from VIN.

E   Manual List

Displays a list of all the manuals including this CD/DVD.

F   Plug-in

Displays information about the plug-ins that are required for reading the manuals on the CD/DVD.

G How to find

Displays the "How to find" file, which explains the usage of this CD/DVD.

MODEL SELECTION

You can find out the applicable manual from the model information (Model Name, Model Code, Engine, Type, Start of Production, and Remarks).

The underlined blue words are links. Click on a link to display the corresponding screen.

Screen Description:

A Top

Returns to [TOP MENU].

B Model Information

Displays a list of model information and links to related manual.

The [☞] mark is a link. Click to display the corresponding screen.

Example of Related Manual List Display: (When [1] was selected)

C VIN List

Displays "VIN LIST". (For more information, refer to [VIN LIST])

D To top of this page

When scrolling is needed to display the whole page, this links back to the top of the page.

VIN SEARCH

You can search for corresponding models by inputting the VIN and display a list of the related models.
The underlined blue words are links. Click to display the corresponding screen.

Screen Description:

A   Input VIN Box

Input the VIN (12 or 17 digits, including hyphens).

B   VIN List

Displays "VIN List". (For more information, refer to [VIN LIST])

C   OK

After inputting the number into the Input VIN box, click this button to run the search.

If the input number is correct, a list for the corresponding model is displayed.

－ If the input VIN is not 12 or 17 digits:

Displays the [Input "VIN" is invalid] error message.

－ If there are no corresponding vehicle types for the input VIN:

Displays the [There is no applicable data] error message.

Search Results Example: (When JSAJTA74V00234567 was searched)

D   Reset

Clears the numbers in the Input VIN box.

E   Top

Returns to [TOP MENU].

VIN LIST

A ↓ **B** → BACK

| Model Name	Model Code	Engine	Type	Start of Production (Year. Month)	Remarks	VIN
GRAND VITARA	JB416	M16	1	2005.04		JSAJTA74V00100001 - 199999
						JSAJTA74V60100001 - 199999
						JS3TA74V#64100001 - 199999
	JB420	J20				JSAJTD54V00100001 - 199999
						JSAJTD54V60100001 - 199999
						JS3TD54V#64100001 - 199999
	JB419D	F9Q		2005.11		JSAJTA44V00100001 - 199999
						JSAJTD44V00100001 - 199999
	JB416	M16		2006.12	ESP model	JSAJTA74V00100001 - 199999
						JSAJTA74V60100001 - 199999
	JB420	J20			ESP model	JSAJTD54V00100001 - 199999
						JSAJTD54V60100001 - 199999
	JB416	M16	2	2006.06	2006.06 minor change	JSAJTA74V00200001 - 999999
						JSAJTC74V00200001 - 999999
						JSAJTA74V70110001 - 999999
						JS3TA74V#74110001 - 999999
						JS3TC74V#74110001 - 999999
	JB420	J20			2006.06 minor change	JSAJTD54V00200001 - 999999
						JSAJTD54V70110001 - 999999
						JSAJTE54V00200001 - 999999
						JSAJTD54V6#200001 - 999999
						JS3TE54V#74110001 - 999999
	JB419D	F9Q			2006.06 minor change	JSAJTA44V00200001 - 999999
						JSAJTD44V00200001 - 999999
						JS3TA44V#74110001 - 999999
						JS3TD44V#74110001 - 999999
	JB627	H27	1	2005.07		JSAJTD94V00100001 - 199999
	JB627	H27	2	2006.06	2006.06 minor change	JSAJTD94V00200001 - 999999
						JS3TD94V#74200001 - 999999

C → To top of this page

You can confirm a VIN that corresponds to the model information (Model Name, Model Code, Engine, Type, Start of Production, and Remarks) and vice versa.

The underlined blue words are links. Click to display the corresponding screen.

<u>Screen Description:</u>

A   Model Information and Applicable VIN List

Displays a VIN that corresponds to the vehicle information.

B   BACK

Returns to the previous page.

C   To top of this page

When scrolling is needed to display the whole page, this links back to the top of the page.

MANUAL LIST

You can confirm a list of all manuals on the CD/DVD and a list of each language manual.

The underlined blue words are links. Click to display the corresponding screen.

Screen Description:

A **Tabs for Displaying Manuals by Language**

Click a language tab to display a list of manuals in the corresponding language.

Language Tab Display Example: (English Manual Display)

B **Manual List Display Screen**

Displays a list of all manuals on the CD/DVD.

You can browse the manual by clicking the manual number.

C **Top**

Returns to [TOP MENU].

D **To top of this page**

When scrolling is needed to display the whole page, this links back to the top of the page.