

- 1. Restore the factory setting.
- 2. Log on the web http://192.168.16.254/home.asp, change the mode to bridge, start ap client. Click the button 'Apply', wait about 30s.




, 3 Close the DHCP function, in order that all the IP address you obtained in the LAN are got from the main router.



4 Access into the page http://192.168.16.254/home.asp, Input the ssid, security mode ext of the wireless router. You want to connect. Click the button 'Apply.', wait about 30s.



3. Access into the page http://192.168.16.254/home.asp again, check the connected information.



If the connection is not successful, please confirm the information of WIFI channel. If the module's channel is different from wifi router, please change it to the same one.

