General Podium Instructions

Volume Control

To use the projector, follow these steps:

- 1. Press the power ON button. You should hear a beep
- 2. If you need to switch to a different source, use the following

remote

buttons

- a. DVD or VCR = VIDEO (on remote)
- b. Podium Computer = Computer 1 (on remote)
- c. Instructor Laptop = Computer 2 (on remote)
- 3. To use your laptop, you may need to use your function keys (usually Fn + F8)
 - a. If you have an NVIDIA Graphics card, you may need further assistance
- 4. Volume Control for each devise is on the bottom left of the remote

Please shut down projector at end of class

- 5. To turn off projector, press the power OFF button
 - a. You will need to press once again to confirm

For help please call 773-442-5060 or xt. 5060

Input selection: VIDEO COMPUTER 1

COMPUTER 2

Power buttons