

B.B. Link Atom Operation Guide

PAIR THE RADIO

1. Power on the ATOM Lite.
2. Open B.B. Link Configurator and select **B.B. Link**.
3. On the radio, open **Menu > Bluetooth > Pairing Mode**.
4. In the Configurator, open **Paired Radio** and select the radio.
5. Accept the pairing request on the radio.

The pairing is stored, and the adapter reconnects automatically after restart.
A **breathing blue LED** indicates that the saved radio is connected.

CONNECT RADIOMAIL

1. Fully close B.B. Link Configurator.
2. In RadioMail, open **Settings > KISS TNC Modem > Default TNC**.
3. Select **B.B. Link**, then tap **Done**.
4. Open the connection screen and select a packet station.

A **solid blue LED** indicates that both the radio and the iOS device are connected.

RIG CONTROL

Rig control is enabled by default. The adapter initialises KISS mode and can respond to RadioMail frequency-change commands. Disable **Control Frequency** in B.B. Link Configurator if the adapter must not change radio settings.

TROUBLESHOOTING

If the adapter connects but the radio does not transmit, open **Menu > Configuration > Interface > KISS (983)** on the radio and set KISS to **Bluetooth**.

FACTORY RESET

Use **Reset Adapter** in B.B. Link Configurator.

CONTROLS

Action	Result
Short press	Disconnect and retry the saved radio connection (or exit battery charging mode)
Press 3+ times	Enter battery charging mode (disables Bluetooth radio emissions)
Hold for 2 seconds while running	Enter deep sleep
Press while sleeping	Wake the adapter

LED STATUS

LED	State
 Yellow	Waiting to pair
 Blue (Slow flash)	Scanning for the radio
 Blue (Breathing)	Radio connected; waiting for iOS
 Blue (Solid)	Radio and iOS connected
 Cyan (Slow flash)	Battery charging mode (Bluetooth off)
 Yellow (Fast flash)	Entering deep sleep
 Red (Slow flash)	Fatal error; reset required
 Green (Activity)	Receiving from the radio
 Red (Activity)	Transmitting to the radio
 Purple (Activity)	Simultaneous receive/transmit activity