

B.B. LINK ATOM OPERATION GUIDE

PAIR THE RADIO

1. Power on the ATOM Lite.
2. Open B.B. Link Configurator and select **B.B. Link**.
3. On the radio, open **Menu > Bluetooth > Pairing Mode**.
4. In the Configurator, open **Paired Radio** and select the radio.
5. Accept the pairing request on the radio.

The pairing is stored, and the adapter reconnects automatically after restart. A breathing blue LED indicates that the saved radio is connected.

CONNECT RADIOMAIL

1. Fully close B.B. Link Configurator.
2. In RadioMail, open **Settings > KISS TNC Modem > Default TNC**.
3. Select **B.B. Link Atom**, then tap **Done**.
4. Open the connection screen and select a packet station.

A solid blue LED indicates that both the radio and the iOS device are connected.

CONTROLS

ACTION	RESULT
Short press	Disconnect and retry the saved radio connection
Hold for 2 seconds while running	Enter deep sleep
Press while sleeping	Wake the adapter

LED STATUS

LED	STATE
	Waiting to pair
 Slow flashing	Scanning for the radio
 Breathing	Radio connected; waiting for iOS
 Solid	Radio and iOS connected
 Fast flashing	Entering deep sleep
 Slow flashing	Fatal error; reset required
 Activity	Receiving from the radio
 Activity	Transmitting to the radio
 Activity	Simultaneous receive/transmit activity

RIG CONTROL

Rig control is enabled by default. The adapter initialises KISS mode and can respond to RadioMail frequency-change commands. Disable **Control Frequency** in B.B. Link Configurator if the adapter must not change radio settings.

TROUBLESHOOTING

If the adapter connects but the radio does not transmit, open **Menu > Configuration > Interface > KISS (983)** on the radio and set KISS to **Bluetooth**.

FACTORY RESET

Use **Reset Adapter** in B.B. Link Configurator.