Launch Control XL 3 — Variation Lab (lab/stems)

Seven voices, each with the same three knobs: Variation (which pattern), Density (how many hits) and Push (syncopation). All knobs at 0 = a plain house groove: four-on-the-floor, off-beat hats, clap on 2 and 4, off-beat bass, syncopated stab.

The knobs are set to 0 on load. Variation: every position is a different pattern; the same position always gives the same one back. Button 1 = next instrument, button 2 = loop length 16 → 12 → 10 → 7 steps (runs against the bar). Column 6 plays slices of a recording: Variation picks where in the recording.

Knob Fader Button unused

Mode 16 — Variation Lab

	1 Low drum	2 Hats	3 Snap	4 Bass	5 Chords	6 Texture	7 Lead	8 Global
Row 1 Variation	CC 13 **Variation** 0 = the plain pattern; every other position is a different, fixed variant (32 in all).	CC 14 **Variation** as 1 Low drum	CC 15 **Variation** as 1 Low drum	CC 16 **Variation** as 1 Low drum	CC 17 **Variation** as 1 Low drum	CC 18 **Variation** as 1 Low drum	CC 19 **Variation** as 1 Low drum	CC 20 **Thin** 0 = full ↔ everything loses its low end (highpass up to 1.5 kHz): for breaks.
Row 2 Density	CC 21 **Density** 0 = few hits ↔ many hits, spread as evenly as possible.	CC 22 **Density** as 1 Low drum	CC 23 **Density** as 1 Low drum	CC 24 **Density** as 1 Low drum	CC 25 **Density** as 1 Low drum	CC 26 **Density** as 1 Low drum	CC 27 **Density** as 1 Low drum	CC 28 **Room** 0 = dry ↔ every voice in reverb (the low drum and the bass only a little).
Row 3 Push	CC 29 **Push** 0 = on the grid ↔ more and more hits come a 16th early (syncopation).	CC 30 **Push** as 1 Low drum	CC 31 **Push** as 1 Low drum	CC 32 **Push** as 1 Low drum	CC 33 **Push** as 1 Low drum	CC 34 **Push** as 1 Low drum	CC 35 **Push** as 1 Low drum	CC 36 **Drift** 0 = patterns stay ↔ every 16 / 8 / 4 / 2 / 1 bars one column rolls a new variant by itself, in turn.
Fader Level	CC 5 **Level** 0 = gone.	CC 6 **Level** as 1 Low drum	CC 7 **Level** as 1 Low drum	CC 8 **Level** as 1 Low drum	CC 9 **Level** as 1 Low drum	CC 10 **Level** as 1 Low drum	CC 11 **Level** as 1 Low drum	CC 12 **Master** 0–1, overall volume.
Button 1 Sound	CC 37 **Sound** 909 kick → 808 kick → sine thump → 808 tom.	CC 38 **Sound** 909 hats → 808 hats → metallic FM tick → noise click.	CC 39 **Sound** 909 clap → 808 rim → 909 snare → FM wood block.	CC 40 **Sound** rubber saw bass → FM bass → square pluck → deep sine.	CC 41 **Sound** FM glass → organ → saw stab → warm pad.	CC 42 **Sound** slices of: wind → insects → crows → gongs.	CC 43 **Sound** FM pluck → glockenspiel → acid saw → muted guitar.	CC 44 **Chapter** next chord root for bass, chords and lead: A → F → D → G.
Button 2 Loop length	CC 45 **Loop length** 16 → 12 → 10 → 7 steps, drifts against the bar.	CC 46 **Loop length** as 1 Low drum	CC 47 **Loop length** as 1 Low drum	CC 48 **Loop length** as 1 Low drum	CC 49 **Loop length** as 1 Low drum	CC 50 **Loop length** as 1 Low drum	CC 51 **Loop length** as 1 Low drum	CC 52 **Reroll** new dice for every column at once.

Generated from `lab/stems/variation-lab.strudel` — edit the `@ctl` comments in the track, not this sheet.