

River Test Report

| Summary                     |                           |        |        |        |      |      |       |  |
|-----------------------------|---------------------------|--------|--------|--------|------|------|-------|--|
| Serial Number               | BDDGTC033747              |        |        |        |      |      |       |  |
| Configuration Name          | DTU_FCT_RX_RY2            |        |        |        |      |      |       |  |
| River EOL Doc Version       | T0_DTU_V2.1               |        |        |        |      |      |       |  |
| Date                        | 27-07-2026_9.52.57 AM     |        |        |        |      |      |       |  |
| Operator                    | Charan_13573              |        |        |        |      |      |       |  |
| DUT                         | 1                         |        |        |        |      |      |       |  |
| Cycle time                  | 393.77                    |        |        |        |      |      |       |  |
| Overall Results             | Fail                      |        |        |        |      |      |       |  |
| Results                     |                           |        |        |        |      |      |       |  |
| Cycle time   393.77         |                           |        |        |        |      |      |       |  |
| Power Lines Impedance check | Config DAQ(1)             |        |        |        |      |      | 1.54  |  |
| Power Lines Impedance check | Read RES TP19-TP3         | 5.00   | 251.87 | Inf    | Pass | Kohm | 6.78  |  |
| Power Lines Impedance check | Config DAQ(3)             |        |        |        |      |      | 1.54  |  |
| Power Lines Impedance check | Read_RES_TP2-TP3          | 5.00   | 47.22  | Inf    | Pass | Kohm | 6.78  |  |
| Power Lines Impedance check | Config DAQ(5)             |        |        |        |      |      | 1.54  |  |
| Power Lines Impedance check | Read_RES_TP7-TP9          | 3.00   | 289.41 | Inf    | Pass | Kohm | 6.84  |  |
| Power Lines Impedance check | Config DAQ(7)             |        |        |        |      |      | 1.54  |  |
| Power Lines Impedance check | Read_RES_TP12-TP3         | 3.00   | 4.11   | Inf    | Pass | Kohm | 6.92  |  |
| J9 impedance check          | Config DAQ(11)            |        |        |        |      |      | 1.54  |  |
| J9 impedance check          | Read_RES_TP48-TP41        | 117.00 | 121.85 | 123.00 | Pass | ohm  | 6.78  |  |
| Power up                    | Set_14_PS1                |        |        |        |      |      | 1.54  |  |
| Power up                    | Set_14V_ps_to 3A          |        |        |        |      |      | 1.54  |  |
| Power up                    | Turn ON +14V & GND Relays |        |        |        |      |      | 1.53  |  |
| Power up                    | Turn_on_14VPS             |        |        |        |      |      | 0.74  |  |
| Power up                    | Config DAQ(18)            |        |        |        |      |      | 1.54  |  |
| Power up                    | Read_VOL_TP66-TP3         | 2.45   | 2.71   | 2.80   | Pass | V    | 6.71  |  |
| Voltage Measurements        | Config DAQ(21)            |        |        |        |      |      | 1.54  |  |
| Voltage Measurements        | Read_VOL_TP02-TP03        | 4.90   | 5.09   | 5.20   | Pass | V    | 7.71  |  |
| Voltage Measurements        | Config DAQ(19)            |        |        |        |      |      | 1.54  |  |
| Voltage Measurements        | Read_VOL_TP19-TP3         | 13.90  | 13.99  | 14.10  | Pass | V    | 11.13 |  |
| Voltage Measurements        | Config_DAQ(22)            |        |        |        |      |      | 1.54  |  |

|                      |                          |              |              |              |      |   |        |
|----------------------|--------------------------|--------------|--------------|--------------|------|---|--------|
| Voltage Measurements | Read_VOL_TP7-TP9         | 3.70         | 3.85         | 3.90         | Pass | V | 9.71   |
| Voltage Measurements | Config DAQ(23)           |              |              |              |      |   | 1.54   |
| Voltage Measurements | Read_VOL_TP12-TP13       | 2.90         | 3.02         | 3.10         | Pass | V | 10.42  |
| MCU Software Flash   | Flash Software           |              | PASS         |              | Pass |   | 6.88   |
| MCU Software Flash   | Power_CYCLE(1)           |              |              |              |      |   | 1.53   |
| MCU Software Flash   | Off_14V(1)               |              |              |              |      |   | 1.54   |
| MCU Software Flash   | On_Power_cycle(1)        |              |              |              |      |   | 1.53   |
| MCU Software Flash   | On_14V(1)                |              |              |              |      |   | 5.54   |
| S.No_write and read  | Write_Barcode            |              |              |              |      |   | 2.65   |
| S.No_write and read  | Read_barcode_STATUS      |              | 62 1         |              | Pass |   | 10.54  |
| S.No_write and read  | Power14Voff(1)           |              |              |              |      |   | 2.54   |
| S.No_write and read  | Poweron14V(1)            |              |              |              |      |   | 2.54   |
| S.No_write and read  | Send_Request_Barcode     |              |              |              |      |   | 1.54   |
| S.No_write and read  | Read_barcode_written     | BDDGTC033747 | BDDGTC033747 | BDDGTC033747 | Pass |   | 6.77   |
| S.No_write and read  | Write_RX_RY_check        |              |              |              |      |   | 2.54   |
| Pre-Flash Neoway     | SET_USB_RELAY            |              |              |              |      |   | 1.53   |
| Neoway Flashing      | Set Boot Mode            |              |              |              |      |   | 5.54   |
| Neoway Flashing      | Set_To_Boot_mode         |              |              |              |      |   | 5.54   |
| Neoway Flashing      | Set_USB_relay_on         |              |              |              |      |   | 1.54   |
| Neoway Flashing      | Flash Software(1)        |              | success      |              | Pass |   | 24.25  |
| Neoway Flashing      | Reset_Boot_Mode          |              |              |              |      |   | 3.54   |
| Post Neoway Flash    | Read_boot_mode_status    |              | 6F           |              | Pass |   | 10.54  |
| Post Neoway Flash    | Read_boot_state_again    |              | 6F 0         |              | Pass |   | 1.54   |
| Post Neoway Flash    | On_power                 |              |              |              |      |   | 1.53   |
| Post Neoway Flash    | OFF_14V_supply           |              |              |              |      |   | 1.54   |
| Post Neoway Flash    | ON_14V_again(1)          |              |              |              |      |   | 10.54  |
| Check N58 Flash      | Send_N58_Check_msg       |              |              |              |      |   | 10.54  |
| Check N58 Flash      | Send_again_n58_flash_msg |              |              |              |      |   | 10.54  |
| Check N58 Flash      | Resend_N58_Rest msg      |              |              |              |      |   | 2.54   |
| Check N58 Flash      | Read-check_ssl           |              | 0            |              | Pass |   | 0.74   |
| SSL Certification    | Connect USB relays       |              |              |              |      |   | 1.53   |
| SSL Certification    | Read_Set_SSL             |              |              |              | Fail |   | 145.07 |