

Quick Start Guide

EFM32TG-STK3300



Congratulations with your new EFM32 Tiny Gecko Starter Kit. Your package should include

- EFM32 Tiny Gecko Starter Kit Board
- USB cable
- CD with IAR Embedded Workbench for ARM, Kickstart edition
- Quick Start Guide (this document)

Please follow these simple steps to start using your new Starter Kit.

1. Download and install Energy Micro Simplicity Studio Software Package.

http://www.energymicro.com/downloads/software

2. Install your choice of development environment (eg. one of the below).

IAR - Embedded Workbench for ARM http://www.iar.com or enclosed CD

Rowley Associates - Crossworks for ARM http://www.rowley.co.uk

CodeSourcery - Sourcery G++ http://www.codesourcery.com

Keil - MDK-ARM http://www.keil.com

- 3. Review the enclosed documentation for your selected development environment, and the EFM32TG-STK3300 user guide found through Simplicity Studio.
- 4. This product includes J-Link Technology. Download and install the latest SEGGER J-Link ARM software

http://www.segger.com/cms/jlink-software.html

- 5. Attach the enclosed USB cable to your PC and kit
- 6. Your kit is ready to use. Source examples are supplied through Simplicity Studio.

For detailed information, please refer to the EFM32TG-STK3300 User Manual, document t0011.

This product is compliant with

Electromagnetic Compatibility (EMC) 2004/108/EC

FCC CFR 47 Part 15 (2008)

RoHS compliant

J-Link Technology by













...the world's most energy friendly microcontrollers

Declaration of Conformity



Energy Micro AS, Sandakervien 118, P.O Box 4633 Nydalen, Oslo, Norway, declares that the following product(s):

- EFM32 Tiny Gecko Starter Kit
- EFM32TG-STK3300

has (have) been tested and conform(s) with the essential requirements and other relevant provision of the following harmonized standard(s) and directive(s):

EN 55022 (2006)

and therefore comply with the essential requirements and provisions of the following Directives of the European Parliament and European Council:

Electromagnetic Compatibility (EMC) 2004/108/EC

The technical test has been executed following the Norwegian accreditation scheme by Nemko, P.O. Box 73 Blindern, N-0314 Oslo, Norway:

Test Report No. E11025.00

Oslo, Norway, 1 April 2011

Jen i pire

President and CEO