

## **Off-line Print Introduction**

Insert Micro SD card to the machine which had stored the Gcode files.



LCD screen and Key-press function instruction.



Key name	Key function	Remark
Left	Back To Previous Menu	
Right	Go to next menu/Enter	
Up	Menu Up / Plus	
Down	Menu Down / Minus	
Middle	Start menu	

## **Off-line Print Introduction**

After inserting the micro SD card into the board, connect the power cord, then you can operate the machine with key and display. Show as below:

