

# COURSE NOTES

## FOUNDATIONS OF SOLID MECHANICS

Hanfeng Zhai

**Disclaimer:** These notes are intended solely for personal reference and study purposes. They represent my own understanding of the course material and may contain errors or inaccuracies. The content presented here should not be considered as an authoritative source, and reliance solely on these materials is not recommended. If you notice any materials that potentially infringe upon the copyright of others, please contact me at [hz253@cornell.edu](mailto:hz253@cornell.edu) so that appropriate action can be taken. Your feedback is greatly appreciated.

2021

Week 1: Mon. 8/29/2021


Vectors & tensors.  $\rightarrow$  Cartesian.

In Physics, we are familiar with

$$\left\{ \begin{array}{l} \nabla \times \vec{E} = 0 \\ \nabla \cdot \vec{E} = \frac{\rho}{\epsilon_0} \end{array} \right. \Rightarrow \text{Electro-statics.}$$

which is, independent of coordinate system

in a RH coordinate.



$$\text{index subscript } \vec{e}_i \cdot \vec{e}_j \equiv \delta_{ij} = \begin{cases} 1, & i=j \\ 0, & \text{if } i \neq j \end{cases}$$


called Kronecker delta.

(in orthonormal basis).


Here,  $v_i$  is component of  $\vec{v}$  with a basis  $\{\vec{e}_i\}$ .

$$= \sum_{j=1}^3 v_j \vec{e}_j$$

transformation of basis.



summation convention



$$\text{Sum of } v \cdot e_i = v_i e_i = v_k e_k$$

repeated indices.

term: subscripts.  $a_{ij} b_k c_m \rightarrow$  free indices.

$\downarrow$

summing over j

contraction, if  $i=m$ .

$\alpha_{ip} b_k c_{pi} \rightarrow$  double summation.

\*\*\* A dummy index cannot repeat more than 2!!!

$$\delta_{ij} \delta_{jk} = \delta_{ik} = \delta_{ik}.$$

$$\begin{aligned} \text{e.g. } \delta_{ij} \delta_{jk} &= \delta_{ii} \delta_{kk} + \delta_{i2} \delta_{2k} + \delta_{i3} \delta_{3k} \\ &= \delta_{ik}. \end{aligned}$$

$\delta_{2k}$  ( $i=2$ ),  $\delta_{3k}$  ( $i=3$ ).

$$\vec{v} \cdot \vec{w} = v_i \vec{e}_i \cdot w_j \vec{e}_j = v_i w_j (\vec{e}_i \cdot \vec{e}_j)$$

$\underbrace{\delta_{ij}}$

$$= v_i w_i = v_j w_j.$$

usual dot product.


Cross product.

$$\vec{v} \times \vec{w} = v_i \vec{e}_i \times w_j \vec{e}_j = v_i w_j \vec{e}_i \times \vec{e}_j \quad (a).$$

$$\vec{e}_i \times \vec{e}_j = [(\vec{e}_i \times \vec{e}_j) \cdot \vec{e}_k] \vec{e}_k$$

free index on two sides of Eqn. must  
be equal !!!  $= \epsilon_{ijk}$  (Permutation symbol)

e.g.



$$(\vec{a} \times \vec{e}_2) \cdot \vec{e}_3 = 1.$$

$$G_{ijk} = 1, (1, 2, 3), (3, 1, 2), (2, 3, 1).$$

$$= -1, (2, 1, 3), (1, 3, 2), (3, 2, 1).$$

$$= 0, \text{ otherwise}.$$

Review undergrad linear algebra  
det( $\sim$ ).

e.g. (a) writes.  $\vec{v}_i w_j G_{ijk} \vec{e}_k$

$$\Rightarrow G_{ijk} v_i w_j \vec{e}_k$$

$$= G_{klj} v_i w_j \vec{e}_k$$

$$Q. \vec{a} \times (\vec{b} \times \vec{c}) = ?$$

$$= a_k \vec{e}_k \times (b_i c_j \vec{e}_i \times \vec{e}_j)$$

$$= a_k \vec{e}_k \times (b_i c_j G_{ilm} \vec{e}_m)$$

$$= a_k b_i c_j (\delta_{iw} \delta_{jk} - \delta_{ik} \delta_{jw}) \vec{e}_w$$

$$= (a_i \vec{e}_i) \times [a_p j_k b_j c_k \vec{e}_p]$$

$$= (\delta_{ij} \delta_{lk} - \delta_{ik} \delta_{lj}) a_i b_j c_k \vec{e}_s$$

$$= (b_s a_k c_k - b_i a_i c_s) \vec{e}_s$$

$$= [b_s (\vec{a} \cdot \vec{c}) - (\vec{a} \cdot \vec{b}) c_s] \cdot \vec{e}_s$$

$$= (\vec{a} \cdot \vec{c}) \vec{b} - (\vec{a} \cdot \vec{b}) \vec{c}$$

• How vectors transform? (on basis)

$$\vec{v} = v_i \vec{e}_i = v'_j \vec{e}'_j$$

$$v'_j = (\vec{v} \cdot \vec{e}'_j) = (v_i \vec{e}_i \cdot \vec{e}'_j)$$

$$= v_i (\vec{e}_i \cdot \vec{e}'_j)$$

$$P_{ji} = \vec{e}'_j \cdot \vec{e}_i$$

projection of one basis on another basis.

$$\vec{v}'_j = P_{ji} \cdot \vec{v}_i$$

$$\vec{v}' = \begin{bmatrix} v'_1 \\ v'_2 \\ v'_3 \end{bmatrix} \quad \vec{v} = \begin{bmatrix} v_1 \\ v_2 \\ v_3 \end{bmatrix} \quad \vec{P} = [P_{ji}]$$

$$\vec{v}' = \vec{P} \vec{v}$$

$$\vec{v} = \vec{P}^{-1} \vec{v}'$$

$$\vec{P}^{-1} = \vec{P}^T$$

off-course supplementary :

Week 1: Wed.

9/1/2021.

Second order Tensor  $\underline{\underline{A}}$ .


A 2<sup>nd</sup> order tensor is a linear transformation from  $\mathbb{E}^3$  to  $\mathbb{E}^3$ .

LT = a special kind of mapping  $\mathbb{E}^3 \rightarrow \mathbb{E}^3$

properties:

$\underline{\underline{A}}(\underline{u})$  to some vector

$\underline{\underline{A}}: (\underline{u}) \rightarrow \underline{\underline{A}}(\underline{u}).$



$$\rightarrow \underline{\underline{A}}(au) = a\underline{\underline{A}}(\underline{u}).$$

↑ real No.

$$\rightarrow \underline{\underline{A}}(\underline{u} + \underline{w}) = \underline{\underline{A}}(\underline{u}) + \underline{\underline{A}}(\underline{w}).$$

$$\uparrow$$
$$\underline{\underline{A}}(au + bw) = a\underline{\underline{A}}(\underline{u}) + b\underline{\underline{A}}(\underline{w}).$$

$\forall \underline{u}, \underline{w} \in \mathbb{E}^3$  and  $a, b$ .

$$\underline{\underline{A}}(0) = 0.$$

Example rigid body rotation about a fixed point.

Definition gradient tensor.

Stress tensor

$$\underline{x} = x_i \vec{e}_i$$

$$\underline{\underline{A}}(\underline{x}) = \underline{\underline{A}}(x_j \vec{e}_j).$$

$$= \underline{\underline{A}}_{ij} x_j \underline{\underline{A}}(\vec{e}_j)$$

this tells us that a linear transformation is completely determined by its action on the basis vectors.

$$\underline{\underline{A}}(\vec{e}_j) = a_{ij} \vec{e}_i \quad \rightarrow a_{ij} \vec{e}_i (\vec{e}_j \cdot \underline{x})$$

$$\underline{\underline{A}}(x_j \vec{e}_j) = a_{ij} x_j \underline{\underline{A}}(\vec{e}_j) = a_{ij} x_j \vec{e}_i$$

$$\underline{\underline{A}}(\vec{e}_1) \cdot \underline{e}_1 = a_{11}$$

$$\underline{\underline{A}}(\vec{e}_1) \cdot \underline{e}_2 = a_{12}$$

$$\underline{\underline{A}}(\vec{e}_1) \cdot \underline{e}_3 = a_{13}$$

$$A = \begin{bmatrix} Aa_{11} & a_{12} & a_{13} \\ a_{21} & Aa_{22} & a_{23} \\ a_{31} & a_{32} & Aa_{33} \end{bmatrix}$$

$$\underline{\underline{A}}(\underline{x}) = a_{ij} \vec{e}_i (\vec{e}_j \cdot \underline{x})$$

$$= a_{ij} \underbrace{\vec{e}_i \vec{e}_j}_{\underline{\underline{A}}} \cdot \underline{x}$$

Define  $\underline{\underline{ab}}$  as the linear transformation

$$(\underline{\underline{ab}})(\underline{x}) = \underline{\underline{a}}(\underline{b} \cdot \underline{x}). \quad ??$$

check: this is a LT.

$$> = \underline{\underline{A}} \cdot \underline{x} \quad (\text{we can skip the dot}). \quad ??$$

$\underline{\underline{ab}}$   $\rightarrow$  dyad

\*\*\* Any linear transformation can be written as sum of dyad

$$\underline{\underline{ab}} \Leftrightarrow \underline{\underline{a}} \otimes \underline{\underline{b}} \rightarrow \text{linear transformation.}$$

A simple representation:  $\underline{\underline{A}} = a_{ij} \vec{e}_i \vec{e}_j$

$$\underline{\underline{ab}} \neq \underline{\underline{ba}}$$

$$\underline{e}_i \rightarrow \underline{e}'_i$$

$$\underline{\underline{A}} = a_{ij} \underline{e}_i \underline{e}_j = a'_{is} \underline{e}'_i \underline{e}'_s$$

$$= a_{ij} (\underbrace{\underline{e}_i \cdot \underline{e}'_r}_{\underline{e}_i} \underbrace{\underline{e}'_r \cdot \underline{e}_j}_{\underline{e}_j} \underbrace{(\underline{e}_j \cdot \underline{e}'_s)}_{\underline{e}'_s})$$

$$= a_{ij} (\underbrace{\underline{e}_i \cdot \underline{e}'_r}_{P_{ri}} \underbrace{(\underline{e}'_r \cdot \underline{e}_s)}_{P_{sj}})$$

$$= a'_{is} \underline{e}'_i \underline{e}'_s$$

$$a'_{is} = a_{ij} P_{rs} P_{ij}$$

$$[\underline{P}\underline{A}]_j [\underline{P}^T]_{js}$$

$$\underline{\underline{A}}' = \underline{P}\underline{A}\underline{P}^T \quad \underline{P}\underline{A}'\underline{P} = \underline{\underline{A}}$$

$$\Downarrow [a'_{is}]$$

$$\underline{\underline{A}}(\underline{x}) = \underline{y}$$

$$\det \underline{\underline{A}} \equiv \det \underline{\underline{A}}$$

$$\det \underline{\underline{A}} = \det (\underline{P}^T \underline{A}' \underline{P}) = \det \underline{P}^T \det \underline{A}' \det \underline{P}$$

$$= \det (\underline{P}^T \underline{P}) \det \underline{A}'$$

I

$$= \det \underline{A}'$$

\*\*\* Det is invariant

$$(a\underline{\underline{A}} + b\underline{\underline{B}})(\underline{x}) = a\underline{\underline{A}}(\underline{x}) + b\underline{\underline{B}}(\underline{x})$$

composition  $\underline{\underline{A}}^{-1}$  of mapping.

$$(\underline{\underline{A}} \circ \underline{\underline{B}})(\underline{x}) = \underline{\underline{A}}(\underline{\underline{B}}(\underline{x}))$$

$$= \underline{\underline{A}} \cdot (\underline{\underline{B}} \cdot \underline{x})$$

$$\underline{\underline{B}} \cdot \underline{x} = b_{ij} \underline{e}_i \underline{e}_j \cdot \underline{x}$$

$$\underline{\underline{A}} \cdot (\underline{\underline{B}} \cdot \underline{x}) = (a'_{is} \underline{e}'_i \underline{e}'_s) \cdot b_{ij} \underline{e}_i \underline{e}_j \cdot \underline{x}$$

$$= a'_{is} \underline{e}'_i \underline{b}_{sj} (\underline{e}_s \cdot \underline{e}_i) \underline{e}_j \cdot \underline{x}$$

$$= a'_{is} b_{sj} \underline{e}'_i \underline{e}_j \cdot \underline{x}$$

$$[\underline{\underline{C}}] = C \quad C = AB$$

$$\underline{\underline{A}}^{-1} \circ \underline{\underline{A}} = \underline{\underline{I}}$$

$$\underline{\underline{I}} = \delta_{ij} \underline{\underline{e}_i} \underline{\underline{e}_j} = \underline{\underline{e}_i} \underline{\underline{e}_i}$$

↓  
identity tensor.

$\underline{\underline{A}}^T$ : transpose of  $\underline{\underline{A}}$ .

$$\underline{\underline{v}} \cdot \underline{\underline{A}}^T \cdot \underline{\underline{u}} = \underline{\underline{u}} \cdot \underline{\underline{A}} \cdot \underline{\underline{v}}$$

for all  $\underline{\underline{u}}$  &  $\underline{\underline{v}}$  in  $\mathbb{E}^3$

$$\underline{\underline{u}} = \underline{\underline{e}_j}$$

$$\underline{\underline{v}} = \underline{\underline{e}_i}$$

$$\left\{ \begin{array}{l} \underline{\underline{e}_j} \cdot \underline{\underline{A}} \cdot \underline{\underline{e}_i} \\ = \underline{\underline{e}_j} \cdot \underbrace{a_{rs} \underline{\underline{e}_r} \underline{\underline{e}_s}}_{\delta_{si}} \cdot \underline{\underline{e}_i} \\ = a_{rs} \delta_{jr} \delta_{si} = a_{ji}. \end{array} \right.$$

$$\underline{\underline{e}_i} \cdot \underline{\underline{A}}^T \cdot \underline{\underline{e}_j} = \underline{\underline{a}}_{ij}^T = a_{ji}.$$

true for 1 coord.

true for all  $\sim$

$$(\underline{\underline{A}} + \underline{\underline{B}})^T = \underline{\underline{A}}^T + \underline{\underline{B}}^T$$

$$(\underline{\underline{A}}^T)^T = \underline{\underline{A}}$$

$$(\underline{\underline{A}}^{-1})^T = (\underline{\underline{A}}^T)^{-1}$$

$$(\underline{\underline{A}} \circ \underline{\underline{B}})^T = \underline{\underline{B}}^T \circ \underline{\underline{A}}^T$$

$$\underline{\underline{A}}^T = \underline{\underline{A}} \quad \text{symmetric}$$

$$\underline{\underline{A}}^T = -\underline{\underline{A}} \quad \text{asymmetric} \rightarrow \text{mechanics of solids.}$$

\*\*\* Eigenvalue of asymmetric tensor

$\det(\underline{\underline{A}} - \lambda \underline{\underline{I}}) \rightarrow \text{independent of basis}$

$$= \det(\underline{\underline{A}}' - \lambda \underline{\underline{I}})$$

$$= \det \left[ \underbrace{\underline{\underline{P}} \underline{\underline{A}} \underline{\underline{P}}^T}_{\underline{\underline{A}}'} - \lambda \underline{\underline{I}} \right].$$

$$= \det \left[ \underline{\underline{P}} (\underline{\underline{A}} - \lambda \underline{\underline{I}}) \underline{\underline{P}}^T \right]$$

$$= \underbrace{\det[\underline{\underline{P}} \underline{\underline{P}}^T]}_1 \det(\underline{\underline{A}} - \lambda \underline{\underline{I}})$$

$$= \det(\underline{\underline{A}} - \lambda \underline{\underline{I}}).$$

$$\det(\underline{\underline{A}} - \lambda \underline{\underline{I}})$$

$$= P_3(\lambda) = (-\lambda)^3 + I_1 \lambda^2 + I_2 \lambda + \det \underline{\underline{A}}.$$

$$I_1 = \frac{1}{2} [(\text{tr}(\underline{\underline{A}}))^2 - \text{tr}(\underline{\underline{A}}^2)]$$

$$I_2 = a_{11} = \text{tr}(\underline{\underline{A}}).$$

$$\hookrightarrow a_{11} + a_{22} + a_{33}.$$

$I_1, I_2, \det A$

are scalar invariants of the tensor  $\underline{\underline{A}}$

$$\underline{\underline{A}} = \lambda_1 \underline{\underline{E}_1} \underline{\underline{E}_1} + \lambda_2 \underline{\underline{E}_2} \underline{\underline{E}_2} + \lambda_3 \underline{\underline{E}_3} \underline{\underline{E}_3}$$

$$D = \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \lambda_2 & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix} \quad \left\{ \begin{array}{l} \underline{\underline{E}_1} \\ \vdots \\ \underline{\underline{E}_3} \end{array} \right.$$

↑  
eigenvectors of  $\underline{\underline{A}}$

$$\det A = \lambda_1 \lambda_2 \lambda_3$$

$$I_2 = \lambda_1 + \lambda_2 + \lambda_3.$$

$$I_1 = \lambda_1 \lambda_2 + \lambda_2 \lambda_3 + \lambda_1 \lambda_3.$$

\* how to diagonalize  $3 \times 3$  matrix.

(Labor day - Monday).

Week 2: Wed.

(Review)

$$\underline{\underline{A}}(\underline{v}) = \underline{\underline{A}} \cdot \underline{v}$$

$$\underline{\underline{A}} = a_{ij} \underline{e}_i \underline{e}_j$$

$$\underline{\underline{A}}(\underline{v}) = a_{ij} v_j \underline{e}_i$$

$$= a_{ij} \underline{e}_i \underbrace{\underline{e}_j \cdot \underline{v}}_{\underline{v}_j}.$$

$$(\underline{\underline{A}} \circ \underline{\underline{B}})(\underline{v}) = \underline{\underline{A}}(\underline{\underline{B}}(\underline{v}))$$

$$= (a_{ij} \underline{e}_i \underline{e}_j)(b_{kl} v_k \underline{e}_k).$$

$$= a_{ij} \underline{e}_i b_{kl} v_k \underline{e}_j$$

$$= a_{ij} b_{ji} v_k \underline{e}_i$$

in other words,

$$\underline{\underline{A}} \circ \underline{\underline{B}} = \underbrace{a_{ij} b_{ji}}_{\lambda} \underline{e}_i \underline{e}_i$$

$$= \underline{\underline{A}} \otimes \underline{\underline{B}} =$$

$$\underline{\underline{A}} = a_{ij} \underline{e}_i \underline{e}_j, \quad \underline{\underline{B}} = b_{kl} \underline{e}_k \underline{e}_l$$

$$\underline{\underline{A}} \cdot \underline{\underline{B}} = a_{ij} \underline{e}_i \underline{e}_j \cdot b_{kl} \underline{e}_k \underline{e}_l$$

$$\underline{\underline{AB}} = \underline{\underline{A}} \circ \underline{\underline{B}}$$

$A$  $B$

$$\underline{AB} : \underline{cd} = (\underline{a} \cdot \underline{c})(\underline{b} \cdot \underline{d}).$$

$$\underline{ab} \cdots \underline{cd} = (\underline{a} \cdot \underline{d})(\underline{c} \cdot \underline{b}).$$

$$\underline{A} = a_{ij} \underline{e}_i \underline{e}_j$$

$$\underline{B} = b_{kl} \underline{e}_k \underline{e}_l$$


$$\underline{A} : \underline{B} = (a_{ij} \underline{e}_i \underline{e}_j) : (b_{kl} \underline{e}_k \underline{e}_l).$$

$$\underline{A} : \underline{B} = a_{ij} b_{kl} (\underbrace{\underline{e}_i \cdot \underline{e}_k}_{\delta_{ik}})(\underbrace{\underline{e}_j \cdot \underline{e}_l}_{\delta_{jl}}).$$

$$= a_{kj} b_{kj} \rightarrow \text{scalar}$$

↳ can be extended to 2 angular relations of linear transformations.

e.g. for vectors



$$\text{tr}(\underline{A})$$

$$= a_{ij} (\underbrace{e_i \cdot e_j}_{\delta_{ij}}) = a_{ii}.$$

$$\text{tr}(\underline{A} + \underline{B}) = \text{tr} \underline{A} + \text{tr} \underline{B}.$$

$$\text{tr}(a \underline{A}) = a \text{tr}(\underline{A}).$$

$$\text{tr}(\underline{A}^T) = \text{tr}(\underline{A}).$$

$$\text{tr}(\underline{A} \circ \underline{B}) = \text{tr}(\underline{B} \circ \underline{A})$$

### Tensor field

Scalar field  $f(x)$


$$df = \frac{\partial f}{\partial x_i} dx_i.$$

$$= \frac{\partial f}{\partial x_i} (\underline{e}_i \cdot d\underline{x}).$$

$$\nabla f = \frac{\partial f}{\partial x_i} \underline{e}_i$$

$$= \nabla f \cdot d\underline{x}$$

$$dx_i = d\underline{x} \cdot \underline{e}_i$$



$$\nabla f \cdot \underline{v} = ?$$

$$\lim_{t \rightarrow 0} \left( \frac{u(x+t\underline{v}) - u(x)}{t} \right) \leftarrow (\nabla u) \cdot \underline{v} \equiv \lim_{t \rightarrow 0} \frac{u(x+t\underline{v})}{t}$$

$$= \left[ u(x) + \frac{\partial u}{\partial x_i} + v_i \right] - u_i(x).$$

$$= \frac{\partial \underline{u}}{\partial x_k} v_k$$

$$= \frac{\partial(u_i e_i)}{\partial x_k} v_k = \frac{\partial u_i}{\partial x_k} e_i (e_k \cdot \underline{v}).$$

$$= (\underbrace{\frac{\partial u_i}{\partial x_k} e_i e_k}_{\nabla \underline{u}}) \cdot \underline{v}$$

$$\nabla^2 \underline{u} = \frac{\partial u_i}{\partial x_{ik}} e_i e_k \rightarrow \text{bump up by 1 order (w/ gradients).}$$

$$\nabla \underline{P} = \frac{\partial \underline{P}}{\partial x_k} e_k$$


$$= \frac{\partial P_{ij}}{\partial x_k} e_i e_j e_k$$

$$\text{tr}(\nabla \underline{u}) = \frac{\partial u_i}{\partial x_k} (e_i \cdot e_k)$$

$$= \frac{\partial u_i}{\partial x_i}$$

$$= \nabla \cdot \underline{u}.$$

$$\nabla \cdot \underline{P} = \frac{\partial P_{ij}}{\partial x_k} e_i (\underbrace{e_j \cdot e_k}_{\delta_{jk}}) = \frac{\partial P_{ij}}{\partial x_j} e_i$$



$$\iiint_V f_i dV = \iint_S f n_i dS.$$


$$f_{,i} = \frac{\partial f}{\partial x_i}$$

$$\int_V u_{j,i} dV = \int_S u_j n_i dS \quad \}$$

$$\int_V T_{k,i} dV = \int_S T_{k,e} n_i dS. \quad \}$$


## Mechanics.

$\left\{ \begin{array}{l} \text{kinematics. } \checkmark \quad (\text{geometry}). \\ \text{Balance laws } \checkmark \quad (\text{forces, moments, ...}) \\ \text{Constitutive laws } \leftarrow \begin{array}{l} \text{"Research":} \\ \text{connect. k.} \end{array} \end{array} \right.$



Week 3: Mon.

kinematics.




Material point is labeled by its coordinate  $\tilde{X}$  or  $\bar{X}$ .

(Ref. config.).

$\Omega_0$  is the configuration of the Body at  $t=0$ .

Normally we choose  $\Omega_0$  to be the undeformed state of the body.

$$\underline{x} - \underline{\mathbb{I}} = \underline{u}(\underline{\mathbb{I}}, t)$$



$t > 0$ . Body deforms at occupies  $\Omega_t$ .

$\tilde{X} \rightarrow \tilde{x}$   
mapping.

this is a mapping:  $\underline{x} = \underline{\tilde{x}}(\underline{\tilde{X}}, t)$ ,  
 $= \underline{x}(\underline{\tilde{X}}, t)$ .

function "kan".

$$\underline{u} = \underline{x} - \underline{\bar{x}} \rightarrow \text{displacement vector.}$$

Always assume mapping  $\underline{x}$  is one-one point.

given one point

Another point associated w/  
it.

\*\*\* Some simple examples: (motion).

$$\underline{x} = \underline{\bar{x}} + \underline{c}(t). \quad \text{Rigid body translation.}$$

X interesting cuz no deformation.

\*\*\* e.g. 2.

rectangular cross section.

Let  $\Omega_0$  be a bar, (straight bar)

$$\text{we define } \underline{x} = \underline{\bar{x}} + \sum_{k=1}^3 (\lambda_k - 1) \underline{x}_k \underline{e}_k.$$

(remember)


$$\underline{u} = \underline{x} - \underline{\bar{x}}$$

$$\underline{u} = \sum_{k=1}^3 (\lambda_k - 1) \underline{x}_k \underline{e}_k$$

$\downarrow$   
real positive numbers.

$\lambda_k = 1$ : no displacements  $\rightarrow$  body remain initial state.

$\lambda_k \neq 1$ : stretch & compress in  $\underline{e}_1, \underline{e}_2, \underline{e}_3$  directions  
 $\hookrightarrow$  Stretch ratios.



$$\lambda_k = \frac{L}{L_0}.$$

\* you can always impose a displacement field on a body.

Rigid body rotation.

$$\underline{x} = \underline{\bar{x}} + \underline{R}(\underline{\theta}) \underline{e}_k.$$

$$\underline{e}_k \rightarrow \underline{R}(\underline{\theta}_k) \underline{e}_k$$

$$\boxed{\underline{R} = n_k \underline{e}_k} \leftrightarrow \text{rotation.}$$

linear trans.  $\rightarrow$  completely det. by action on its basis

does not increase any defination



$$d\underline{x} = \frac{\partial \underline{x}}{\partial \underline{X}_j} d\underline{X}_j \quad (\text{def of grad.}).$$

$$= \underbrace{\nabla_{\underline{X}} \underline{x}}_F \cdot d\underline{X}.$$

$\underline{F} = \nabla_{\underline{X}}$  → deformation gradient tensor.

↳ contains all the information on local deformation.  
 $\underline{F}(\underline{X}, t)$

$$\underbrace{\nabla_{\underline{X}} \underline{x}}_F = \frac{\partial (x_i e_i)}{\partial \underline{X}_j} e_j$$

$$\underline{F} = \frac{\partial x_i}{\partial \underline{X}_j} e_i e_j$$

$$[\underline{F}] = \begin{bmatrix} \frac{\partial x_1}{\partial \underline{X}_1} & \frac{\partial x_1}{\partial \underline{X}_2} & \frac{\partial x_1}{\partial \underline{X}_3} \\ \vdots & \vdots & \vdots \end{bmatrix}.$$

respect to the basis  $e_i, e_j$

$$d\underline{x} = \underline{F} \cdot d\underline{X}$$

change of length (fiber)

$$d\underline{x} \cdot d\underline{x} - d\underline{X} \cdot d\underline{X}$$

$$= (\underline{F} \cdot d\underline{X}) \cdot (\underline{F} \cdot d\underline{X}) - d\underline{X} \cdot d\underline{X}$$

$$= d\underline{X} \cdot \underbrace{(\underline{F}^T \cdot \underline{F})}_{C} \cdot d\underline{X} - d\underline{X} \cdot d\underline{X}$$

$C$  is the Cauchy-Green Tensor

$$= d\underline{X} \cdot (C - I) \cdot d\underline{X}.$$

$$I \cdot d\underline{X} = d\underline{X} \quad \downarrow E$$

$$\frac{\|d\underline{x}\|^2}{\|d\underline{X}\|^2} = \left( \frac{\|d\underline{x}\|}{\|d\underline{X}\|} \right)^2 \text{ Lagrangian Strain Tensor}$$

$$\frac{d\underline{x} \cdot d\underline{x}}{\|d\underline{X}\|^2} - 1$$

$$= \frac{d\underline{X}}{\|d\underline{X}\|} \cdot C \cdot \frac{d\underline{X}}{\|d\underline{X}\|} - 1$$


$$= \underbrace{N \cdot C \cdot N}_{\text{unit vector}} - 1$$

stretch ratio

$\underline{X}, t$ .

Solid:  $\underline{X} \rightarrow$  reference configuration.

Fluid:  $\underline{X} \rightarrow$  spatial  $\rightarrow$  current coordinates.



$$\text{Ex 1: } \underline{u} = \sum_{k=1}^3 (\lambda_k - 1) \otimes x_k e_k \quad (3k).$$

↑ don't use enumeration  
with  $\lambda$  !!.

$$[\underline{F}] = \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \lambda_2 & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix} \quad \underline{F} = \lambda_1 \underline{e}_1 \underline{e}_1 + \lambda_2 \underline{e}_2 \underline{e}_2 + \lambda_3 \underline{e}_3 \underline{e}_3$$

$$\underline{F} = \lambda_1 \underline{e}_1 \underline{e}_1 + \lambda_2 \underline{e}_2 \underline{e}_2 + \lambda_3 \underline{e}_3 \underline{e}_3.$$

$$\lambda_1 = \lambda_2 = \lambda_3 > 1.$$

uniform expansion:  $[\underline{F}] = \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \lambda_2 & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix}$

uniform compression

$$\det \underline{F} = J$$

Rubber is almost incompressible,  
so  $J \approx 1$ .

invariant

$$= \lambda_1 \lambda_2 \lambda_3$$


In general,  $\det \underline{F} = \frac{dV}{dV_0}$  the deform of the volume over the reference (original) volume.

always true.

$$= \frac{V}{V_0} \leftarrow \text{new}$$

reference volume

in a tension bar:



$$\underline{\epsilon} = \epsilon_{ij} \underline{e}_i \underline{e}_j$$

$$\epsilon_{ij} = \frac{1}{2} \left( \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right) + \underbrace{\frac{1}{2} \left( \frac{\partial u_k}{\partial x_i} \cdot \frac{\partial u_k}{\partial x_j} \right)}_{\epsilon_{ij}}$$

small strain tensor  
(1% ~ 2%).

effect of  
large defor.  
quadratic term.

$$10^{-2} \cdot 10^{-2} = 10^{-4}$$

$$(10^{-2}\% \sim 4 \cdot 10^{-2}\%)$$

Week 3.

Sep. 15th (Wed.)

### Review: $\underline{\underline{F}}$ Deformation Gradient Tensor

completely characterize the local deformation at a point  $\underline{x}$ .

$\underline{\underline{F}}(\underline{x}, t)$ ,  $\underline{x}, t$ , independent variables.

Material description.

$\underline{\underline{C}} = \underline{\underline{F}}^T \underline{\underline{F}}$  Right Cauchy-Green Tensor

$$\underline{\underline{E}} = \underline{\underline{F}}^T \underline{\underline{F}} - \underline{\underline{I}}.$$

$$d\underline{x} \cdot d\underline{x} = d\underline{x} \cdot \underline{\underline{C}} \cdot d\underline{x}$$

$$\begin{aligned} \underline{n} \text{ is a} \\ \text{unit vector.} \end{aligned}$$
$$\frac{\|\underline{dx}\|^2}{\|\underline{d\underline{x}}\|^2} = \frac{\underline{n} \cdot \underline{dx}}{\|\underline{d\underline{x}}\|} \cdot \underline{\underline{C}} \cdot \frac{\underline{n} \cdot \underline{dx}}{\|\underline{d\underline{x}}\|}$$

$$\frac{\|\underline{dx}\|}{\|\underline{d\underline{x}}\|} = \lambda.$$

Ratio of length of material line element.

Stretch Ratio =  $\frac{\text{length of mat. line ele. in the Ref. configuration.}}{\text{length of mat. line ele. in the current configuration.}}$

$$\lambda_n^2 = \underline{\underline{N}} \cdot \underline{\underline{C}} \cdot \underline{\underline{N}}.$$

$$\underline{\underline{N}} \cdot \underline{\underline{E}} \cdot \underline{\underline{N}} = \lambda_n^2 - 1. \quad \downarrow \quad \text{Lagrangian Strain tensor.} \quad \text{measure the deformation.}$$

$$E_{ij} = \frac{1}{2} \left[ \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right] + \frac{1}{2} \left[ \frac{\partial u_k}{\partial x_i} + \frac{\partial u_k}{\partial x_j} \right]$$

$E_{ij}$

Remember:

$$\underline{x} = \underline{x} + \underline{u}(\underline{x}, t).$$

Both  $\underline{\underline{C}}$  &  $\underline{\underline{E}}$  are symmetric Tensors.

$$\underline{\underline{C}}^T = \underline{\underline{C}}. \quad \text{Recall } \underline{\underline{F}} \text{ is reversible.}$$

$$\underline{\underline{F}}^T \underline{\underline{F}} = \underline{\underline{C}}.$$

$\downarrow$  reversible  $\uparrow$   $\underline{\underline{C}}$  is positive definite.

$$\begin{aligned} \underline{d\underline{x}} \cdot \underline{\underline{C}} \cdot \underline{d\underline{x}} > 0. \quad \text{only when } \underline{d\underline{x}} = 0. \\ \text{identical} \quad \rightarrow \|\underline{\underline{F}} \cdot \underline{d\underline{x}}\|^2 > 0. \quad \underline{d\underline{x}} \neq 0. \quad \text{Real.} \\ (\text{exactly}) \end{aligned}$$

$\underline{\underline{C}}$  symmetric implies that  $\underline{\underline{C}}$  has eigenvalues

$$\lambda_1^2 > \lambda_2^2 > \lambda_3^2 \in \lambda_1, \lambda_2, \lambda_3.$$

eigenvalues

$\underline{\underline{C}}$  positive definite implies  $\lambda_i^2 > 0$ .

$i=1, 2, 3$ .

$\underline{\underline{C}}$  can be diagonalized

that is,  $\underline{\underline{C}}$  can be written as

$$\underline{\underline{C}} = \lambda_1^2 \underline{\underline{n}}_1 \underline{\underline{n}}_1 + \lambda_2^2 \underline{\underline{n}}_2 \underline{\underline{n}}_2 + \lambda_3^2 \underline{\underline{n}}_3 \underline{\underline{n}}_3$$

$\underline{\underline{n}}$  are orthonormal eigen vectors of  $\underline{\underline{C}}$

that is  $\underline{n}_i \cdot \underline{n}_j = \delta_{ij}$

THIS  $\lambda_1, \lambda_2, \lambda_3$  are called principal stretches.

$\underline{n}_i$ 's are the principal direction.

### Polar Decomposition Theorem

$$\underline{\underline{F}} = \underline{\underline{R}} \underline{\underline{U}} = \underline{\underline{V}} \underline{\underline{R}}$$

$\underline{\underline{R}}$  is a rigid body rotation tensor,  $\underline{\underline{R}}^T = \underline{\underline{R}}^{-1}$

$$\underline{\underline{R}}^T \underline{\underline{R}} = \underline{\underline{R}} \underline{\underline{R}}^T = \underline{\underline{I}}$$

$\underline{\underline{U}}$  is symmetric, positive definite.

$$\text{and } \underline{\underline{U}}^2 = \underline{\underline{C}} \quad \& \quad \underline{\underline{U}} = \sqrt{\underline{\underline{C}}}$$

$$\underline{\underline{U}} = \lambda_1 \underline{\underline{n}}_1 \underline{\underline{n}}_1 + \lambda_2 \underline{\underline{n}}_2 \underline{\underline{n}}_2 + \lambda_3 \underline{\underline{n}}_3 \underline{\underline{n}}_3$$

$$\underline{\underline{\text{check}}} \quad \underline{\underline{U}} \cdot \underline{\underline{U}} = \underline{\underline{U}}^2 = \underline{\underline{C}}$$

$\underline{\underline{F}}$  can be decompose into two simple tensor,

where first tensor,  $\underline{\underline{U}}$   $\rightarrow$  stretch tensor.

↓


it stretch the material

point in principal directions

then it rotate with  $\underline{\underline{R}}$ .

$$\underline{\underline{F}} = \underline{\underline{R}} \underline{\underline{U}} \cdot \underline{\underline{I}}. \rightarrow \text{this a local theorem}$$

$\underline{\underline{U}}$  comes first, and  $\underline{\underline{R}}$  comes second.



$$n_i = R(n_i)$$

\* Only need to prove

$$\underline{\underline{R}} = \underline{\underline{F}} \underline{\underline{U}}^{-1} \text{ is a rotation.}$$

$$\underline{\underline{R}}^T \underline{\underline{R}} = \underline{\underline{I}}.$$

$$\underline{\underline{R}}^T \underline{\underline{R}} = (\underline{\underline{F}} \underline{\underline{U}}^{-1})^T (\underline{\underline{F}} \underline{\underline{U}}^{-1}).$$

$$= (\underline{\underline{U}}^T \underline{\underline{F}}^T) (\underline{\underline{F}} \underline{\underline{U}}^{-1}) = \underline{\underline{U}}^{-1} \underline{\underline{F}}^T \underline{\underline{F}} \underline{\underline{U}}^{-1}$$

Symmetric  $\downarrow$   
 $\underline{\underline{U}}^{-1}$

$$= \underline{\underline{U}}^{-1} \underline{\underline{U}} \underline{\underline{U}} \underline{\underline{U}}^{-1}$$

$$= \underline{\underline{I}}$$

Therefore we prove:  $\underline{\underline{R}} \underline{\underline{R}}^T = \underline{\underline{R}}^T \underline{\underline{R}} = \underline{\underline{I}}$ .

$$\underline{n}_i = \underline{\underline{R}}(\underline{n}_i).$$

$$\underline{\underline{R}} = \underline{n}_i \underline{n}_i = \underline{n}_1 \underline{n}_1 + \underline{n}_2 \underline{n}_2 + \underline{n}_3 \underline{n}_3.$$

\*\*\* Decomposition is unique.  
eeeeeeeeeeeeeeeee.

$$\text{if we define: } \underline{\underline{V}} = \lambda_1 \underline{n}_1 \underline{n}_1 + \lambda_2 \underline{n}_2 \underline{n}_2 + \lambda_3 \underline{n}_3 \underline{n}_3.$$

$$\underline{\underline{V}} \underline{\underline{B}} = (\lambda_1 \underline{n}_1 \underline{n}_1 + \lambda_2 \underline{n}_2 \underline{n}_2 + \lambda_3 \underline{n}_3 \underline{n}_3) \cdot \\ (\underline{n}_1 \underline{n}_1 + \underline{n}_2 \underline{n}_2 + \underline{n}_3 \underline{n}_3).$$

$$= \lambda_1 \underline{n}_1 \underline{n}_1 \underline{n}_1 + \lambda_2 \underline{n}_2 \underline{n}_2 \underline{n}_2 + \lambda_3 \underline{n}_3 \underline{n}_3 \underline{n}_3$$

then we can check:

$$\underline{\underline{R}} \underline{\underline{U}} = \underline{\underline{V}} \underline{\underline{R}}.$$

[IN CASE] in mechanics theorem paper,

Someone writes:

$$\underline{\underline{F}} = \underline{\underline{F}}_{IA} \underline{\underline{e}}.$$

$\underline{\underline{F}}_{IA} \in \underline{\underline{E}}_A \rightarrow$  two point tensor


$$\underline{\underline{e}}_i \cdot \underline{\underline{e}}_j = \delta_{ij}$$

$$\underline{\underline{E}}_A \cdot \underline{\underline{E}}_B = \delta_{AB}$$

in the ref. config.  $\underline{\underline{e}}_1, \underline{\underline{e}}_2, \underline{\underline{e}}_3$

current config.

$$\underline{\underline{E}}_1, \underline{\underline{E}}_2, \underline{\underline{E}}_3$$



Simple Shear Deformation.

$$\begin{cases} x_1 = x_1 + I \tan \gamma & \text{fixed number} \\ x_2 = x_2 \\ x_3 = x_3 \end{cases} \quad (0, \pi/2).$$

$$x = x_i \underline{\underline{e}}_i \quad [\underline{\underline{E}}] = \begin{bmatrix} 1 & \tan \gamma & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

$$\underline{F} = \underline{e}_1 \underline{e}_1 + \tan \gamma \underline{e}_1 \underline{e}_2 + \underline{e}_2 \underline{e}_2 + \underline{e}_3 \underline{e}_3$$



$$\det \underline{F} = 1.$$

$$\hookrightarrow \det (\underline{R} \underline{U}) = \underbrace{\det \underline{R}}_{=1} + \det \underline{U} \rightarrow \lambda_1, \lambda_2, \lambda_3.$$

↓

$$\frac{\underline{U}}{V_0}$$

$$\underline{F} =$$



Office How:

$$\underline{F} = (\delta_{ij} + u_{ij}) \underline{e}_i \underline{e}_j$$

$$\underline{E} = \frac{1}{2} [u_{i,j} + u_{j,i} + u_{k,i} u_{k,j}],$$

$$ij = \frac{\partial}{\partial x_j}$$

Week 4 (5). Mon.

Linear Theory. (small deformation).

↪ perturbation theory.

geometry change small.

(gradients of displacements small,  $\ll 1$ ).

$$\bar{\epsilon} = \frac{1}{2} \left[ \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} + \frac{\partial u_k}{\partial x_i} \frac{\partial u_k}{\partial x_j} \right].$$

$$u_k = u_k e_k.$$

higher order terms.

terms.

$$\approx \frac{1}{2} \left[ \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right].$$

leading order terms

$$\underline{\epsilon} - \underline{\underline{\epsilon}} = 2 \bar{\epsilon}. \quad \underline{\underline{\epsilon}} = \underline{\underline{\epsilon}} + \underline{\underline{\omega}}.$$

Small rotation tensor

$$\underline{F} = \underline{\underline{\epsilon}} + \frac{\partial u_i}{\partial x_j} e_i e_j \rightarrow \bar{\epsilon}_{ij}$$

$$\frac{\partial u_i}{\partial x_j} = \frac{1}{2} \left( \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right) + \frac{1}{2} \left[ \frac{\partial u_i}{\partial x_j} - \frac{\partial u_j}{\partial x_i} \right]$$

sym Anti-sym

$$G_{ij} = K_{ij} + \epsilon_{ij} + \omega_{ij} \left( \delta_{ij} + \epsilon_{ij} + \omega_{ij} \right)$$

$$= \delta_{ij} \delta_{ij} + \delta_{ij} \epsilon_{ij} + \epsilon_{ij} \delta_{ij} +$$

$$\epsilon_{ij} \epsilon_{ij} + \epsilon_{ij} \omega_{ij}$$

$$+ \omega_{ij} \delta_{ij} + \omega_{ij} \epsilon_{ij}$$

$$+ \omega_{ij} \epsilon_{ij} + \omega_{ij} \omega_{ij}$$

$$\underline{\epsilon} = \underline{\underline{\epsilon}}^2. (???)$$

$$\underline{\epsilon} \approx \underline{\underline{\epsilon}} + 2 \bar{\epsilon}.$$

$$\underline{\underline{\epsilon}} \approx \underline{\underline{\epsilon}} + \underline{\underline{\epsilon}}. \quad \underline{\underline{\epsilon}}^2 = \underline{\underline{\epsilon}} + 2 \bar{\epsilon} + \bar{\epsilon} \bar{\epsilon}$$

$$\approx \underline{\underline{\epsilon}} + 2 \bar{\epsilon}.$$

$$\underline{\underline{\epsilon}}^+ \approx \underline{\underline{\epsilon}} - \underline{\underline{\epsilon}}.$$

$$\underline{F}^{-1} = \underline{R} \underline{\underline{\epsilon}}$$

$$\underline{R} = \underline{F} \underline{\underline{\epsilon}}^+. \quad \underline{R} \approx (\underline{\underline{\epsilon}} + \underline{\underline{\omega}})(\underline{\underline{\epsilon}} - \underline{\underline{\epsilon}}).$$

$$\underline{\underline{\epsilon}}^+ = \frac{\partial \underline{x}}{\partial t} \Big|_{\substack{\text{fix.} \\ \underline{x}}} = \frac{\partial \underline{u}}{\partial t} \Big|_{\substack{\text{fix.} \\ \underline{x}}} = \underline{\underline{\epsilon}} - \underline{\underline{\omega}} + \underline{\underline{\omega}}.$$

↪ (at a fixed material point)

$$\underline{x} = \underline{\xi} + \underline{u}(\underline{\xi}, t).$$

$$\underline{A} = \frac{\partial^2 \underline{x}}{\partial t^2} \Big|_{\substack{\underline{x} \\ \underline{\xi}}} = \frac{\partial^2 \underline{u}}{\partial t^2} \Big|_{\substack{\underline{x} \\ \underline{\xi}}} = \underline{\underline{\alpha}}$$

$$\underline{V}(\underline{x}, t).$$

mechanics: quantities in spatial descrip.

density

$$\rho(\underline{x}, t).$$

the material derivative:

$$\dot{f}(x, t) = f(\underline{\chi}(\underline{x}, t)).$$

$$\frac{Df}{Dt} = \dot{f} \quad \text{Fixed } \underline{x}.$$

$$= \frac{\partial f}{\partial x_i} \frac{\partial \underline{\chi}_i}{\partial t} + \frac{\partial f}{\partial t} \Big|_{\underline{x}} \\ \underline{x} = \underline{\chi}^{-1}(x, t)$$

velocity,

$$\underline{v}_i(\underline{x}, t).$$

$$= \frac{\partial f}{\partial x_i} \underline{v}_i(\underline{x}, t) + \frac{\partial f}{\partial t} \Big|_{\underline{x}} = \nabla_{\underline{x}} f \cdot \underline{v} + \frac{\partial f}{\partial t} \Big|_{\underline{x}}$$

$$\nabla_{\underline{x}} f = \frac{\partial f}{\partial x_j} e_j.$$

$$\nabla_{\underline{x}} g = \frac{\partial g}{\partial x_j} e_j.$$

$$\underline{V} = \underline{V}(\underline{x}, t) = \frac{\partial \underline{\chi}}{\partial t} \Big|_{\underline{x}}.$$

$$\underline{x} = \underline{V}(\underline{\chi}^1(x, t), t) \cdot \underline{x} = \underline{\chi}^1(x, t).$$

In the spatial configuration.

$$\underline{a} = \underline{A}(\underline{\chi}^{-1}(x, t), t).$$



$$\underline{a} = \underline{v} \cdot \nabla_{\underline{x}} \underline{v} + \frac{\partial \underline{v}}{\partial t} \Big|_{\underline{x}}.$$

Concept of Stress

if given displacement field, & ref. config.

( $\Rightarrow$  then we can calculate everything)

Assumption: Cauchy's hypothesis.



Surface interactions

Important: orientation  $\Rightarrow$  X shape.

$$\underline{\tau} = \frac{\partial f}{\partial s} \quad ds \rightarrow 0 \\ = \underline{\tau}(n, \underline{x}, t).$$


$\underline{n}$  → outward unit normal vector in the current configuration.

$\underline{t}$  → traction vector (stress).

If we know traction in 3D, then we

know the stress at this point.

Cauchy's theorem.



Force on pyramid?

$\underline{t}_3$ .

Body forces → depends on volume of element.

$\rho$  = mass per unit volume in current configuration.

Body forces per unit volume in linear momentum balance.

$$\underline{t} dA - \underline{t}_1 dA_1 - \underline{t}_2 dA_2 - \underline{t}_3 dA_3 + \rho dv$$

$$= m \frac{\partial \underline{v}}{\partial t} \cdot (\rho dV) \underline{a}.$$

$dV$  is the volume of small pyramid

$$dA \gg dV, \quad \frac{dV}{dA} \rightarrow 0.$$

(in small pyramid).

$$\underline{t} = \underline{t}_1 \frac{dA_1}{dV} + \underline{t}_2 \frac{dA_2}{dV} + \underline{t}_3 \frac{dA_3}{dV}$$

$$\underline{t} = \underline{\epsilon} \underline{n} + \underline{t}_2 \underline{n} + \underline{t}_3 \underline{n}$$

$$\underline{t}_1 \underline{\epsilon}_1 \cdot \underline{n} + \underline{t}_2 \underline{\epsilon}_2 \cdot \underline{n} + \underline{t}_3 \underline{\epsilon}_3 \cdot \underline{n}$$

$$\underline{t}_1 = \underline{\sigma}_1 \underline{\epsilon}_1$$

$$\underline{\epsilon}_k = \underline{\epsilon}_k \underline{\epsilon}_k, \quad k = 1, 2, 3.$$

$$\underline{t}_j = \underline{\sigma}_{ij} \underline{\epsilon}_i$$

$$= \underline{\sigma}_{ij} \underline{\epsilon}_i \underline{\epsilon}_j \cdot \underline{n}.$$


(other text book:  
 $\underline{\sigma} = \underline{\sigma}^T \cdot \underline{n}$ ).

$\underline{\sigma}$  = Cauchy or True stress tensor

$$\underline{t}_j = \underline{\sigma}_{ji} \underline{n}_i$$

$$\underline{t} = \underline{\sigma} \cdot \underline{n}$$

Week 4, Wed.




$$t_2 = \sigma_{12} e_1 + \sigma_{22} e_2 + \sigma_{32} e_3.$$

$\underline{\sigma}$  True stress tensor in current config.

Cauchy

$\underline{\sigma} \cdot \underline{n} = \underline{t} \rightarrow$  traction vector.



\* Equilibrium equation - Deformed configuration  
(LMB)

Linear momentum balance.

Key Results.

$$\nabla_x \cdot \underline{\sigma} + \rho b = \rho \cdot \underline{a}$$

Body force  
acceleration

spatial. Divergence.

$$\frac{\partial \sigma_{ij}}{\partial x_j} + \rho b_i = \rho a_i. \dots (N1)$$

Current config. !!

In real-world applications, cuz you didn't know

current config.

In elastic prob., we use reference config.

In Ref config.

$\bar{t}q. (N1)$  become:

$$\nabla_{\underline{x}} \cdot \underline{\underline{P}} + p_0 \underline{\underline{B}} = p_0 \underline{\underline{A}}.$$

$$\frac{\partial P_{ij}}{\partial x_j} + p_0 B_i - p_0 A_i. \quad \downarrow \underline{\underline{A}} = \underline{\underline{A}}(\underline{x}, t).$$

First Piola Tensor  $\Rightarrow$  Nominal Stress tensor

AMB Angular momentum balance.


AMB.

$$\underline{\underline{P}} \underline{\underline{F}}^T = \underline{\underline{F}}^T \underline{\underline{P}}^T.$$

Derivation.

METHOD I:

Forces acting on  $\Omega_t$ .



(F.1)

(Force balance) integral of  $\int_{\Omega_t} \rho b dV$

$$+ \int_{\Omega_t} \underline{\underline{\Sigma}} \cdot \underline{n} dS \quad (\text{traction})$$

AMB

(Newton's law). +  $\frac{D}{Dt} \int_{\Omega_t} \rho \underline{v} dV$  \*\*\* cannot take inside.

$$\rho dV = \rho_0 dV_0 \quad \text{conservation of mass.}$$

$$\rho \frac{dV}{dV_0} = \frac{\rho_0}{\rho} = \det \underline{\underline{F}}$$

Jacobian.

$\bar{t}q. (F1)$  becomes.

$$\frac{D}{Dt} \int_{\Omega_t} \rho \underline{\underline{v}} dV = \frac{D}{Dt} \int_{\Omega_0} \rho_0 \underline{\underline{V}} dV_0$$

fixed

So can take  $\frac{D}{Dt}$  inside

$$= \int_{\Omega_0} \rho_0 \underline{\underline{A}} \cdot \underline{\underline{v}} dV_0.$$

$$= \int_{\Omega_t} \rho \underline{\underline{a}} dV$$

$$\int_{\partial\Omega_t} \underline{\underline{\Sigma}} \cdot \underline{n} dS + \int_{\Omega_t} (\rho b - \rho \underline{\underline{a}}) dV.$$

Divergence theorem.

$$\int_{\Omega_t} \nabla_{\underline{x}} \cdot \underline{\underline{\Sigma}} dV$$


$$\int_{\Omega_t} [\nabla_{\underline{x}} \cdot \underline{\underline{\Sigma}} + \rho b - \rho \underline{\underline{a}}] dV = 0$$

This is true for any  $\Omega_t \Rightarrow$

$$\Rightarrow \nabla_x \cdot \underline{\sigma} + p b = p a.$$

$$[\sigma_{23}(x,t) + \frac{\partial \sigma_{23}}{\partial x_3} dx_3]$$

FINISHED !!!




Net force in 1D,

$$\left[ \frac{\partial \sigma_{23}}{\partial x_2} + \frac{\partial \sigma_{31}}{\partial x_3} + \frac{\partial \sigma_{12}}{\partial x_1} \right] dx_1 dx_2 dx_3.$$

$$+ p b dx_1 dx_2 dx_3 = p a dx_1 dx_2 dx_3.$$

$$\frac{\partial \sigma_{ij}}{\partial x_j} + p b_i = p a_i.$$


$\Delta \rightarrow$  total force.




force

$$\sigma_{ij} = \sigma_{ji}$$

$$\int_{\Omega} p \underline{b} dV_0 + \int_{\partial R_t} \underline{\sigma} \cdot \underline{n} ds = \int_{\Omega} p \underline{A} dV_0$$



$$I = \sigma \cdot n = \frac{df}{dS_t} \Rightarrow I dS_t = df.$$



$$dV = \underline{n} \cdot dS_t \cdot d\underline{x} = \underline{n} \cdot dS_t \cdot \underline{F} \cdot d\underline{x}$$

$$dV_0 = N \cdot dS_0 \cdot d\underline{x}$$

$$\frac{dV}{dV_0} = \det \underline{F} = J$$

$$\underline{n} \cdot dS_t \cdot \underline{F} \cdot d\underline{x} = J \underline{n} \cdot dS_0 \cdot d\underline{x}$$

$$d\underline{x} \cdot dS_t \underline{F}^T \cdot \underline{n} = d\underline{x} \cdot J \underline{n} \cdot dS_0$$

$d\underline{x}$  is solitairy!

$$dS_t \cdot \underline{F}^T \cdot \underline{n} = J \underline{n} \cdot dS_0$$

$$\underline{F}^T \cdot \underline{n} \cdot dS_0 = J \underline{n} \cdot dS_0$$

Substitute

$$\int_{\partial \Omega_t} \underline{x} \cdot \underline{n} \cdot d\underline{s}$$

$$\underline{n} \cdot dS_0 = J \underline{F}^T \cdot \underline{n} \cdot dS_0$$

Nansen's formula

Nansen's

$$\int_{\partial \Omega_0} J \underline{F}^T \cdot \underline{n} \cdot dS_0$$


$\rightarrow \underline{P}$

By definition

$$\underline{P} = J \underline{F}^T \underline{F}^{-1}$$

Divergence

$$\int_{\partial \Omega_0} \nabla_{\underline{x}} \cdot \underline{P} dV_0 \rightarrow \nabla_{\underline{x}} \cdot \underline{P} + \oint_{\partial \Omega_0} \underline{B} = \underline{S}_0 \cdot \underline{A}$$



$$\underline{t} \times dS_0 = df = t dS_t$$

$$\underline{P} \cdot \underline{n} = t$$

↓

not a symmetric tensor

$$\underline{P} = J \underline{F}^T \underline{F}^{-1}$$

↓

not symmetric

symmetric -

$$\underline{P} \underline{F}^T = \underline{F} \underline{P}^T \Rightarrow \underline{P} \underline{F}^T = \underline{P} \underline{F}^{-1}$$

AMB.

In fluid mech., use current config. at variables.

Basic balance laws of continuum mechanics

(Derived in current configuration)

Office hour Fri. 3:30pm.

HW #2.

$$\underline{A} = a_{ij} \underline{e}_i \underline{e}_j$$

$\{\underline{e}_i\}$  original basis.

$\{\underline{e}_j\}$  New.

$$\begin{bmatrix} a_{11} & a_{12} & a_{13} \\ a_{21} & a_{22} & a_{23} \\ a_{31} & a_{32} & a_{33} \end{bmatrix}$$

whole num.

$\lambda_i$ : eigenvalues.

Symmetry.

$$\underline{A} \text{ in new basis: } \underline{A} = \lambda_1 \underline{E}_1 \underline{E}_1 + \lambda_2 \underline{E}_2 \underline{E}_2$$

$$+ \lambda_3 \underline{E}_3 \underline{E}_3$$

$$\rightarrow \begin{bmatrix} 6 & -2 & -1 \\ -2 & 6 & -1 \\ -1 & -1 & 3 \end{bmatrix}$$

$$\text{Eigenvalues: } \lambda_1 = 8, \lambda_2 = 6, \lambda_3 = 3$$

Original one:  $\underline{A} = 6\underline{e}_1 \underline{e}_1 - 2\underline{e}_1 \underline{e}_2 - 1\underline{e}_1 \underline{e}_3 \dots$

↳ So,  $\underline{A} = 8\underline{E}_1 \underline{E}_1 + 6\underline{E}_2 \underline{E}_2 + 3\underline{E}_3 \underline{E}_3$

what is  $\underline{E}_1$ ?

Original tensor  $\underline{A} = a_{ij} \underline{e}_i \underline{e}_j$ .

$$= \lambda_1 \underline{E}_1 \underline{E}_1 + \lambda_2 \underline{E}_2 \underline{E}_2 + \lambda_3 \underline{E}_3 \underline{E}_3$$

$$\underline{E}_1 \cdot \underline{E}_1 = 1, \underline{E}_2 \cdot \underline{E}_1 = 0, \underline{E}_3 \cdot \underline{E}_1 = 0$$

need to normalize to 1

$$(a_{ij} \underline{e}_i \underline{e}_j) \cdot \underline{E}_1 = \lambda_1 \underline{E}_1$$

$$\underline{E}_1 \cdot \underline{e}_j = P_{ij}$$

$$a_{ij} \underbrace{\underline{e}_i (\underline{e}_j \cdot \underline{E}_1)}_{P_{ij}} = \lambda_1 \underline{E}_1$$

$$\nabla$$

$$\underline{E}_1 = P_{1i} \underline{e}_i$$

$$a_{ij} P_{ij} \underline{e}_i = \lambda_1 \underline{E}_1 = \lambda_1 P_{1i} \underline{e}_i$$

$$\text{or } [a_{ij} P_{ij} - \lambda_1 P_{1i}] \underline{e}_j = 0$$

$$\Rightarrow a_{ij} \vec{p}_j - \lambda \vec{p}_{ii} = 0 \quad i=1,2,3$$

$$A = [a_{ij}] \quad A \vec{p}_i - \lambda \vec{p}_i = 0$$

$\vec{p}_i = \begin{bmatrix} p_{i1} \\ p_{i2} \\ p_{i3} \end{bmatrix}$

eigen vector  
of  $A$  for  $\lambda$

$$(A - \lambda I) \vec{p}_i = 0$$

$\lambda \rightarrow$  eigenvalue of  $A$

$\vec{p}_i$  is a eigen vector for  $A$  ( $\lambda_i$ ).

$$\vec{e}_i = P_{ii} \underline{e}_i$$

$$\vec{e}_i \cdot \vec{e}_i = 1. \quad P_{ii} P_{ii} = 1$$

Same idea applies to  $\vec{e}_2$

$$\vec{e}_2 = P_{22} \underline{e}_i \leftarrow \lambda_2$$

$\vec{e}_3 \dots$

$$\underline{A} \cdot (\underline{e}_1 + \underline{e}_2) = \dots$$

\* get the same as matter which basis ...

$$\underline{A} = (\underline{e}_1 \underline{e}_2)$$

linear transformation

$\underline{A} \cdot \underline{e}_1 =$  first column of  $\underline{A}$ .

$$(\underline{e}_1 \underline{e}_2) \cdot \underline{e}_1 = 0$$

$$A = \begin{pmatrix} 0 & 1 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{pmatrix}$$

$$\underline{A} \cdot \underline{e}_2 = (\underline{e}_1 \underline{e}_2) \cdot \underline{e}_2 = \underline{e}_1 (\underline{e}_2 \cdot \underline{e}_2) = \underline{e}_1.$$

$$= 1 \underline{e}_1 + 0 \underline{e}_2 + 0 \underline{e}_3$$

$$\underline{A} \cdot \underline{e}_3 = 0$$

respect to basis

$$\{\underline{e}_1, \underline{e}_2, \underline{e}_3\}$$

$$\underline{A} = a_{ij} \underline{e}_i \underline{e}_j$$

$$[\underline{e}_1 \underline{e}_2] = \begin{pmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{pmatrix}$$

$$[A] = \begin{bmatrix} a_{11} & 0 & 0 \\ 0 & a_{22} & 0 \\ 0 & 0 & 0 \end{bmatrix} + \begin{bmatrix} 0 & a_{12} & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix} +$$

$$= a_{11} e_1 e_1 + \dots$$

$$\underline{v} = v_1 e_1 + v_2 e_2 + v_3 e_3.$$

$$\bar{e}_1 = \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix}.$$

$$\underline{v} = \begin{bmatrix} v_1 \\ v_2 \\ v_3 \end{bmatrix}.$$

$$\rightarrow v_1 \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix} + v_2 \begin{bmatrix} 0 \\ 1 \\ 0 \end{bmatrix} + \dots$$

$$\underline{v} = e_1$$

$e_i e_j$

$$\underline{A} = a_{11} e_1 e_1 + a_{12} e_1 e_2 + a_{13} e_1 e_3 + \dots$$

$$\underline{[A]} = \begin{bmatrix} a_{11} & a_{12} & a_{13} \\ a_{21} & a_{22} & a_{23} \\ a_{31} & a_{32} & a_{33} \end{bmatrix}$$

break it down into simple linear  
comps.

$$\underline{v} = v_1 e_1 + v_2 e_2 + v_3 e_3$$

\* Eigenvalues  $\rightarrow$  invariants

Eigen vectors  $\rightarrow$  be care of the basis !!!

$$\{e_1, e_2, e_3\} \rightarrow E_i = P_{ij} e_j$$

$$\{\bar{e}_1, \bar{e}_2, \bar{e}_3\}.$$

$$\bar{P}_i = \begin{bmatrix} P_{i1} \\ P_{i2} \\ P_{i3} \end{bmatrix}.$$

with respect to this basis.

associated with  $P_{ij}$ .

$\underline{W}$  = Skew Symmetric

$$\underline{\underline{W}} \cdot \underline{v} = \underline{ad} \times \underline{v}$$



expand: \*\*\* Need to tell what  $\underline{W}$  is

$$\underline{\underline{W}} = w_{12} \underline{e}_1 \underline{e}_2 + w_{21} \underline{e}_2 \underline{e}_1 + \dots$$

$$w_{11}, w_{22}, w_{33}, = 0,$$

$$\underline{\underline{W}} \cdot \underline{v} = \underline{P} \times \underline{v}.$$

$$w_{21} = -w_{12}$$

$$= w_{12} \underline{e}_1 \underline{e}_2 - w_{12} \underline{e}_2 \underline{e}_1 + \dots$$

$$\underline{\underline{W}} \cdot \underline{v} \rightarrow \underline{v} = v_i \underline{e}_i$$

$$\underline{P} \times \underline{v} = \dots v_1 \dots v_2 \dots v_3$$

$$P_1 = w_{32}$$

$$P_2 = w_{13}.$$

$$P_3 = w_{21}.$$

$$\triangleright P = w_{32} \underline{e}_1 + w_{13} \underline{e}_2 + w_{21} \underline{e}_3.$$

Sep 27. Week 3.

Personal Review - So far:

→ Cartesian Tensors.

- Review on Notation.

Summation Convention (Indical notation)

Permutation symbol.

Transformation Rule for vectors

▷ Second Order tensors.

▷ Transpose of tensor

Symmetric & Skew-Symmetric tensor

Tensor transformation (basis, ...)

Operations of tensors: (products, ...)

Symmetric tensors: Diagonalization.

High order tensor

Trace of second order tensor

High order tensor

Tensor fields.

Kinematics

Sep 27, Week 5. Mon.

Review: last lecture: balance laws.

True stress tensor  $\underline{\underline{\sigma}}$  in current coordinate.

$$\rightarrow \nabla_{\underline{x}} \cdot \underline{\underline{\sigma}} + p \underline{b} = p \underline{a} \quad \text{invariate form}$$

$$\frac{\partial \sigma_{ij}}{\partial x_j} + p b_i = p a_i. \quad i=1, 2, 3. \quad (\times \text{ config. influence})$$

3 PDEs. in the current coordinate  
~~AAA~~

Independent spatial variable are  $x_i$ .

$$\underline{\underline{\sigma}} = \underline{\underline{\sigma}}^T, \quad \underline{\underline{\sigma}} = \underline{\underline{\sigma}}^T$$

Balance law in reference configuration, independent variables are  $\underline{x}_i$ .

$\underline{\underline{P}}$  (Nominal or 1st Piola stress tensor).

$$\underline{\underline{P}} = J \underline{\underline{\sigma}} \underline{\underline{F}}^{-T} \rightarrow J = \det \underline{\underline{F}}.$$

true stress.

$$\underline{\underline{\sigma}} = \frac{1}{J} \underline{\underline{P}} \underline{\underline{F}}^T$$

$$\underline{\underline{\sigma}} (\underline{x} = \underline{x}(\underline{\underline{x}}, t), t)$$

$$\nabla_{\underline{x}} \underline{\underline{P}} + p_0 \underline{B}_0 = p_0 \underline{A}$$

$$\frac{\partial P_{ij}}{\partial x_j} + p_0 B_{0i} = p_0 A_i.$$

$\underline{\underline{P}}$  is not always symmetric

so. an.. (AMB)  $\underline{\underline{P}} \underline{\underline{F}}^T = \underline{\underline{F}} \underline{\underline{P}}^T$

Proof.

$$\det \underline{\underline{F}} = J = \frac{dV}{dV_0}, \quad p_0 dV_0 = p dV$$

$$\frac{p_0}{p} = \frac{dV}{dV_0} = J = \det \underline{\underline{F}}$$

Material is called incompressible if  $J=1$ ,  $\forall \underline{x}$


Review Part

$$\underline{\underline{P}} \cdot \underline{N} dS_0 = \underline{\underline{\sigma}} \cdot \underline{N} \cdot dS_0$$

Simple example:  $\underline{\underline{\sigma}} = \sigma_{11} \underline{e}_1 \underline{e}_1$

$$\sigma_{11} = \frac{F}{A}$$


$$P_0 = \frac{F}{A_0}$$



Incompressible solid.  $J = \lambda_1 \lambda_2 \lambda_3 = 1$ .

$$\lambda = \frac{1}{J \lambda_1}$$

Plane stress



$$\text{Sym} \rightarrow \sigma_{31} = \sigma_{32} = 0.$$

None-vanishing stress state.  $\left\{ \begin{array}{l} \text{hydrostatic pressure } i, w \gg t. \\ (\text{atmosphere}) \end{array} \right.$

$$\sigma_{11}, \sigma_{12} = \sigma_{21}, \sigma_{22}$$

$$\sigma_{\alpha\beta}, \alpha, \beta = 1, 2.$$

Assumption:  $\sigma_{\alpha\beta}(x_1, x_2, t)$ , independent of  $x_3$

$$\text{Equilibrium Eq: } \frac{\partial \sigma_{\alpha\beta}}{\partial x_\beta} + \rho b_\alpha = \rho g^0$$




Quasi-static problem

Reduce to a 2D problem

Pure shear:

$$\underline{\sigma} = \sigma_{12} e_1 e_2 + \sigma_{21} e_2 e_1$$

$$= \tau (e_1 e_2 + e_2 e_1).$$



Hooke - Young equation.

Equilibrium.

$$\gamma_w \cos \theta - \gamma_{ls} = \gamma_{vs}$$


$$\frac{\gamma}{G a} = \text{elastoplasticity no.}$$

shear modulus.

water leak out  $\rightarrow$  poroelasticity

EASY WAY TO DO THIS:

$$\left[ \begin{array}{l} \text{glued.} \rightarrow u_3 = 0 \\ \nabla_{\bar{x}} \underline{P} = -\rho \underline{B}_0 \\ \underline{P} \cdot \underline{n} = 0 \end{array} \right] \quad \underline{P} = -\rho g \underline{e}_3$$



3 equations  $\rightarrow$  6 unknowns ( $\underline{\sigma}_{\alpha\beta}$ ).

3 unknowns  $\rightarrow \hat{\underline{u}}$ .

9 unknowns.

## Nonlinear Elasticity

### Continuum Mechanics.

Sep 29, Wed, Week 5.

Constitutive law.

$$\underline{\sigma} = \underline{\Psi}(\underline{F}(t'), -\infty < t' \leq t).$$

$$\underline{\sigma}(t)$$

Follow the whole deformation history.

how to obtain the function  $\rightarrow Q$ .

▽ Hyperelasticity (Green's elasticity).

Elasticity  $\underline{\sigma}$  depends only on  $\underline{F}(t)$ .

$$\underline{\sigma} = \underline{\Psi}(\underline{F}(t)).$$

↳ response function.

Mathematically,  $\rightarrow$  the strain energy density.

$$\underline{P} = \frac{\partial w(\underline{F})}{\partial \underline{F}} \quad \text{energy per unit volume}$$


\*  $\uparrow$   
the definition of hyperelastic materials.

$$P_{ij} = \frac{\partial w}{\partial F_{ij}}.$$

$$dw = \frac{\partial w}{\partial F_{ij}} df_{ij} = \frac{\partial w}{\partial F} : dF$$

$$= P_{ij} df_{ij} = P : dF \quad \text{work}$$

$$d\phi = -\underline{t} \cdot d\underline{x} \quad \text{potential}$$



external work rate

$$= \int_{\partial\Omega_t} (\underline{\Omega} \cdot \underline{n}) \cdot \underline{v} ds + \int_{\Omega_t} \rho \underline{b} \cdot \underline{v} dV_t$$

in the reference configuration:

$$\begin{aligned} (\text{Polar stress}) \int_{\partial\Omega_0} (\underline{P} \cdot \underline{N}) \cdot \underline{V} &= dS_0 + \int_{\Omega_0} \rho_0 b_0 \cdot \underline{V} dV_0 \end{aligned}$$

$$\int_{\partial\Omega_0} (\underline{P} \cdot \underline{N}) dS_0 = \int_{\Omega_0} P_{ij} N_j V_i dS_0$$

div. Theo.

$$= \int_{\partial\Omega_0} (P_{ij} V_i)_{,j} dV_0 \quad ij = \frac{\partial}{\partial x_j}$$

$$= \int_{\partial\Omega_0} P_{ij,j} V_i dV_0 + \int_{\Omega_0} P_{ij} V_{i,j} dV_0$$

$$P_{ij,j} = -\rho_0 B + \rho_0 A_i$$

$$\bar{EWR} = \int_{\Omega_0} \rho_0 A \cdot \underline{V} dV_0 + \int_{\Omega_0} P_{ij} V_{i,j} dV_0$$

$$F_{ij} = \delta_{ij} + u_{i,j}$$

$$\int_{\Omega_0} P_{ij} F_{ij} dV_0$$

$$V_{i,j} = \frac{\partial u_i}{\partial x_j} \left[ \frac{\partial u_i}{\partial t} \Big|_{x_i} \right]$$

$$= \frac{\partial F_{ij}}{\partial t} \Big|_{\underline{x}}$$

$$\frac{Df_{ij}}{Dt} = \dot{f}_{ij}$$

move the body  
 kinetic energy, (KE).

$$= \frac{1}{2} \frac{D}{Dt} \left( \int_{\Omega_0} P_0 (\underline{V} \cdot \dot{\underline{V}}) dV_0 \right)$$

in the reference configuration

$$+ \int_{\Omega_0} \underline{P} : \dot{\underline{F}} dV_0$$

(completely general)  
 ↓ work rate

deform the body.

there could be dissipation in the process.

$$\frac{\partial w}{\partial f_i} = \underline{P}$$

★ hyperelastic

$$\text{assume } P_{ij} = \frac{\partial w}{\partial f_{ij}} \quad \frac{D}{Dt} \int_{\Omega_0} w(E) dV_0$$

$$dW = \frac{\partial w}{\partial f_{ij}} df_{ij}$$

~~$$(dW) = \frac{\partial w}{\partial f_{ij}} df_{ij}$$~~

$$\frac{Dw}{Dt} = \frac{\partial w}{\partial f_{ij}} \frac{Df_{ij}}{Dt} \rightarrow \dot{f}_{ij}$$

$\checkmark P_{ij}$

$t_1 \rightarrow t_2$ , have to integrate the rate to time.

Total work from  $t_1 \rightarrow t_2$

$$\int_{t_1}^{t_2} EWP dt = \int_{t_1}^{t_2} \frac{D}{Dt} \int_{\Omega_0} P(\underline{V}) dV_0 dt$$

$$+ \int_{t_1}^{t_2} \frac{D}{Dt} \left( \int_{\Omega_0} w(E) dV_0 \right) dt$$

$$t_1: \underline{E}_1 \underline{V}_1$$

$$t_2: \begin{matrix} \underline{E}_2 & \underline{V}_2 \\ \downarrow & \downarrow \\ \underline{F}_2 & \underline{V}_2 \end{matrix} \quad \int_{\Omega_0} w(\underline{F}_2) dV_0$$

$$- \int_{\Omega_0} w(\underline{F}_1) dV_0 = 0$$

Motivation for Hyper elasticity

→ No energy loss during loading

## Objectivity

$$\underline{W}(\underline{\underline{F}}) = \underline{W}(\underline{\underline{Q}}\underline{\underline{F}})$$



rigid body rotation.

$$\underline{\underline{Q}} = \begin{matrix} \text{rotation} \\ \uparrow \\ \text{(any)} \end{matrix}$$

$$\underline{\underline{F}} = \underline{\underline{Q}} \underline{\underline{B}} \underline{\underline{U}}$$

only depends  
on stretch  
tensor


$$W(\underline{\underline{F}}) = W(\underline{\underline{B}}^T \underline{\underline{F}} \underline{\underline{U}}) = \underline{W}(\underline{\underline{U}}).$$

★ only the stretching parts make a diff.


$$= \hat{W}(\underline{\underline{C}}). (\because \underline{\underline{U}}^2 = \underline{\underline{C}}).$$

$$\underline{\underline{P}} = \underline{\underline{P}}_{ij} \Rightarrow \frac{\partial W}{\partial F_{ij}} = \frac{\partial \hat{W}}{\partial C_{ijkl}} \frac{\partial C_{kl}}{\partial F_{ij}}$$

$$\Rightarrow 2 \underline{\underline{f}} \frac{\partial \hat{W}}{\partial C_{ij}} (\text{tr} \underline{\underline{P}})$$



not isotropic.



$$W(\underline{\underline{F}}) = W(\underline{\underline{F}} \underline{\underline{Q}})$$

~~only for isotropic~~

isotropic: true for all  $\underline{\underline{Q}}$

depends on the symmetry of the materials.

Oct. 5, Mon, Week 6.

$$\underline{x} = \underline{\underline{x}} + \underline{u}(\underline{x}, t)$$

$$\underline{\underline{x}} = \underline{x}^{-1}(\underline{x}, t).$$

$$\underline{u}(\underline{x}^{-1}(\underline{x}, t)) = \underline{a}(\underline{x}, t).$$

$$\underline{x} - \underline{\underline{x}} = \underline{y} \quad \frac{\partial u_i}{\partial \underline{x}_j} = \frac{\partial u_i}{\partial x_k} \cdot \frac{\partial x_k}{\partial \underline{x}_j}$$

$$\frac{\partial u_i}{\partial \underline{x}_j} = \frac{\partial u_i}{\partial x_k} \cdot \frac{\partial x_k}{\partial \underline{x}_j}.$$

$$\underline{x} - \underline{\underline{x}} = \underline{y}.$$

$$\underline{\underline{x}} - \underline{d}\underline{x} = \underline{y}$$

$$\det(\underline{\underline{I}} + \underline{d}\underline{\underline{B}}) = \underline{\underline{I}} + \frac{1}{R} (\underline{d}\underline{\underline{B}}) + O(\underline{d}\underline{\underline{B}})^2$$

$$\begin{aligned} d(\det \underline{\underline{A}}) &= \det \underline{\underline{A}} \cdot \left( 1 + \frac{\text{tr}(\underline{\underline{A}}^{-1} \underline{d}\underline{\underline{A}})}{\det \underline{\underline{A}}} \right) - \det \underline{\underline{A}} \\ &= (\det \underline{\underline{A}}) \text{tr}(\underline{\underline{A}}^{-1} \underline{d}\underline{\underline{A}}). \end{aligned}$$

$$= (\det \underline{\underline{A}}) (\underline{\underline{A}}^{-T} : \underline{d}\underline{\underline{A}})$$

$$= \frac{\partial \det \underline{\underline{A}}}{\partial \underline{\underline{A}}} : \underline{d}\underline{\underline{A}}.$$

↪ hold true for all  $\underline{\underline{A}}$ .

$$\Rightarrow \frac{\partial \det \underline{\underline{A}}}{\partial \underline{\underline{A}}} = (\det \underline{\underline{A}}) \underline{\underline{A}}^{-T}.$$

$$\frac{\partial (\det \underline{\underline{A}})}{\partial A_{ij}} = (\det \underline{\underline{A}}) A_{jk}^{-1}.$$

$$\begin{aligned} \hookrightarrow P &= \frac{\partial W}{\partial F} = \frac{\partial \hat{W}}{\partial C} = \frac{\partial \hat{F}}{\partial C} \left[ \frac{\partial \Phi}{\partial I_1} \frac{\partial I_1}{\partial C} + \frac{\partial \Phi}{\partial I_2} \frac{\partial I_2}{\partial C} \right. \\ &\quad \left. + \frac{\partial \Phi}{\partial I_3} \frac{\partial I_3}{\partial C} \right] \end{aligned}$$

1st Piola stress.

$$\underline{\underline{P}} = 2 \left[ \left( \frac{\partial \Phi}{\partial I_1} + I_1 \frac{\partial \Phi}{\partial I_2} \right) \underline{\underline{F}} + \frac{\partial \Phi}{\partial I_2} \underline{\underline{F}}^T + I_3 \frac{\partial \Phi}{\partial I_3} \underline{\underline{F}}^{-T} \right]$$

$$\begin{aligned} \underline{\underline{F}}^T \underline{\underline{C}}^{-T} &= \underline{\underline{F}} (\underline{\underline{F}}^T \underline{\underline{F}})^{-1} \\ &= \underline{\underline{F}} (\underline{\underline{F}}^{-1} \underline{\underline{F}}^T). \\ &= \underline{\underline{F}} \end{aligned}$$

Recall

$$\underline{\underline{\Sigma}} = \frac{1}{J} \underline{\underline{P}} \underline{\underline{F}}^T.$$

implies.

$$J = \det \underline{\underline{f}}$$

$$\begin{aligned} \hookrightarrow \frac{1}{J} \left[ \left( \frac{\partial \Phi}{\partial I_1} + I_1 \frac{\partial \Phi}{\partial I_2} \right) \underline{\underline{F}} \underline{\underline{F}}^T - \frac{\partial \Phi}{\partial I_2} (\underline{\underline{F}} \underline{\underline{F}}^T)^T \right. \\ \left. + I_3 \frac{\partial \Phi}{\partial I_3} \underline{\underline{I}} \right] = \underline{\underline{\Sigma}}. \end{aligned}$$

Tension Test.

$$\underline{\underline{F}} \rightarrow \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \lambda_1 & 0 \\ 0 & 0 & \lambda_2 \end{bmatrix}$$

$$\underline{\underline{F}} = \lambda_1 e_1 e_1 + \lambda_2 e_2 e_2 + \lambda_3 e_3 e_3$$

$$\begin{aligned} \text{if } \underline{\underline{F}}^T \underline{\underline{F}} &\Rightarrow \int \pi^3 = 0 \\ \text{if } \underline{\underline{F}} &\Rightarrow \begin{pmatrix} 0 & \lambda_1^2 & 0 \\ 0 & 0 & \lambda_2^2 \\ 0 & 0 & \lambda_3^2 \end{pmatrix} \end{aligned}$$

$$\text{tr}(\underline{\underline{C}}) = \lambda_1^2 + \lambda_2^2 + \lambda_3^2.$$

$$\lambda_1 = \lambda_2 = \lambda.$$

$$\Rightarrow \det \underline{\underline{C}} = \lambda^4 \lambda_3^2.$$


$$\underline{\underline{P}} = \underline{\underline{\Sigma}} / \lambda.$$

$$P_{33} = \frac{\sigma_{33}}{\lambda}. \quad \sigma_{ij} = 0, \quad j, i \neq 3.$$

$$\lambda \rightarrow I_n, I_1, I_3$$

loading  $\rightarrow \lambda \rightarrow$  curve.

fit:  $\checkmark$   
constitutive modeling



$$\lambda_c = 1 - \alpha \frac{\Delta L}{L_0}$$

strain ener. dens.  
function.

$$\det \underline{\underline{F}}$$

$$\underline{\underline{\sigma}} = C_1 (I_1 - 3 - 2 \log(J)) + C_2 (\ln J)^2$$

( $C_1, C_2$  are material constants.)


common model

locally linear model.

$$\underline{\underline{\sigma}} \rightarrow \underline{\underline{\bar{\epsilon}}}$$

Simple tensile & simple shear

determine different parameters.



Temperature is ~~more~~ important

↳ entropy.

Incompressible.

$$\frac{dV}{dV_0} = \frac{J}{\det \underline{\underline{F}}} - 1$$

Isootropic deformation.

Define new energy function.

$$W_{\text{new}} = W(\underline{\underline{F}}) - P(J-1)$$

Lagrangian multiplier.

(impose constraints)

$$P = \frac{\partial W_{\text{new}}}{\partial \underline{\underline{F}}} = \frac{\partial W}{\partial \underline{\underline{F}}} - P \cdot \frac{\partial \det(\underline{\underline{F}})}{\partial \underline{\underline{F}}}$$

$$= \frac{\partial W}{\partial \underline{\underline{F}}} - P(\det \underline{\underline{F}}) \underline{\underline{F}}^{-T}$$

$$J=1$$

$$\underline{\underline{\sigma}} = P \underline{\underline{F}}^T$$

$$\underline{\underline{\sigma}} = \frac{\partial W}{\partial \underline{\underline{F}}} \underline{\underline{F}}^T - P \underline{\underline{I}}$$

model.

$$I_3 = \det \underline{\underline{C}} = \det(\underline{\underline{F}}^T \underline{\underline{F}}) = \det(\underline{\underline{F}}^T) \det \underline{\underline{F}} = 1$$

Isotropic incompressible solid.

$$W = \Phi(I_1, I_2)$$

$$\Sigma = \left[ \left( \frac{\partial \Phi}{\partial I_1} + I_2 \frac{\partial \Phi}{\partial I_2} \right) b - \frac{\partial \Phi}{\partial I_2} b^2 \right] - P_I$$

Corrected Note: (Based on Wiley books).

Review.

$$\text{Hyperelasticity} \rightarrow P = \frac{\partial W(E)}{\partial F}$$

$\rightarrow$  gradient of strain energy density with respect to  $F$ .

$\rightarrow$  end exactly where it starts.

$$\text{Objectivity} \sim W(F) = \hat{W}(C) \neq \bar{W}(E),$$

$$C = F^T F$$

$$\text{Isotropic Material} \sim W(E) = W(FQ).$$

$\forall$  orthogonal tensor  $Q$

$$\text{Define } \tilde{F} = FQ \sim \text{if isotropic.}$$

$$W(\tilde{F}) = W(F) \quad \forall Q.$$

$$\text{Objectivity} \sim W(\tilde{F}) = \hat{W}(C) = W(\tilde{F}^T \tilde{F}).$$

$$= \hat{W}(FQ)^T (FQ) = \hat{W}(Q^T C Q).$$

$\hat{W}$  is a scalar invariant of Tensor  $C$ .

$$\det[C - \lambda I] = (-\lambda)^3 + I_1 \lambda^2 - I_2 \lambda + I_3,$$

independent of  $Q$ .

$$\rightarrow \begin{cases} I_1 = \text{tr } C \\ I_2 = \frac{1}{2} [(\text{tr } C)^2 - \text{tr } C^2] \\ I_3 = \det C \end{cases}$$

$\rightarrow$  for isotropic material.

$$\hat{W} = \Phi(I_1, I_2, I_3).$$

isotropic.

$$\rightarrow P = \frac{\partial W}{\partial F} = \frac{\partial F}{\partial C} \frac{\partial \hat{W}}{\partial C}$$

$$= 2F \left[ \frac{\partial \Phi}{\partial I_1} \left( \frac{\partial I_1}{\partial C} \right) + \frac{\partial \Phi}{\partial I_2} \left( \frac{\partial I_2}{\partial C} \right) + \frac{\partial \Phi}{\partial I_3} \left( \frac{\partial I_3}{\partial C} \right) \right]$$

$$\stackrel{I}{=} \stackrel{I_1, I_2, I_3}{I_1 I_2 I_3 - C} \stackrel{C^{-1}}{C = I_3 C^{-1}}$$

$$I_3 = \det C.$$

most general: how to find  $\frac{\partial \det A}{\partial A}$ .

$$d(\det \underline{A}) = \frac{\partial \det \underline{A}}{\partial A} : d\underline{A}$$

$$= \frac{\partial (\det \underline{A})}{\partial A_{ij}} dA_{ij}.$$

$$d(\det \underline{A}) = \det(\underline{A} + d\underline{A}) - \det(\underline{A})$$

$$= \det(\underline{A} (I + \underline{A}^{-1} d\underline{A}) - \det \underline{A}$$

$d\underline{B}$

$$J = 1 \sim \underline{\underline{\Omega}} = \underline{\underline{P}} \underline{\underline{F}}^T = \frac{\partial W}{\partial \underline{\underline{F}}} \underline{\underline{F}}^T - \rho \underline{\underline{I}}$$

$$d(\det(\underline{\underline{dF}})) = \det \underline{\underline{A}} (1 + \text{tr}(\underline{\underline{A}}^{-1} d\underline{\underline{A}})) - \det \underline{\underline{A}}$$

$$= (\det \underline{\underline{A}}) \text{tr}(\underline{\underline{A}}^{-1} d\underline{\underline{A}})$$

$$= (\det \underline{\underline{A}}) (\underline{\underline{A}}^{-1} : d\underline{\underline{A}})$$

$$= \frac{\partial \det \underline{\underline{A}}}{\partial \underline{\underline{A}}} : d\underline{\underline{A}}$$

$$\rightarrow \frac{\partial \det \underline{\underline{A}}}{\partial \underline{\underline{A}}} = (\det \underline{\underline{A}}) \underline{\underline{A}}^{-T}$$

$$\dots + \frac{\partial \Phi}{\partial I_3} \frac{\partial I_3}{\partial \underline{\underline{C}}} \rightarrow I_3 \underline{\underline{C}}^{-T} = I_3 \underline{\underline{C}}^{-1}$$

$$I_3 = \det \underline{\underline{C}}$$

$$\underline{\underline{P}} = 2 \left[ \left( \frac{\partial \Phi}{\partial I_2} + I_1 \frac{\partial \Phi}{\partial I_2} \right) \underline{\underline{F}} - \frac{\partial \Phi}{\partial I_2} \underline{\underline{F}} \underline{\underline{C}}^{-T} + \left( \frac{\partial \Phi}{\partial I_3} \underline{\underline{F}}^{-T} \right) \right]$$

$$\underline{\underline{\Omega}} = \frac{1}{J} \underline{\underline{P}} \underline{\underline{F}}^T \rightarrow \text{true stress.}$$

Tension Test

For isotropic.

$$\underline{\underline{\Omega}} = 2 \left[ \left( \frac{\partial \Phi}{\partial I_1} + I_1 \frac{\partial \Phi}{\partial I_2} \right) \underline{\underline{b}} - \frac{\partial \Phi}{\partial I_2} \underline{\underline{b}}^T \right] - \rho \underline{\underline{I}}$$

Oct 7. Wed, Week 6.  
Incompressible hyperelasticity.

- Kinematics — quantities deformation.

$\underline{\underline{C}}$ ,  $\underline{\underline{\epsilon}}$ ,  $\underline{\underline{U}}$  strain measures.

- Balance laws. — stresses.

$\underline{\underline{P}}$ ,  $\underline{\underline{\Omega}}$ , ... other stresses.  
measures.

e.g. 2nd Piola stress.

Biot stress.

- Constitutive Model.

Relationship Stress - strain.


$$\underline{\underline{P}} = -\underline{\underline{P}} \underline{\underline{F}}^{-T} + 2 \left[ \left( \frac{\partial \Phi}{\partial I_1} + I_1 \frac{\partial \Phi}{\partial I_2} \right) \underline{\underline{F}} - \frac{\partial \Phi}{\partial I_2} \underline{\underline{F}} \underline{\underline{C}}^{-T} \right]$$

Recall  $I_1$ ,  $I_2$  are invariants of  $\underline{\underline{C}}$ .  $\frac{\partial \Phi}{\partial I_2} \underline{\underline{F}} \underline{\underline{C}}^{-T}$

$$I_1 = \text{tr} \underline{\underline{C}}, \quad I_2 = \frac{1}{2} \left[ (\text{tr} \underline{\underline{C}})^2 - \text{tr}(\underline{\underline{C}}^2) \right]. \quad (1)$$

Lagrange multiplier enforce  $\det \underline{\underline{F}} = J = 1$ .

E.g. Uniaxial Tension or Compression test.



$L_0 \gg W_0$  and  $to.$ , Tension test.

$\underline{P} \cdot \underline{N}$  on all lateral surface is 0.

Ref. config.  $\underline{N} = \underline{e}_2$  on  $e_3$ .

Undeformed lateral surfaces  $\leftarrow \boxed{P_{13} = P_{23} = P_{33} = 0, P_{12} = P_{22} = P_{32} = 0}$

$\nabla_{\underline{x}} \cdot \underline{P} = 0$ .  $\leftrightarrow$  Balance law.

Simples model:  $\Phi = \frac{\mu}{2} (I_1 - 3)$

Ideal rubber  $\rightarrow$  Neo-Hookean solid.  
 $\Rightarrow = \frac{\mu}{2} (\lambda_1^2 + \lambda_2^2 + \lambda_3^2 - 3)$

Principal coordinate.

Principal stretches.

Eqn (1):  $\rightarrow$

$$\underline{\underline{P}} = -\underline{P}\underline{F}^{-T} + \mu\underline{F} \quad \leftarrow \text{Material model. (constitutive).}$$



$$u_1 = (\lambda_1 - 1)X_1$$

$$u_2 = u_3 = (\lambda_2 - 1)X_2$$

$$\lambda_2 = \lambda_3$$

$$\rightarrow (\lambda_2 - 1)\lambda_3$$

$$\underline{\underline{F}} = \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \lambda_2 & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix}$$

$$\det \underline{\underline{F}} = 1 \quad \lambda_1 \lambda_2 \lambda_3 = 1 \rightarrow \lambda_2 = \frac{1}{\sqrt{\lambda_1 \lambda_3}}$$

incompressibility.

Subs. into constitutive model.

make sure you satisfy boundary conditions.

\* Not satisfy balance law  $\rightarrow$  Nonequilibrium states.

$$[\underline{\underline{F}}] = \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \frac{1}{\sqrt{\lambda_1}} & 0 \\ 0 & 0 & \frac{1}{\sqrt{\lambda_1}} \end{bmatrix} \quad \left| \begin{array}{l} P_{11} = -P/\lambda_1 + \cancel{\mu/\lambda_2} \cancel{\mu/\lambda_3} \\ P_{22} = -P\sqrt{\lambda_1} + \cancel{\mu/\sqrt{\lambda_1}} \\ = P_{33} \end{array} \right.$$

$$[\underline{\underline{F}}^{-T}] = \begin{bmatrix} \frac{1}{\lambda_1} & 0 & 0 \\ 0 & \sqrt{\lambda_1} & 0 \\ 0 & 0 & \sqrt{\lambda_1} \end{bmatrix} \quad \left| \begin{array}{l} P_{12} = P_{21} = P_{23} = P_{32} \\ = P_{13} \cancel{+} P_{31} = 0 \end{array} \right.$$

$\lambda_1 = \text{const.} \rightarrow$  equilibrium equation automatically satisfied.

B.C. are automatically satisfied.

Now, determine  $P$ .

$$B.C. = P_{22} = P_{33} = 0 \Rightarrow P\sqrt{\lambda_1} = \mu\sqrt{\lambda_1}$$

$$\Rightarrow P = \frac{\mu}{\lambda_1}$$


Substitute back to  $P_{11}$ .

$$P_{11} = -\frac{\mu}{\lambda_1^2} + \mu\lambda_1$$

$$\underline{\underline{G}} = \underline{\underline{P}} \underline{\underline{F}}^T$$

$$\underline{\underline{\sigma}}_{11} = P_{11}\lambda_1$$

$$\underline{\underline{\sigma}}_{11} = -\frac{\mu}{\lambda_1} + \mu\lambda_1^2$$



$$\lambda_1 \approx 1 + \varepsilon. \quad \underline{\underline{\sigma}}_{11} = -\frac{\mu}{1+\varepsilon} + \mu(1+\varepsilon)^2$$

$$\approx -\mu(1-\varepsilon) + \mu(1+2\varepsilon) = 3\mu\varepsilon$$

$$\varepsilon \ll 1$$

$$\mu = E/3$$


$$\frac{E}{2(1+\nu)} = \mu$$

$$\nu = \frac{1}{2}$$

Poisson ratio.

plane stress deformation

(Surface traction free).



$$B.C.: \underline{\underline{P}} \cdot \underline{\underline{e}}_3 = 0, \text{ on surface}$$

$$u_1(x_1, x_2), u_2(x_1, x_2)$$

$$u_3(x_1, x_2)$$

(Assumption).

$P_{13} = P_{23} = P_{33} = 0$ , in the region (everywhere).

Plane stress assumption.

$$\underline{\underline{F}} = \begin{bmatrix} 1 + \frac{\partial u_1}{\partial x_1}, & \frac{\partial u_1}{\partial x_2}, & 0 \\ \frac{\partial u_2}{\partial x_1}, & 1 + \frac{\partial u_2}{\partial x_2}, & 0 \\ 0, & 0, & \frac{\partial u_3}{\partial x_3} \end{bmatrix}$$

$$\frac{\partial u_3}{\partial x_1}, \quad \frac{\partial u_3}{\partial x_2}, \quad \frac{\partial u_3}{\partial x_3}$$

$$\lambda_3 \rightarrow \lambda_3(x_1, x_2)$$

$$1 + \frac{\partial u_3}{\partial x_3}$$

Oct, 13, 2021. Wed.

$$\underline{\underline{P}} = -\underline{\underline{P}} \underline{\underline{F}}^{-T} + \mu \underline{\underline{F}}$$

$$[\underline{\underline{P}}] = -P \begin{bmatrix} 1 + \frac{\partial u_2}{\partial x_3} & -\frac{\partial u_2}{\partial x_1} & 0 \\ -\frac{\partial u_1}{\partial x_2} & 1 + \frac{\partial u_1}{\partial x_3} & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix}$$

$\underbrace{[\underline{\underline{F}}^{-T}]}$

$$+ \mu \begin{bmatrix} 1 + \frac{\partial u}{\partial x_1} & 0 & 0 \\ 0 & \ddots & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix} \underline{\underline{\Phi}} = \frac{\mu}{2} (I_1 - 3)$$

$$P_{33} = -\frac{P}{\lambda_3(\lambda_1, \lambda_2)} + \mu \lambda_3 (\lambda_1, \lambda_2) = 0$$

equilibrium

$$\left\{ \begin{array}{l} \frac{\partial P_{11}}{\partial x_1} + \frac{\partial P_{12}}{\partial x_2} + \frac{\partial P_{13}}{\partial x_3} = 0 \\ \frac{\partial P_{21}}{\partial x_1} + \frac{\partial P_{22}}{\partial x_2} = 0. \end{array} \right.$$

$$P_{11} = \mu \lambda_3^3 \cdot \left( 1 + \frac{\partial u_2}{\partial x_3} \right) + \mu \left( 1 + \frac{\partial u}{\partial x_1} \right).$$

Review: plane stress: incompressible neo-Hookean Solid

$\underline{\underline{F}}$  for plane stress.

$$[\underline{\underline{E}}] = \begin{bmatrix} x_{1,1} & x_{1,2} & 0 \\ x_{2,1} & x_{2,2} & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix} \quad , \alpha = \frac{\partial}{\partial x_x}$$

$$x_\alpha = X_\alpha + U_\alpha (X_1, X_2) \quad \alpha = 1, 2$$

$\lambda_3$  is independent of  $X_3$ .

$\lambda_3$  is the out-of-plane stretch ratio,  
 $\lambda_3(X_1, X_2)$ .

$$\underline{\underline{F}}_{in} = X_\alpha \beta \underline{\underline{e}}_\alpha \underline{\underline{e}}_\beta$$

neo-Hookean

$$\underline{\underline{P}} = -\underline{\underline{P}} \underline{\underline{F}}^{-T} + \mu \underline{\underline{F}}$$

for im incompressibility

$$J = \det \underline{\underline{F}} = 1 = (\det \underline{\underline{F}}_{in}) \lambda_3 = 1$$

$$\Rightarrow \det \underline{\underline{F}}_{in} = \frac{1}{\lambda_3}$$

$$(x_{1,1}x_{2,2} - x_{1,2}x_{2,1})$$

$$\begin{bmatrix} F^T \\ F \end{bmatrix} = \begin{bmatrix} x_{2,2}\lambda_3 & -x_{2,1}\lambda_3 & 0 \\ -x_{1,2}\lambda_3 & x_{1,1}\lambda_3 & 0 \\ 0 & 0 & 1/\lambda_3 \end{bmatrix}$$

(II) Next Step:

$$P_{11} = -P x_{2,2} \lambda_3 + \mu x_{1,1}.$$

$$P_{22} = -P \lambda_3 x_{2,1} + \mu x_{1,2}.$$

$$P_{12} = P \lambda_3 x_{1,2} + \mu x_{2,1}.$$

$$P_{21} = -P \lambda_3 x_{1,1} + \mu x_{2,2}.$$

$P_{13} = P_{23} = P_{31} = P_{32} = 0$ , consistent with the plane stress assumption.

$$\underline{P_{33} = 0} = -P \frac{1}{\lambda_3} + \mu \lambda_3 = 0.$$

$$\therefore P = \mu \lambda_3^2.$$

Substitute

use LMB: (ignore body forces).  
2 acceleration.

$$P_{11,1} + P_{12,2} = 0.$$

$$(4(P\lambda_3^2 x_{2,2}),_1 + \mu x_{1,11} + (\mu \lambda_3^3 x_{1,2})_{12}$$

$$+ \mu x_{1,22} = 0.$$


$$0 = P_{21,1} + P_{22,2} = (\mu \lambda_3^3 + x_{1,2})_{21} + \mu x_{2,11}$$

$$- (\mu \lambda_3^3 x_{1,1})_{12} + \mu x_{2,22} = 0.$$

$$\left. \begin{array}{l} \mu \nabla_x^2 x_1 + \mu ((\lambda_3^3 x_{1,2})_{12} - (\lambda_3^3 x_{2,2})_{11}) = 0 \\ \mu \nabla_x^2 x_2 + \mu [ \end{array] \right. = 0$$

$$\lambda_3 = \frac{1}{x_{1,1} x_{2,2} - x_{2,1} x_{1,2}}$$

coupled PDEs for unknowns  $x_1, x_2$ .



on lateral sides:

$$\sigma_1 = -\sigma_0, \quad P_{11} = P_{21} = 0$$

$$\sigma_1 = \sigma_0, \quad P_{11} = P_{21} = 0$$

on crack forces.  $-\sigma_0 \leq \sigma_1 \leq \sigma_0, \quad \tau_{12} = 0 \pm$


$$P_{12} = P_{22} = 0$$

### Plane strain

#### Assumption:

$$\left\{ \begin{array}{l} u_1 = u_1(\sigma_1, \sigma_2) \text{ imply } F = \begin{bmatrix} x_{1,1} & x_{1,2} & 0 \\ x_{2,1} & x_{2,2} & 0 \\ 0 & 0 & 1 \end{bmatrix} \\ u_2 = u_2(\sigma_1, \sigma_2) \\ u_3 = 0 \end{array} \right.$$

$$\det F = 1, \rightarrow \text{to determine } P$$



linear elasticity

kinematics

$$\underline{\epsilon} = \frac{u_{i,j} + u_{j,i}}{2}, \quad \epsilon_i = \frac{\partial}{\partial x_i}$$

one simple strain measure, only)

small strain tensor

$$\frac{\partial \sigma_{ij}}{\partial x_j} = -P_i \delta_{ij} \quad \text{Equilibrium}$$

All you need, is constitutive model.

large deformation  $\xrightarrow{\text{linearize}}$  constitutive model.

$$\frac{\partial W(\underline{\epsilon})}{\partial \underline{\epsilon}} = \underline{\Omega} \quad \text{Small for all in linear stage}$$

$$(\hat{w} = \bar{w} = w).$$

$$\underline{\Omega}_{ij} = K_{ijkl} \epsilon_{kl}$$

$$\underline{\Omega}_{ij} = K_{ijkl} \epsilon_{kl} \quad (\underline{\epsilon} \text{ expect})$$

independent of strain tensor

$$\underline{\Omega}_{ij} = \frac{\partial W}{\partial \epsilon_{ij}} \quad \text{quadratic function of strain}$$

$$(\text{try}) \quad W = \frac{1}{2} K_{ijkl} \epsilon_{ij} \epsilon_{kl}$$

$$\text{Ons} \quad \left( \frac{\partial W}{\partial \epsilon_{is}} = \frac{1}{2} K_{jkl} \delta_{ir} \delta_{js} \epsilon_{kl} + K_{ijkl} \epsilon_{ij} \right)$$

$\underbrace{K_{rskl}}_{\delta_{ir} \delta_{js}}$        $\underbrace{K_{jirs}}_{\delta_{kl}}$

$$\sigma_{is} = \frac{1}{2} [ K_{rskl} \epsilon_{rl} + K_{jirs} \epsilon_{ij} ]$$

$$\left( \frac{\partial \sigma_{is}}{\partial \epsilon_{kl}} = \frac{1}{2} [ K_{rskl} \epsilon_{kl} + K_{kirs} \epsilon_{kl} ] \right)$$

$$\sigma_{ij} = \frac{1}{2} [ K_{ijkl} \epsilon_{kl} + K_{klji} \epsilon_{kl} ]$$

$$\sigma_{ij} = \frac{1}{2} [ K_{ijkl} \epsilon_{kl} + K_{klji} \epsilon_{kl} ] \epsilon_{kl}$$

$\hat{K}$

$$K_{ijkl} = K_{klji} \quad \text{symmetric in } kl, ij$$

$\downarrow$  81 component.

Symmetry of  $\sigma_{ij} \Rightarrow K_{ijkl} = K_{klji}$

Symmetry of  $\epsilon_{kl} \Rightarrow K_{ijkl} = K_{ijlk}$ .

$$9 \times 9 \rightarrow 6 \times 6$$

$\downarrow$   
36 independent components

The existence of  $W$ .

$$\sigma_{ij} = \frac{\partial W}{\partial \epsilon_{ij}}$$

implies  $K_{ijkl} = K_{klji}$ .

$$\downarrow$$

21 ind. comp.

most common

model for elastic

Oct. 15, office hours.

$C_1, C_2$ ,  $\propto$  shear modulus  
Poisson's ratio.

letting  $\lambda \rightarrow 1$

at very small  $\rightarrow$  agrees with Hooke's law.

Plot the curve.

normalize the stress for shear modulus

other terms  $\propto$  ratio of  $C_1, C_2$

function only of the

Poisson's ratio

reasonable choice  $\nu = 0.45$

0.5 (incompressible).

a lot of curve with different

Poisson's ratio.

\* normalized shear modulus  $G$ .

Piola & Cauchy

normalized by

You can normal the stress by  $G$ .

$\lambda_1, \lambda_3$

$$\lambda_3^2 - 1 + \frac{C_2}{C_1} \ln(\lambda_1^2 \lambda_3) = 0$$

$$\lambda^2 - 1 + \left( \frac{C_2}{C_1} \right) \ln(\lambda^3 \lambda^2) = 0$$

$f(\lambda)$   $\downarrow$  incompressible  $\frac{C_2}{C_1} \rightarrow$  huge  
 $G$ .

$\lambda_3 \lambda^2 = 1$ .  $\leftarrow$  Lambert function

1st order expansion

John Hutchinson

$\rightarrow$

$$0.45 \lambda_3 + 0.45 = \lambda_1 - 1$$

$$1.45 - 0.45 \lambda_3 = \lambda_1 - 1$$

Oct. 18th, 2021, Mon.

Review.

Linear elasticity.

$$W = \frac{1}{2} k_{ijkl} \cdot \varepsilon_{ij} \varepsilon_{kl}$$

$$\sigma_{ij} = \frac{\partial W}{\partial \varepsilon_{ij}}$$

$k_{ijkl}$  has 21 independent constants.

$$k_{ijkl} = k_{jilm} = k_{ijlk} = k_{mlij}$$

Anisotropic

$$\sigma_{ij} = k_{ijkl} \varepsilon_{kl}$$

$$W = \frac{1}{2} \sigma_{ij} \varepsilon_{ij} = \frac{1}{2} \underline{\underline{\sigma}} \cdot \underline{\underline{\varepsilon}}$$

Isotropic solids.

$$k_{ijkl} = \lambda \delta_{ij} \delta_{kl} + \mu (\delta_{ik} \delta_{jl} + \delta_{il} \delta_{jk})$$

$\lambda, \mu$  are constants.

General form of isotropic 4<sup>th</sup> order Tensor

"Introduction to Cartesian Tensors"

Jim - ~~Notes~~  
Knowles

$$\begin{aligned}\sigma_{ij} &= \lambda \delta_{ij} \varepsilon_{kk} + \mu [\varepsilon_{ij} + \varepsilon_{ji}] \\ &= 2\mu \varepsilon_{ij} + \lambda \varepsilon_{kk} \delta_{ij}.\end{aligned}$$

Generalized Hooke's Law

$\mu, \lambda$  are called lame constants.

$$\sigma_{kk} = 2\mu \varepsilon_{kk} + 3\lambda \varepsilon_{kk}$$

$$\sigma_{kk} = (2\mu + 3\lambda) \varepsilon_{kk}$$

$$2\mu \varepsilon_{ij} + \lambda \frac{\sigma_{kk}}{(2\mu + 3\lambda)} \delta_{ij} = \sigma_{ij}$$

$$\varepsilon_{ij} = \frac{\sigma_{ij}}{2\mu} - \frac{\lambda}{(2\mu + 3\lambda)} \cdot \frac{1}{2\mu} \cdot \delta_{ij}$$

$$\varepsilon_{ij} = \frac{1+\mu}{E} \sigma_{ij} - \frac{2\lambda}{E} \delta_{ij}$$

$\nu$  - Poisson's ratio.

$E$  - Young's Modulus

$$\frac{1}{2\mu} = \frac{1+2\nu}{E} \Rightarrow \mu = \frac{E}{2(1+2\nu)}$$

$$\text{Shear Modulus. } \frac{2\nu}{E} = \frac{\lambda}{(2\mu + 3\lambda) 2\nu}$$

### Tension test

$$\sigma_{ii} = \sigma, \quad \sigma_{ij} = 0, \quad (i, j \neq 1).$$

$$\epsilon_{ii} = \frac{\sigma_{ii}}{E},$$

↳ tension modulus.

$$\epsilon_{ii} = \epsilon_{33} = -\frac{\nu}{E} \sigma_{11}.$$

$$\frac{\epsilon_{ii}}{\epsilon_{11}} = \nu,$$

Poisson's ratio  $\geq 0$ .

There are negative Poisson's ratio material  
but anisotropic.

Apply a pure hydrostatic tension.

$$\epsilon_{ij} \leftarrow \epsilon_{kk} = -\frac{(1+\nu)}{E} P \delta_{ij} + \frac{3\nu}{E} \sigma_{ij}.$$

if  $\sigma_{ij} = -P \delta_{ij}$ .

$$\epsilon_{ii} = \epsilon_{ii} = \epsilon_{33} = -\frac{(1+2\nu)}{E} P.$$

$$\text{Bulk Modulus} = -\frac{1}{K} P \rightarrow -P/K.$$

$$k = \frac{E}{1+2\nu} \cdot \frac{E}{1-2\nu}.$$

$$\nu \rightarrow \frac{1}{2}, \quad k \rightarrow \infty.$$

$\downarrow$   
 $\nu = 0$ : incompressible solid

$$\sigma_{ij} = 2\mu \epsilon_{ij} + \lambda \epsilon_{kk} \delta_{ij}.$$

~~$$\sigma_{ij} = 2\mu \epsilon_{ij} \rightarrow \sigma_{ij} = 2\mu \epsilon_{ij} - P \delta_{ij}.$$~~

~~ANNA~~. Office hour.

$$\lambda = \frac{EV}{(1+\nu)(1-2\nu)}$$

General form relation for linear elasticity

$$\begin{aligned} \textcircled{1} \quad \epsilon_{ij} &= \frac{u_{ij} + u_{ji}}{2} \\ \textcircled{2} \quad \sigma_{ij}, j &= -P B_i \\ \textcircled{3} \quad \sigma_{ij} &= 2\mu \epsilon_{ij} + \lambda \epsilon_{kk} \delta_{ij} \end{aligned}$$

- Substitute  $\textcircled{1}$  into  $\textcircled{3}$  to express strains in terms of displacements.


- Substitute stress into  $\textcircled{2}$  to obtain

$$G \nabla^2 u + (\lambda + G) \nabla(\nabla \cdot u) = -P B$$

↳ Navier's equation (3 PDEs)

Subject Navier's Eq. to BCs

Typical e.g.



On.

traction is prescribed.

mixed BCs.


Displacement prescribed.

$$\{ \sigma_{ij} n_j = T_i(\underline{x}), \underline{x} \in S_T \}$$


$$S_u: u_i = f_i(\underline{x}), \underline{x} \in S_u$$

$$\left[ 2\mu \left[ \frac{u_{i,j} + u_{j,i}}{2} \right] + \lambda u_{k,k} \delta_{ij} \right] n_j = T_i(\underline{x}).$$

fixed boundary



In linear elasticity.



Build up complex solutions from simple ones.

$$\sigma_{ij}, j = -P_0 B_i$$

Suppose we guess a solution for  $\sigma_{ij}$  that also satisfies the Boundary Conditions (BC) (traction BC).

$$\begin{array}{|c|} \hline \text{---} \\ \hline \end{array} \quad B = q \underline{\varepsilon}_3$$

If we guess:  $\sigma_{ij}^*$ .

compute displacement.

$$u_j^* = \frac{(1+\nu)}{E} \sigma_{ij}^* - \frac{\nu}{E} \sigma_{kk}^* \delta_{ij}$$

Integrate strain  $\underline{\epsilon}^*$  to get displacement field

There are three unknown disp.

$u_1, u_2, u_3 \rightarrow$  (position).

I guess  $\sigma_{ij}^* \rightarrow \epsilon_{ij}^*$

$$\epsilon_{ij}^* = \frac{u_{i,j} + u_{j,i}}{2}$$

6 equations here ↗

6 equations, & 3 unknowns.

The solutions may not exists, if e.  
not unique.

Plane strain.

↪ linear clas.

$$u_3=0, \epsilon_{11} = \frac{\partial u_1}{\partial x_1} = u_{1,1}$$

$$\epsilon_{22} = \frac{\partial u_2}{\partial x_2} = u_{2,2}$$

$$\epsilon_{12} = \frac{1}{2} \left( \frac{\partial u_1}{\partial x_2} + \frac{\partial u_2}{\partial x_1} \right) = \frac{u_{1,2} + u_{2,1}}{2}$$

$$\epsilon_{ij} \text{ (rest)} = 0$$

$u_3=0, u_1, u_2$  depends on  $x_1, x_2$  only.

You can show that

$$-\epsilon_{22,22} + \epsilon_{11,22} + \epsilon_{22,11} = 0$$

$$\frac{\partial^2 \sigma_{ij}}{\partial x_i \partial x_n} = (\epsilon_{ij})_{12}$$

↪ compatibility equation for plane strain.

: puts a constraint on the strain.

$$\gamma \epsilon_{ij} = \frac{\sigma_{ij} (1+\nu)}{E} - \frac{2 \nu \sigma_{kk} \delta_{ij}}{E}$$

↪ you will find this:

$$\nabla^2 (\sigma_u + \sigma_v) = \frac{1}{(1-\nu)} \nabla \cdot (\rho \mathbf{b}).$$

compatibility equation for stress.

Wed., Oct. 20, 2021. Week 9 (?)

### Linear Elasticity

$$\left. \begin{array}{l} 6 \text{ Eqs. } \varepsilon_{ij} = \frac{u_{ij} + u_{ji}}{2} \text{ - kinematics.} \\ 3 \text{ Eqs. } \nabla_j \cdot \underline{\sigma}_{ij} = -p_i B_i \text{ - Balance laws.} \end{array} \right\}$$

$$6 \text{ Eqs. } \varepsilon_{ij} = \frac{(1+\nu) \sigma_{ij}}{E} = \frac{2 \nu G_{\text{eq}} \gamma_{ij}}{E}$$

Constitutive model.

15 Eqs.

unknowns:  $\varepsilon_{ij}$ ,  $\gamma_{ij}$ ,  $u_i$ ,  $\sigma_{ij}$ . 15 unknowns.

Navier Eqs. (Displacement formulation).

$$G \nabla^2 \underline{u} + (\lambda + G) \nabla (\nabla \cdot \underline{u}) = -p \underline{B}$$

3 Eqs., & 3 unknowns.  $u_1, u_2, u_3$ .

Independent variables:  $\underline{x}_i$ .  
positions.

dependent is  $u_i$ .

Most useful when body is subject to BCs.

### Antiplane shear deformation.

$$u_\alpha \equiv 0, \alpha = 1, 2. \text{ No in-plane disp.}$$

$$u_3 = u(I_1, I_2), \text{ independent of } I_3.$$



$$\varepsilon_{\alpha\beta} = 0, \alpha = 1, 2.$$

$$\varepsilon_{33} = \frac{\partial u_3}{\partial I_3} = 0.$$

Only non-vanishing strain are.

engineering strain.  $\varepsilon_{13} = \varepsilon_{31} = \frac{1}{v} \frac{\partial u}{\partial I_1} = \frac{1}{v} \gamma_1$   
 $\varepsilon_{23} = \varepsilon_{32} = \frac{1}{v} \frac{\partial u}{\partial I_2} = \frac{1}{v} \gamma_2$

constitutive model.

$$\sigma_{\alpha\beta} = 0 \text{ in-plane stress}$$

$$\tau_{33} = 0$$

$$\left\{ \begin{array}{l} \tau_{13} = \tau_{31} = G \gamma_1 \\ \tau_{23} = \tau_{32} = G \gamma_2 \end{array} \right.$$

Equilibrium Eqs. are identically satisfied in  
1 & 2 directions ( $B_1 = B_2 = 0$ )

$$\frac{\partial \sigma_{31}}{\partial x_1} + \frac{\partial \sigma_{32}}{\partial x_2} = 0$$

↑

no body force.

$$\frac{\partial \tau_1}{\partial x_1} + \frac{\partial \tau_2}{\partial x_2} = 0 \quad (\Rightarrow) \quad \nabla_x \cdot \vec{\tau} = 0. \quad \textcircled{1}$$

$$\underline{\tau} = \tau_1 \underline{e}_1 + \tau_2 \underline{e}_2$$

$\gamma_1$  &  $\gamma_2$  must satisfy the fact that.

$$\gamma_1 = \frac{\partial w}{\partial x_1}, \quad \gamma_2 = \frac{\partial w}{\partial x_2} \Rightarrow \frac{\partial \gamma_1}{\partial x_2} = \frac{\partial \gamma_2}{\partial x_1}$$

Stress compatibility

the eqn. int.  $\frac{\partial \tau_1}{\partial x_2} = \frac{\partial \tau_2}{\partial x_1}. \quad \textcircled{2}$

Introduce a stress function  $\phi$ .

$$\tau_1 = -\frac{\partial \phi}{\partial x_2}, \quad \tau_2 = -\frac{\partial \phi}{\partial x_1}. \quad \textcircled{3}$$

Subs.  $\textcircled{2}$  into  $\textcircled{1}$  we see that  
↓  
 $\textcircled{3}$

$\textcircled{1}$  is satisfied automatically.

$$\frac{\partial \tau_1}{\partial x_1} = \frac{\partial^2 \phi}{\partial x_1 \partial x_2}, \quad \frac{\partial \tau_2}{\partial x_2} = \frac{\partial^2 \phi}{\partial x_2 \partial x_1}$$

Substitute  $\textcircled{3}$  into  $\textcircled{2}$ .

$$\frac{\partial^2 \phi}{\partial x_2} + \frac{\partial^2 \phi}{\partial x_1} = 0 \quad \text{or} \quad \nabla_x^2 \phi = 0.$$

3

Replace Eqn in  $\textcircled{2}$ .

Stress function approach

Disp. Formulation.  $\tau_1 = G \frac{\partial w}{\partial x_1}$ .

$$\tau_2 = G \frac{\partial w}{\partial x_2} \quad \nabla_x^2 w = 0.$$

Substitute into  $\textcircled{1}$ .

↑  
simpliest form of



Navier's equation.

$$\phi + i w = f(z).$$

✓

$$\phi + i Gw$$

\* Anti-plane shear.



Reminder: Plane strain

$$U_\alpha(\bar{x}_1, \bar{x}_2), \quad \alpha = 1, 2$$

$$U_3 = 0.$$

$\epsilon_{11}, \epsilon_{22}, \epsilon_{33}$  (all others strain components = 0).

Compatibility.

$$\frac{\partial^2 \epsilon_{11}}{\partial \bar{x}_2^2} - 2 \frac{\partial^2 \epsilon_{12}}{\partial \bar{x}_1 \partial \bar{x}_2} + \frac{\partial^2 \epsilon_{22}}{\partial \bar{x}_1^2} = 0$$

Note

$$\frac{\partial \sigma_{33}}{\partial \bar{x}_1} = 0, \quad \text{is automatically satisfied.}$$

$$\sigma_{31} = \sigma_{32} = 0, \quad \sigma_{33} \text{ is independent of } \bar{x}_3.$$

$$\epsilon_{33} = 0, \Rightarrow \frac{\sigma_{33}}{E} - \frac{\nu(\sigma_{11} + \sigma_{22})}{E} = 0$$

$$\boxed{\sigma_{33} = \nu(\sigma_{11} + \sigma_{22})}.$$

Equilibrium equation is identically satisfied

in 3 direction..

$$\text{Therefore: } \frac{\partial \sigma_{11}}{\partial \bar{x}_1} + \frac{\partial \sigma_{22}}{\partial \bar{x}_2} = \rho_0 B_1,$$

$$\frac{\partial \sigma_{11}}{\partial \bar{x}_1} + \frac{\partial \sigma_{22}}{\partial \bar{x}_2} = \rho_0 B_2$$

Equilibrium Eqs (LMB).

Assuming  $B = 0$ .

Airy stress function,  $\phi$ .

$$\sigma_{11} = \frac{\partial^2 \phi}{\partial \bar{x}_2^2} \quad \sigma_{12} = -\frac{\partial^2 \phi}{\partial \bar{x}_1 \partial \bar{x}_2}.$$

$$\sigma_{22} = \frac{\partial^2 \phi}{\partial \bar{x}_1^2}. \quad (5)$$

Substitute (5) into (4a, b).

$$\epsilon_{11} = \frac{\sigma_{11}}{E} - \frac{\nu(\sigma_{11} + \sigma_{22})}{E}$$

$$\epsilon_{22} = \frac{\sigma_{22}}{E} - \frac{\nu(\sigma_{11} + \sigma_{22})}{E} \quad \boxed{\sigma_{33} = \nu(\sigma_{11} + \sigma_{22})}$$

$$\epsilon_{12} = \frac{\sigma_{12}}{E} - \frac{\nu(\sigma_{11} + \sigma_{22})}{E} \quad \frac{\sigma_{12}}{E} \rightarrow T. \quad \boxed{1}$$

Simplified plane

$$\epsilon_{11} = \frac{1+\nu}{E} [(1-\nu)\sigma_{11} - \nu\sigma_{22}], \quad \text{strain constitutive model}$$


$$\gamma = \frac{T}{G} \quad \epsilon_{22} = \frac{(1+\nu)}{E} [(1-\nu)\sigma_{22} - \nu\sigma_{11}]$$

Non-zero Inplane stress fields are



$$\sigma_{11}, \sigma_{22}, \sigma_{12}$$

Non-zero Out-of-plane stress.

$$\sigma_{33} = \nu(\sigma_{11} + \sigma_{22})$$




\$S\_T\$: Traction Boundary Conditions,



Stresses \$\propto\$ stress function.

$$\left\{ \begin{array}{l} \sigma_{11} = \frac{\partial^2 \phi}{\partial x_1^2} \\ \sigma_{22} = \frac{\partial^2 \phi}{\partial x_2^2} \\ \sigma_{12} = -\frac{\partial^2 \phi}{\partial x_1 \partial x_2} \end{array} \right.$$

Plane stress (finite deformation).



\$t \ll L\$ and other in-plane dimensions.

$$\sigma_{13} = \sigma_{23} = \sigma_{33} = 0 \rightarrow \text{three non zero stresses } \downarrow \sigma_{11}, \sigma_{22}, \sigma_{12}$$

$$\varepsilon_{13} = \varepsilon_{23} = \varepsilon_{32} = \varepsilon_{31} \approx 0.$$

$\varepsilon_{xy}$  is approx. independent of  $x_3$ .

$$\frac{\nabla V}{V} = \varepsilon_{11} + \varepsilon_{22} + \varepsilon_{33} = 0$$

Incompressible.

Constitutive model

Plane stress.  $\sigma_{33} = 0$ .

$$\varepsilon_{11} = \frac{\sigma_{11}}{E} - \frac{\nu(\sigma_{22} + \sigma_{33})}{E} = \frac{\sigma_{11}}{E} - \frac{2\sigma_{22}}{E}$$

$$\varepsilon_{12} = \frac{\sigma_{21}}{2G}$$

~~$$\varepsilon_{22} = \frac{\sigma_{22}}{E} - \frac{\nu(\sigma_{11} + \sigma_{33})}{E} = \frac{\sigma_{22}}{E} - \frac{2\sigma_{11}}{E}$$~~

Plane strain

$$\varepsilon_{11} = \frac{\sigma_{11}}{E} - \frac{\nu(\sigma_{22} + \sigma_{33})}{E} \rightarrow \nu(\sigma_{11} + \sigma_{22})$$


$$= \frac{\sigma_{11}}{E} - \frac{\nu(\sigma_{11} + \nu(\sigma_{11} + \sigma_{22}))}{E}$$

$$= \frac{(1-\nu^2)\sigma_{11}}{E} - \frac{\nu(1+\nu)\sigma_{22}}{E}$$

Compatibility & equilibrium.

$$\nabla^4 \phi = 0. \quad (\text{No body force}).$$


v.  $\rightarrow \frac{v}{1-v}$   
 plane stress. plane strain.



$$\underline{\varepsilon} = \frac{\nabla u + (\nabla u)^T}{2}$$

$$\varepsilon_{ij} = \frac{u_{ij} + u_{ji}}{2}$$

$$u = u_r e_r + u_\theta e_\theta$$



$$\{ e_r = \cos \theta e_1 + \sin \theta e_2$$

$$e_\theta = -\sin \theta e_1 + \cos \theta e_2$$

$$(1 \sim -\frac{u_0}{r}) e_0 e_0$$

In Cartesian coordinates.

$$\nabla u = \frac{\partial u_i}{\partial x_j} e_i e_j$$

$$\nabla u = \frac{\partial u_i}{\partial x_j} e_i e_j$$

$$\vec{\nabla} u = \frac{\partial u_i}{\partial x_j} e_j e_i - (\nabla u)^T$$

$$\nabla = e_r \frac{\partial}{\partial r} + e_\theta \frac{\partial}{\partial \theta}$$

$$e_r \frac{\partial}{\partial r} + \frac{e_\theta}{r} \frac{\partial}{\partial \theta}$$

$$\nabla u = (e_r \frac{\partial}{\partial r} + \frac{e_\theta}{r} \frac{\partial}{\partial \theta})(u_r e_r + u_\theta e_\theta)$$

$$= e_r \cdot \frac{\partial(u_r e_r)}{\partial r} + e_r \cdot \frac{\partial(u_\theta e_\theta)}{\partial r}$$

$$= e_r \cdot \frac{\partial u_r}{\partial r} e_r + e_r \left( \frac{\partial u_\theta}{\partial r} e_\theta \right)$$

$$+ \frac{e_\theta}{r} \left[ \frac{\partial u_r}{\partial \theta} e_r + u_r \frac{\partial e_r}{\partial \theta} \right]$$

$$+ \frac{e_\theta}{r} \frac{\partial u_\theta}{\partial \theta} e_\theta + \frac{e_\theta}{r} u_\theta (e_r)$$

$$\frac{\partial e_\theta}{\partial \theta} = -\cos \theta e_1 - \sin \theta e_2 = -e_r$$

$$\nabla u = \frac{\partial u_r}{\partial r} e_r e_r + \frac{\partial u_\theta}{\partial r} e_\theta e_\theta + \frac{1}{r} \frac{\partial u_\theta}{\partial \theta} e_\theta e_r$$

$$+ \left[ \frac{u_r}{r} \cdot e_0 e_0 + \frac{1}{r} \cdot \frac{\partial u_\theta}{\partial \theta} \right] e_0 e_0$$

$$\varepsilon = \frac{\partial u_r}{\partial r} e_r e_r + \left[ \frac{u_0}{r} + \frac{1}{r} \cdot \frac{\partial u_\theta}{\partial \theta} \right] e_0 e_0$$

$$+ \frac{1}{r} \left[ \frac{\partial u_\theta}{\partial r} - \frac{1}{r} \frac{\partial u_\theta}{\partial \theta} - \frac{u_0}{r} \right] e_0 e_r + \frac{1}{r} [ ] e_{0r}$$

$e_{0r}$


$$\nabla u \text{ (Cartesian)} \quad \{e_1, e_2\}$$



$r_r, r_\theta, r_{00}$  polar coordinates.

$\{e_r, e_\theta\}$ .

Oct. 27, 2021. Wed



$\nabla^2 \phi = 0$  harmonic

$\nabla^4 \phi = 0$  biharmonic

$$u = u_r e_r + u_\theta e_\theta$$

$$e_r = \cos\theta e_1 + \sin\theta e_2$$

$$e_\theta = -\sin\theta e_1 + \cos\theta e_2.$$

$$\sigma = \sigma_{ij} e_i e_j = \sigma_{rr} e_r e_r + \dots$$

$\nabla \cdot \underline{\sigma} \rightarrow$  Easy in Cartesian Coordinate

Plane strain or plane stress

$$\left\{ \frac{\partial \sigma_{rr}}{\partial r} + \frac{1}{r} \cdot \frac{\partial \sigma_{\theta\theta}}{\partial \theta} + \frac{\sigma_{rr} - \sigma_{\theta\theta}}{r} = 0. \right.$$

Derive

$$\frac{1}{r} \cdot \frac{\partial \sigma_{\theta\theta}}{\partial \theta} + \frac{\partial \sigma_{rr}}{\partial r} + \frac{\partial \sigma_{\theta\theta}}{\partial r} = 0$$

THIS ONE!!!

Third eqn. automatically satisfied.

$$\sigma_{rr} = \frac{\phi_r}{r} + \frac{\phi_{,\theta\theta}}{r}$$


$$\phi_{,\theta\theta} = \phi_{,rr} \quad \sigma_{\theta\theta} = -(\phi_{,\theta}/r), r$$

$$\nabla^4 \phi = 0 = \left[ \frac{1}{r} \frac{\partial}{\partial r} \left( r \frac{\partial}{\partial r} \right) + \frac{1}{r^2} \frac{\partial^2}{\partial \theta^2} \right] \phi = 0$$


### Technique of solution

① Fourier transform.


[Strip or half space problem]



T T T T T T



② superposition. (simple idea x technique)



Sum of two solutions.

⇒ work for  
traction free. multiplex elasticity

③ separation of variables.

⇒ works for simple geometry.

Complex variable method

function theory.

(Antiplane shear).

$$\nabla^2 \phi = 0 \quad \text{and} \quad \nabla^2 w = 0.$$

$$\left. \begin{aligned} \phi_{,x} &= \sigma_{33}, \\ \phi_{,y} &= \tau_{32} \end{aligned} \right\} \phi$$

$$x = x_1, \quad y = x_2 \quad (\text{stress function}).$$

$$\sigma_{13} = G \frac{\partial w}{\partial x} = G w_{,x}$$

$$\tau_{23} = G \frac{\partial w}{\partial y} = G w_{,y}$$

①, ②,

$$\Rightarrow \phi_{,x} = G w_{,y}. \quad (3)$$

$$\phi_{,y} = -G w_{,x}$$

Define a complex function.

$$f(z) = \phi + iGw$$

$\uparrow$  real part of  $f$ .  $\curvearrowright$  imaginary part of  $f$

③ is a rotation between real part of  $f$  and its imaginary parts.

③ is called the Cauchy-Riemann Eqs.

$$h(z) = u + iv. \quad \curvearrowright \text{CR.}$$

$\left[ \begin{array}{l} u_{,x} = v_{,y} \\ u_{,y} = -v_{,x} \end{array} \right]$  Any function with Real & Imaginary parts that satisfies the CR Eqs is called an analytic function in a Domain  $D$ .

$$\left\{ \begin{array}{l} \phi_{,xx} = G w_{,xy} \\ \phi_{,xy} = -G w_{,xy} \end{array} \right.$$

$$\left\{ \begin{array}{l} \nabla^2 \phi = 0 \end{array} \right.$$

$\cos x \leftarrow$  replace  $x$  by  $z$ .  $= \cos z$ .

$$\frac{e^x + e^{-x}}{2} \quad \cos z = \frac{e^z + e^{-z}}{2}$$

$$e^z = e^{x+iy} = e^x e^{iy}$$

$$= e^x [\cos y + i \sin y]$$

$$(e^x \cos y + i e^x \sin y) + e^{-x} [\cos y - i \sin y] = e^x \cos y + i e^{-x} \sin y$$

$$= \frac{(e^x + e^{-x}) \cos y + i(e^x - e^{-x}) \sin y}{2}$$

$$= \underbrace{\cosh x \cos y}_{u} + i \underbrace{\sinh x \sin y}_{v} = \omega z.$$

$$\left\{ \begin{array}{l} u_{,x} = v_{,y} \\ u_{,y} = -v_{,x} \end{array} \right. \quad \checkmark \rightarrow \text{CR}$$

$$f(z) = \sum_{n=0}^{\infty} a_n (z - z_0)^n \rightarrow a_n = \frac{1}{n!} f^{(n)}(z_0)$$

$\curvearrowleft$  analytic solution.

$$= \frac{\partial f}{\partial z^n} \Big|_{z_0}$$

$$f(z) = \sum_{n=0}^{\infty} a_n n(z - z_0)^{n+1}$$

$$\phi'(z) = \phi_x + iG_w w_x.$$

$$= \frac{\phi_x}{i} + \frac{iG_w w_x}{i}$$

$$= -i\phi_y + G_w w_y$$

$$\phi = \operatorname{Re} [\bar{z}\phi(z) + \chi(z)]$$

Analytic

$$\bar{z} = x - iy.$$

take this methods.

displacements:

$$2G(u_1 + iu_2) = x\phi(z) - \bar{z}\phi'(z) - \psi(z)$$

$$\psi(z) = \chi'(z) = \frac{d\chi}{dz}.$$

$\chi = 3 - 4\nu$ . plane strain.

$$= \frac{3-\nu}{1+\nu} \text{ stress.}$$

$$\sigma_{11} + \sigma_{22} = 2[\phi'(z) + \bar{\phi}'(z)].$$


$$\tau_{12} + i\tau_{21} = \phi'(z) + \bar{\phi}'(z) + \bar{z}(\phi''(z) + \psi'(z)).$$

$$\frac{dz^n}{dz} = n z^{n-1}.$$

\* Any rule with different factors can be applied  
→ complex variable theory.

(doesn't depend on the hole size).

$\frac{\sigma_{11}^*}{\sigma_{\infty}} = \text{const. independent of } \sigma_{\infty}$



$$\sigma_{11}^* = \sigma_{\infty} f(\frac{x}{a}, \frac{y}{a})$$

$$= \sigma_{\infty} f(\frac{x}{a}, \frac{y}{a})$$

$$\frac{\sigma_{11}^*}{\sigma_{\infty}} = f(0, 1).$$

3

(infinite).  $\rightarrow w \gg a$ .

$$\underline{\underline{\sigma}} = \sigma_{11} = \sigma_{\infty}, \text{ as } |x| \rightarrow \infty$$

$$\text{I \& II. } \tau_{21} = 0, \text{ as } |x| \rightarrow \infty$$

$$\text{III \& IV: } \sigma_{12} = 0, \text{ as } |y| \rightarrow \infty$$

$$\sigma_{12} = 0, \text{ as } |y| \rightarrow \infty$$

BC on hole:  $\underline{\underline{\sigma}} \cdot \underline{n} = 0$  on hole.

$$\underline{n} = \underline{e}_r = \cos \theta \underline{e}_r + \sin \theta \underline{e}_\theta$$

$$\sigma_{11} n_\beta = 0 \rightarrow r = a = \sqrt{x^2 + y^2}.$$

$$\sigma_{11} \cos \theta + \sigma_{12} \sin \theta = 0.$$

$$\sigma_{21} \cos \theta + \sigma_{22} \sin \theta = 0$$

$|\theta| \leq \pi$ .

- linear problem

1:  $\frac{\sigma_{ij}}{\sigma_{\infty}}$  independent of  $G, z$ .

$\rightarrow \sigma_{12}$  proportional to  $\sigma_{\infty}$

Mon. Nov. 1st, Week 11

### Theory of Torsion


#### Semi-inverse Method

① Guess a form for the disp. field.

$\Downarrow$   
strain  
 $\Downarrow$   
stress  $\rightarrow$  satisfy equilibrium.

check the BCs are satisfied.

\* Cylinder with a uniform cross-section.



$u$  is the displacement field.

$$u_1 = -\alpha x_2 x_3 \quad u_2 = \alpha x_1 x_3 \quad u_3 = w(x_1, x_2)$$

$\alpha$ : a constant.

walking function.

To motivate this, look at a special case

$w=0$ , Bar is circular.

$$\underline{e}_1, \underline{u} = \underline{e}_1, \underline{e}_1 + u_3 \underline{e}_2 = u_n \underline{e}_n + u_\theta \underline{e}_\theta$$



$$u_r = e_1 \cos \theta + e_2 \sin \theta$$

$$u_\theta = -e_1 \sin \theta + e_2 \cos \theta$$

$$u_n = u \cdot \underline{e}_n \quad u_\theta = u \cdot \underline{e}_\theta$$


$$u_1 = -\alpha \sin \theta X_3 \quad u_2 = \alpha \cos \theta X_3$$

$$u_n = 0, \quad u_\theta = \alpha r X_3.$$



$$\text{on surface: } u_\theta = \alpha R X_3.$$

$$(r=R)$$



$$u_\theta = \alpha r L = r \theta_0$$

$$M = \theta \theta_0, \quad \alpha = \frac{\theta \theta_0}{L} \quad \text{the unit of trace per unit length}$$

Strain tensor in cylindrical coordinates

the strain due to  $\underline{e}_n = e_{00} = e_{10} = e_{20} = 0$


$$\underline{\epsilon}_{03} = \frac{1}{2} \alpha r \quad = \epsilon_{33} = 0$$

$$1? = R \theta_0 \quad ? = \frac{R \theta_0}{L} = Ra$$

$$\underline{\sigma}_{03} = \frac{G}{2} \alpha r \quad \text{is stress!}$$

only non-trivial stress component in polar coordinate

\* traction free BCs automatically satisfied



on surface of cylinder

$$\int \underline{\sigma}_{03} \cdot \underline{n} dA = M$$

(Recall the nullifying function of  $\mathbf{z}$ )

$$\epsilon_{11} = 0, \epsilon_{22} = 0, \epsilon_{33} = 0, \epsilon_{23} = 0,$$

$$\epsilon_{13} = \frac{1}{2} \left[ -\alpha x_2 + \frac{\partial w}{\partial x_1} \right]$$

$$\epsilon_{21} = \frac{1}{2} \left[ \alpha x_1 + \frac{\partial w}{\partial x_2} \right]$$

$$\Rightarrow \begin{cases} T_{\alpha\beta} = 0, \alpha=1,2 \\ T_{33} = \alpha \end{cases}$$

$$T_{33} = \alpha$$

$$T_{13} = G \left[ -\alpha x_2 + w_{,1} \right] \quad T_{23} = G \left[ \alpha x_1 + w_{,2} \right]$$

Enforce equilibrium,

Equilibrium in 1, 2 directions are satisfied

and vertically.  $\rightarrow$  No Body Force.

in 3 direction.

$w$  is harmonic.

Equilibrium is satisfied.

$$\frac{\partial T_{13}}{\partial x_1} + \frac{\partial T_{23}}{\partial x_2} = 0 \Rightarrow \text{Traction free BCs on the side of the Bar}$$

$$\frac{\partial^2 w}{\partial x_1^2} + \frac{\partial^2 w}{\partial x_2^2} = 0$$

in some sense, anti-plane shear.

$$\nabla^2 w = 0.$$

$$T_{ij} n_j = 0 \quad (\text{traction free}).$$

$$t = -\frac{dx_1}{ds} \epsilon_1 + \frac{dx_2}{ds} \epsilon_2 \quad \underline{n} \Rightarrow$$

$$n = \frac{dx_2}{ds} \epsilon_1 - \frac{dx_1}{ds} \epsilon_2$$

$$T_{ij} n_j = 0$$

$\Downarrow$

$$[T_{31} n_1 + T_{32} n_2 = 0] \quad (\text{BCs}).$$

$$[T_{31} \cdot \frac{dx_2}{ds} - T_{32} \frac{dx_1}{ds} = 0]$$

$$G \left[ -\alpha x_2 + w_{,1} \right] \frac{dx_2}{ds} - G \left[ \alpha x_1 + w_{,2} \right] \frac{dx_1}{ds} = 0.$$

(we can cancel the  $G$ ).

$$w_{,1} \frac{dx_2}{ds} - w_{,2} \frac{dx_1}{ds} = \alpha \left( x_1 \frac{dx_1}{ds} + x_2 \frac{dx_2}{ds} \right)$$

$$\text{grad: } \nabla w \cdot \underline{n} = \frac{\alpha}{v} \left[ \frac{d(x_1^2 + x_2^2)}{ds} \right]$$

traction free BCs  $\frac{dw}{dn}$ .

$$\frac{dw}{dn} = \frac{\alpha}{v} \frac{d(x_1^2 + x_2^2)}{ds} \rightarrow \text{BCs for Laplace}$$

$$\nabla^2 w = 0. \quad \text{Norman BCs.}$$

Guaranteed this \*

$$\int_C \frac{dw}{dn} ds = 0 \quad (\text{existence of solution}) \quad \text{condition to be satisfied}$$

automatically satisfied.  $\rightarrow \frac{dw}{dn}$ .

$$M = \alpha \left[ G \iint_A (x_1 x_2 + x_1 w_{,2} - x_2 w_{,1}) dx_1 dx_2 \right]$$

$k$ : torsional stiffness

$$M = k\alpha$$

$w$  is harmonic

$\phi$

$w$  is the real / Im part of an analytical function.

$$f(z) = w + i\phi \quad i = \sqrt{-1}$$

$$z = x_1 + ix_2$$

$w, \phi$  are related by CR eqns.

$$\begin{cases} w_{,1} = \phi_{,2} \\ w_{,2} = -\phi_{,1} \end{cases}$$

$$\Omega_{13} = G[-\alpha x_2 + w_{,1}] = G[-\alpha x_2 + \phi_{,2}]$$

$$\Omega_{23} = G[\alpha x_1 + w_{,2}] = G[\alpha x_1 - \phi_{,1}]$$

Note:  $w, \phi$ , is harmonic, so  $\phi$  also

satisfy  $\nabla^2 \phi = 0$ .

Check: Equilibrium eqn is automatically satisfied

$$\Omega_{13} n_1 + \Omega_{23} n_2 = 0 \Rightarrow \text{BCs},$$

$$\Omega_{13} \frac{dx_2}{ds} - \Omega_{23} \frac{dx_1}{ds} = 0.$$

Wed, Nov. 3rd, Week 12

REVIEW: Displacement.  $\rightarrow \nabla^2 w = 0$

$$\text{TRACTION FREE BCs: } \frac{dw}{dn} = x_2 n_1 - x_1 n_2$$

$$= x_2 \frac{dx_2}{ds} + x_1 \frac{dx_1}{ds} = \frac{1}{2} \frac{d(x_1^2 + x_2^2)}{ds}$$

$$\underline{\xi} = \frac{dx_1}{ds} e_1 + \frac{dx_2}{ds} e_2$$

$$\underline{n} = \frac{dx_2}{ds} e_1 - \frac{dx_1}{ds} e_2$$

$$\begin{cases} \Omega_{13} = \frac{G}{2} \alpha [-x_2 + w_{,1}] \\ \Omega_{23} = \frac{G}{2} \alpha [x_1 + w_{,2}] \end{cases}$$

$$\begin{cases} u_1 = -\alpha x_2 x_3 \\ u_2 = \alpha x_1 x_3 \\ u_3 = \alpha w(x_1, x_2) \end{cases}$$

A different approach.

$$f(z) = w + i\phi \quad \text{conjugate harmonic function to } w.$$

$$w_{,1} = \phi_{,2} \quad \& \quad w_{,2} = -\phi_{,1} \quad \Leftrightarrow$$

$$\nabla^2 \phi = 0$$

$$\Omega_{13} = \frac{G}{2} \alpha [-x_2 + \phi_{,2}], \quad \Omega_{23} = \frac{G}{2} \alpha [x_1 - \phi_{,1}]$$

$$\text{T.F. BCs} \quad \Omega_{13} n_1 + \Omega_{23} n_2 = 0 \Rightarrow [-x_2 + \phi_{,2}] n_1 + [x_1 - \phi_{,1}] n_2 = 0.$$

$$\underbrace{-x_2 \frac{dx_2}{ds} + x_1 (-\frac{dx_1}{ds})}_{\frac{d(x_1^2 - x_2^2)}{ds}} - \phi_{,1} n_2 + \phi_{,2} n_1 = 0.$$


$$\underbrace{\phi_{,1} t_1 + \phi_{,2} t_2}_{\nabla \phi \cdot \underline{t}} = \frac{\partial \phi}{\partial s}$$

$$\Rightarrow \frac{d\phi}{ds} = \frac{d(x_1^L + x_2^L)}{ds} \Rightarrow \phi = \frac{x_1^L + x_2^L}{L} + \text{const} \Rightarrow \text{Curve } C$$

Set const = 0.

$$\underline{\underline{BC}}: \left[ \begin{array}{l} \phi = \frac{x_1^L + x_2^L}{L} \quad \text{on } C \\ \nabla^2 \phi = 0 \end{array} \right]$$

Example



$$f(z) = w + i\phi.$$

$$f(z) = i(C^L) z^L \rightarrow z^L = x + iy$$

const.

$$z^L = x^L - y^L + 2ixy$$

$3C^L + ik^L \rightarrow$  some other const.

$C$  &  $k$  are real numbers.

hopefully satisfy the boundary conditions.

$$\omega = iC^L(x^L - y^L) + ik^L - 2C^L xy$$

real part

imaginary part.

$$\underline{\underline{BC}} \text{ on } C: C^L(x^L - y^L) - k^L = \frac{x^L + y^L}{L}$$

$$k^L = x^L \left[ \frac{1}{L} - C^L \right] + y^L \left[ \frac{1}{L} + C^L \right]$$

$$C^L = \frac{1}{2} \frac{a^L - b^L}{a^L + b^L} \quad k^L = \frac{ab^L}{a^L + b^L}$$

that means  $\rightarrow \phi$


$$\underline{\sigma}_{13} = \frac{G}{2} \alpha [-x_2 + \phi_{,2}]$$

$$\underline{\sigma}_{23} = \frac{G}{2} \alpha [x_1 - \phi_{,1}]$$

$$\left\{ \begin{array}{l} \underline{\sigma}_{13} = -2G \alpha a^L y \\ \underline{\sigma}_{23} = 2G \alpha b^L x \end{array} \right. \quad \frac{a^L + b^L}{a^L - b^L}$$

$w = -2C^L xy$  Also know warping function.

Note  $c=0$ ,  $a=b$ , circle



$$M = \iint_y (\underline{\sigma}_{32} x - \underline{\sigma}_{23} y) dA$$

$$= \frac{G T \alpha b^3 a^3}{(a^L + b^L)^2} = k \alpha. \quad A = \pi ab$$



how to calculate warping function / stresses in torsion.

Prandtl stress function approach:

$$\nabla^2 \phi = 0$$

$$\phi = \frac{1}{2} (x^L + y^L)^2, \text{ on } C.$$


Define a function:  $\underline{\Phi} = \phi - \frac{1}{2} (x^L + y^L)^2$   
on the BC,  $\underline{\Phi} = 0$ . on C

$$\nabla^2 \underline{\Phi} = -2 \rightarrow \text{Poisson's equation}$$

$$\phi = \underline{\Phi} + \frac{1}{2} (x^L + y^L)^2 \rightarrow \left\{ \begin{array}{l} \underline{\sigma}_{13} = \frac{G}{2} \alpha \underline{\Phi}_{,1} \\ \underline{\sigma}_{23} = \frac{G}{2} \alpha \underline{\Phi}_{,2} \end{array} \right.$$

Calculate the moment:

$$M = \alpha 2G \int \Phi dA.$$



constant  $\Phi$  curve

$$\Phi = c$$

the gradient of  $\Phi$ , normal  $\rightarrow$  surface.

$$\nabla \Phi = \Phi_{,1} e_1 + \Phi_{,2} e_2$$


$$[\Phi_{,1} e_1 - \Phi_{,2} e_2] \Rightarrow \nabla \cdot \nabla \Phi = 0.$$

The constant lines are the direction of shear vector

$\Rightarrow$  lines of shear stresses.

$$\nabla \cdot \Phi = \Phi_{,1}^2 + \Phi_{,2}^2 \propto [|\Phi| G]$$

Pearlitz soap film analogy



$T \rightarrow$  surface tension.

( $\approx$  const)

Force / length.

$\nabla^2 D = -\frac{P}{T}$

pressure.

$D(x,y)$ .

Deflection.

define new const.

$$\frac{1}{2}d = \frac{DT}{P}$$

$$D = \frac{dp_c}{2T}$$

$$\nabla^2 d = -2 \Rightarrow d=0 \text{ on } C$$

$$\nabla^2 \phi = -2$$

Similar!!

$$\text{also } D=0 \text{ on } C$$

Small membrane deflection formula.

$$c_i = \frac{\lambda_i}{2} \quad \lambda_i = \frac{\Delta}{2} E, V$$

$$\sigma = \frac{1}{J} (c_1 (\lambda_1^{2-1}) + c_2 \ln(J)) = 0$$

$$\lambda_i = 1 + \epsilon_{ii} \quad \frac{1}{\lambda_i} = 1 - \epsilon_{ii}$$

~~$$\lambda^3 \rightarrow \lambda^2 = 1 + 2\epsilon_{ii} + \epsilon_{ii}^2$$~~

$$J = \det F = \lambda_1^2 \lambda_2 = 1 + 2\epsilon_{11} + \epsilon_{33}$$

$$\ln(1+\epsilon_{ii}) \approx \epsilon_{ii}$$

$$c_1 \rightarrow$$

## II Solid Mechanics

Nov. 8, Mon, Week 12.


### Linear Viscoelasticity

ideal model:

#### Cartoon Models


- uniaxial tension test.

$$\uparrow \sigma(t)$$



real material:

Deformation  $\Rightarrow$  (history).



• MAXWELL model  $\dot{\epsilon}$   
 spring & dashpot  
 in series

Viscosity:  $\eta$ .

$\Delta \sigma_0$

$\Delta \epsilon_S$

$\Delta \sigma_S$

$$\Delta \sigma = E \Delta \epsilon_S$$

long run: simple fluid.

(suddenly apply a stress)

$$\dot{\epsilon} = \frac{\Delta \sigma}{E}$$

Same since they are  
in series.

$\Delta \sigma_{vis}$

$\eta$


$$\dot{\epsilon}_{vis} = \frac{\Delta \sigma_{vis}}{\eta}$$

$$\dot{\epsilon}_{vis} = \frac{\Delta \sigma}{\eta}$$

$$\begin{cases} \dot{\epsilon} = \frac{\Delta \sigma}{E} + \frac{\Delta \sigma_{vis}}{\eta} \\ \dot{\epsilon}_S + \dot{\epsilon}_{vis} \end{cases}$$


$\Rightarrow$  ODE in time

Voigt model.




$$\sigma = \sigma_s + \sigma_{vis}.$$

$$\sigma_k = E\varepsilon + \eta\dot{\varepsilon} \Rightarrow \text{Voigt model.}$$



Maxwell.



Solve a ODE to get

this curve.

$$t > 0, \Rightarrow \eta\dot{\varepsilon} + E\varepsilon = 0.$$



$$\varepsilon = A e^{-\frac{E}{\eta}t} + \frac{1}{E}$$

$$= \frac{1}{E} \left[ 1 - e^{-\frac{E}{\eta}t} \right].$$


Short time: fluid; \$ long time solid

• Standard model

$\sigma(\varepsilon)$ .



Voigt element.



$$\frac{1}{E_1} + \frac{1}{E_2} = \frac{1}{E_L} + \frac{1}{\eta}$$

Solid behavior for both long & short time

$$\dot{\sigma} + \frac{\bar{E}_1 + \bar{E}_2}{2} \sigma = E_1 \dot{\varepsilon} + \frac{\bar{E}_2 \bar{E}_1}{\eta} \varepsilon. \quad \text{Linear ODE}$$

3 parameters to determine.

• Concept of Creep function.

Creep function  $C(t)$  strain history due to

$$\text{a unit stress } \sigma = H(t) = \begin{cases} 1, & t > 0 \\ 0, & t < 0. \end{cases}$$

$$C(t) = \left( \frac{1}{E} + \frac{t}{2} \right) H(t). \Rightarrow \text{Maxwell}$$

$$C(t) = \frac{1}{E} \left( 1 - e^{-\frac{E}{\eta}t} \right) H(t). \Rightarrow \text{Voigt.}$$

$$C(t) = \frac{\bar{E}_1 + \bar{E}_2}{\bar{E}_1 \bar{E}_2} - \frac{1}{\bar{E}_2} e^{-\frac{E_2 t}{\eta}} \quad \text{units: } \frac{1}{t}$$


$t_c \leftrightarrow \text{Creep relaxation time}$

$$C(t=0) = \frac{1}{E_1} \quad \text{short time modulus.}$$

$$C(t=\infty) = \frac{1}{E_2} + \frac{1}{E_1} = \frac{1}{E_\infty}$$


long time modulus.

$$\frac{E_\infty}{E_1} = 10^{-3}.$$




$$\epsilon(t) = H(t).$$

UNIT STRAIN & STRESS HISTORY.



$$\epsilon(t) = E e^{-\frac{E}{T_2} t} H(t).$$

Für standard Solid:



$$t_R = \frac{\tilde{E}_1 + \tilde{E}_2}{\tilde{E}_1}, \quad \tilde{E}_0 = E_1.$$

$$\left( \rightarrow \frac{n}{E_1 + E_2} \text{ (typo)} \right)$$

Boltzmann superposition principle

(1) Assume system is linear.

(2) Assume Causality.

(3) Non-Aging.

Creep.

Driven  $C(t)$

Response of system

due to a unit stress step function.

$$\begin{aligned} \sigma(t) &= \sigma(0^+) H(t) + \sigma'(\Delta\tau) \int_{-\infty}^t H(t-\Delta\tau) d\tau \\ H(t-\Delta\tau) &= H(t-\Delta\tau) + \sigma'(\Delta\tau) \Delta\tau H(t-\Delta\tau), \end{aligned}$$

$$\epsilon(t) = \sigma(0^+) C(t) + \sigma'(\Delta\tau) \Delta\tau C(t-\Delta\tau)$$

$$C(t-\Delta\tau) + \sigma'(\Delta\tau) \Delta\tau C(t-2\Delta\tau)$$

$$H(t-2\Delta\tau) + \dots$$

$$\begin{aligned} &= \sigma(0^+) C(t) + \int_{0^+}^t \sigma'(\tau) C(t-\tau) d\tau. \end{aligned}$$

Nov. 10, Wed, Week 12.





Review: Boltzmann superposition -

Any stress history can be broken down into sum of step functions.

↓ Each step fun.  $f(t-\tau)$   
 $C(t-\tau)$ .

Real linear viscoelastic  $\Rightarrow \dot{\epsilon}(t) = \sigma(0^+) C(t) + \int_{0^+}^t C(t-\tau) \frac{d\sigma}{dt} d\tau$   
 model for uniaxial tension.

Do a simple example



[Convolution product  $f(t), g(t)$ . Define for  $t \in (0, \infty)$ .

$$f \cdot * g = \int_0^t f(t-\tau) g(\tau) d\tau = \int_0^t g(t-\tau) f(\tau) d\tau.$$

①  $\boxed{\dot{\epsilon} = \sigma(0^+) C(t) + C * \sigma'}$   $\sigma' = \frac{d\sigma}{dt}$

The Laplace transform of a function  $f$  defined in zero to infinity.

$$\mathcal{L}[f] = \int_0^\infty e^{-st} f(t) dt.$$

$\mathcal{L}[f]$  is a function of  $s$ .  
 $s$  is the transform variable.

$s$  is in general a complex variable

Properties.

$$\mathcal{L}[f'(t)] = sf(s) - f(0^+).$$

$$\mathcal{L}[f * g] = \tilde{f}(s) \tilde{g}(s) \leftarrow \text{convolution Theorem}$$

Laplace transform (1) :

$$\tilde{\epsilon}(s) = \sigma(0^+) \tilde{Y}(s) + \underbrace{\mathcal{L}[Y * \sigma']}_{}.$$

$$\begin{aligned} & \tilde{C}(s) \underbrace{\mathcal{L}[\sigma'(t)]}_{[s\tilde{\sigma}(s) - \sigma(0^+)]} \\ \rightarrow & \tilde{\epsilon}(s) = s\tilde{C}(s)\tilde{\sigma}(s) \quad (2) \\ \text{clear } & \rightarrow \text{ & linear.} \quad \text{transform domain!} \end{aligned}$$

$$\text{Messy} \Rightarrow \epsilon(t) = \sigma(0^+) C(t) + \int_{0^+}^t C(t-\tau) \frac{d\sigma}{d\tau} d\tau.$$

Do the same thing with Relaxation function  $Y(s)$ .

Apply a strain history:  $\epsilon(t) \leftarrow$  given.

$$\sigma(t) = \sigma(0^+) Y(t) + \int_{0^+}^t Y(t-\tau) \frac{d\epsilon}{d\tau} d\tau.$$

$$\boxed{\tilde{\sigma}(s) = s \tilde{Y}(s) \tilde{\epsilon}(s)} \quad (3) \quad \text{on the transform plane,}\\ \text{it's trivial.}$$

Combine (2) & (3)

$$\hat{\sigma}(s) = s \tilde{Y}(s) \cdot s \tilde{C}(s) \tilde{\sigma}(s).$$

$$\Rightarrow \boxed{s \tilde{Y}(s) \cdot \tilde{C}(s) = 1} \quad \text{related.}$$

$$\tilde{Y}(s) = \frac{1}{s^2 \tilde{C}(s)}.$$

$$Y(t) = \mathcal{L}^{-1}\left[\frac{1}{s^2 \tilde{C}(s)}\right]$$


$$\hookrightarrow \tilde{Y}(s) \cdot \tilde{C}(s) = \frac{1}{s^2}$$

$$\left( \mathcal{L}^{-1}\left[\frac{1}{s^2}\right] = t \right)$$

$$\int_0^t Y(t-\tau) C(\tau) d\tau = t \quad t \geq 0.$$

$$\frac{1}{2\pi i} \int_{\gamma-i\infty}^{\gamma+i\infty} \tilde{Y}(s) e^{st} ds = Y(t), \quad t > 0.$$

$$S = S_1 + iS_2$$



$Y(s)$  is  
Analytic on  $\text{Re } s > 0$

Isotropic linear viscoelastic solid.

$$\sigma_{ij} = 2G \epsilon_{ij} + \lambda \epsilon_{kk} \delta_{ij}. \quad \underline{\text{Memorize this!!}}$$

$$\epsilon_{ij} = \frac{\sigma_{ij}}{2G} - \frac{\nu}{E} \sigma_{kk} \delta_{ij} \quad E = \frac{G}{2(1+\nu)}$$

deviatoric stress tensor

$$\tilde{S}_{ij} = \tilde{\sigma}_{ij} - \frac{1}{3} \tilde{\sigma}_{kk} \delta_{ij}$$

$$\tilde{\epsilon}_{ij} = \epsilon_{ij} - \frac{1}{3} \epsilon_{kk} \delta_{ij}$$

↑  
strain deviator tensor

volumetric part

in literature,  $\frac{1}{3} \tilde{\sigma}_{kk} = \tilde{\sigma}$ ;  $\epsilon_{kk} = \frac{e}{V}$

$e_{ij}$  change of volume.

Shear Modulus.  
(relaxation modulus).

$$\left\{ \begin{array}{l} S_{ij} = 2G e_{ij} \\ \tilde{\sigma}_{kk} = 3K \epsilon_{kk} \end{array} \right. \quad \begin{array}{l} \uparrow \\ \text{(relaxation)} \\ \text{Bulk Modulus.} \end{array}$$

Exactly the SAME

$$\left\{ \begin{array}{l} \tilde{\sigma}_{ij} = 2G \tilde{\epsilon}_{ij} + \lambda \epsilon_{kk} \delta_{ij} \\ \tilde{\epsilon}_{ij} = \frac{\tilde{\sigma}_{ij}}{2G} - \frac{\lambda}{E} \tilde{\sigma}_{kk} \delta_{ij} \end{array} \right.$$

$$S_{ij} = e_{ij}(0^+) Y_1(t) + \int_{0^+}^t Y_1(t-\tau) \frac{\partial e_{ij}}{\partial \tau} d\tau$$

$$Y_1(t) \longleftrightarrow 2G, \quad \tilde{\sigma}_{kk} = \epsilon_{kk}(0^+) Y_2(t) + \int_{0^+}^t Y_2(t-\tau) \frac{\partial \epsilon_{kk}}{\partial \tau} d\tau$$

$$Y_2 \longleftrightarrow 3K$$

Consider 2

$$\tilde{S}_{ij} = S \tilde{Y}_1(s) \tilde{\epsilon}_{ij}$$


$$\tilde{\sigma}_{kk} = S \tilde{Y}_2(s) \tilde{\epsilon}_{kk}$$

linear elasticity  $\tilde{\sigma}_{ij,j} = 0$ . no body force.

$$\tilde{\epsilon}_{ij} = \frac{\tilde{u}_{ij} + \tilde{u}_{ji}}{2}, \quad \text{kinematics.}$$

constitutive model.  $\left\{ \begin{array}{l} S_{ij} = e_{ij}(0^+) Y_1(t) + Y_1^* \tilde{\epsilon}_{ij} \\ \tilde{\sigma}_{kk} = \tilde{\epsilon}_{ij} \epsilon_{kk}(0^+) Y_2(t) + Y_2^* \tilde{\epsilon}_{kk} \end{array} \right.$

general problem



linear elasticity  $\left\{ \begin{array}{l} \tilde{\sigma}_{ij,j} = 0 \\ \tilde{\epsilon}_{ij} = \frac{\tilde{u}_{ij} + \tilde{u}_{ji}}{2} \end{array} \right.$

correspondence principle

$$\tilde{S}_{ij} = S \tilde{Y}_1(s) \tilde{\epsilon}_{ij}(s)$$


$$\tilde{\sigma}_{kk} = S \tilde{Y}_2(s) \tilde{\epsilon}_{kk}(s)$$

$$\underline{\underline{\sigma}}(x, s) = \underline{\underline{f}}(x, s)$$

$$\tilde{u}_{ij,j} = \Pi_i(x, s)$$

2G

Simple Example




$$\text{BCs. } \begin{cases} \sigma_{rr}(r=a, t>0) = P_0, \\ \tau_{rn}(r=b, t>0) = 0 \end{cases}$$

$SY(s), C_1(s) s = 1$

$$\tilde{\epsilon}_{ij}(s) = S C_1(s) \tilde{s}_{ij}$$

$$e_{ij} = C_1(t) \tilde{s}_{ij}(t^*) + \int_{t^*}^t C_1(t-\tau) \frac{\partial \tilde{s}_{ij}}{\partial \tau} d\tau$$



$$u_3(x_1, x_2, x_3=0) = -\Delta$$

$$(x_1^2 + x_2^2) < 1$$

$$\sigma_{ij} = \frac{G\Delta}{a} f\left(\frac{r}{a}, 0\right)$$

Office Hour.


$$f \rightarrow \phi$$

$$\nabla^2 \phi = 0, \quad \phi = \frac{x^2 + y^2}{2}$$

formulate

$f \rightarrow \text{BCs} \rightarrow \text{simple.}$

$$f|_{\text{BCs}} = 0$$



$f \rightarrow \text{harmonic}$

↳ separation of variables

Differential Eqs.

$$\frac{\partial^2 \phi}{\partial x^2} + \frac{\partial^2 \phi}{\partial y^2} = 0 \Rightarrow \frac{\partial^2 \phi}{\partial x^2} = -\frac{\partial^2 \phi}{\partial y^2}$$

$$f = \frac{\partial \phi}{\partial x^2} + 1$$

Example:




PRAUDTL: Stress function

Three common formulations for solving torsion:  
 $w$ ,  $\phi$ ,  $\Phi_p$ .

Solution for Laplacean

$\gamma$   
Harmonic Analysis.



November 15, 201. Week 13. Mon.

REVIEW: correspondence principle.

$$Y(t) = Y_\infty + (Y_0 - Y_\infty) \sum_{j=1}^n a_j e^{-t/t_j}$$

$Y_\infty = Y(t = \infty)$  long time modulus.

$Y_0 = Y(t = 0)$ , Instantaneous Modulus.

$$\sum_{j=1}^n a_j = 1$$

$t_j$  = Relaxation times.

$\hookrightarrow Y(t)$ .

creep fact.

wrong.

Power law model.


$$Y(t) = Y_\infty + (Y_0 - Y_\infty) \cdot Y_0$$

$$\frac{1}{1 + (t/t_0)^\alpha}$$

Corresponds to

$$\underbrace{\varepsilon_0}_{\text{...}}, \underbrace{\varepsilon_1}_{\text{...}}, \underbrace{\varepsilon_2}_{\text{...}}, \underbrace{\varepsilon_3}_{\text{...}}, \dots$$

$n$  of this



Phenology.

Shear strain:  $\varepsilon = \varepsilon_0 e^{int}$ .

\* What is the response?

(long time / steady state res.)



$$\text{Shear Stress } \sigma(t) = \varepsilon_0(t^+) Y_1(t) + \int_0^t (Y_1(\tau) - \tau) \frac{d\varepsilon}{d\tau} d\tau$$

$$= \varepsilon_0 Y_1(t) + \int_0^t \varepsilon_0 \int_0^\tau Y_1(\tau - \tau') e^{i\omega\tau'} d\tau' d\tau$$

$$\varepsilon_0 Y_1(t) + i\omega \varepsilon_0 \int_{t^+}^t [Y_1(t-\tau) - Y_1(\tau)] e^{i\omega\tau} d\tau$$

$$+ i\omega \varepsilon_0 Y_1(t) \int_{t^+}^t e^{i\omega\tau} d\tau$$

$$i\omega \varepsilon_0 Y_1(t) \cdot \frac{e^{i\omega t}}{i\omega}$$

$$= \varepsilon_0 Y_1(t) e^{i\omega t} - \varepsilon_0 Y_1(t)$$

$$= \varepsilon_0 Y_1(t) e^{i\omega t} + i\omega \varepsilon_0 \int_0^t [Y_1(t-\tau) - Y_1(\tau)] e^{i\omega\tau} d\tau$$

$$\int_0^t Y_1(t-\tau) e^{i\omega\tau} d\tau. \quad \eta = t-\tau.$$

$$\tau = t-\eta.$$

$$= \int_t^\infty Y_1(\eta) \cdot e^{i\omega(t-\eta)} (-d\eta)$$

$$= \int_0^t Y_1(\eta) e^{i\omega(t-\eta)} d\eta = e^{i\omega t} \int_0^t Y_1(\eta) e^{-i\omega\eta} d\eta$$

$$\int_0^t Y_1(\tau) \cdot e^{i\omega\tau} d\tau.$$

$$= Y_1(t) \cdot e^{i\omega t} \int_0^t e^{i\omega\eta} d\eta.$$

$$J(t) = \varepsilon_0 Y_1(t) \cdot e^{i\omega t} + i\omega \int_0^t [Y_1(\eta) - Y_1(t)] e^{i\omega\eta} d\eta$$

$$= e^{i\omega t} \left[ \varepsilon_0 Y_1(t) + i\omega \int_0^t [Y_1(\eta) - Y_1(t)] e^{-i\omega\eta} d\eta \right]$$

$\xrightarrow{t \rightarrow \infty}$  converge to  $\varepsilon_0 Y_1(\infty) + i\omega \int_0^\infty [Y_1(\eta) - Y_1(\infty)] e^{-i\omega\eta} d\eta$ .


$\hat{Y}_1(\omega)$

Complex Modulus

$$\sigma(t \rightarrow \infty) = \varepsilon_0 e^{i\omega t} \hat{Y}_1(\omega).$$

$$\hat{Y}_1 = \hat{Y}_1(\omega) + i \hat{F}_1(\omega)$$

Storage modulus      loss modulus.



$$\hat{Y}'(\omega) = Y_1(\omega) + \omega \int_0^\infty [Y_1(\eta) - Y_1(\omega)] \sin(\omega\eta) d\eta.$$

$$\hat{Y}''(\omega) = \omega \int_0^\infty [Y_1(\eta) - Y_1(\omega)] \cos(\omega\eta) d\eta.$$

$\hat{Y}'(\omega) = \hat{Y}'(-\omega)$  → even fct. of  $\omega$

$\hat{Y}''(\omega) = \text{odd fct. of } \omega$

Change of energy in a cycle.

$$W = \int_{\text{cycle}} \sigma d\epsilon$$

$$\text{we apply } \sigma = \epsilon_0 \left[ \frac{e^{i\omega t} + e^{-i\omega t}}{2} \right]$$

$$= \epsilon_0 \cos(\omega t).$$

$$\epsilon_0 \frac{e^{i\omega t}}{2} \rightarrow \epsilon_0 \hat{Y}_1(\omega) e^{i\omega t} = \sigma(t).$$

$$\epsilon_0 \frac{e^{-i\omega t}}{2} \rightarrow \frac{\epsilon_0 \hat{Y}_1(-\omega)}{2} e^{-i\omega t} = \sigma(t).$$

$$\hat{Y}_1(-\omega) = \hat{Y}_1(\omega)$$

$$\sigma = \frac{\epsilon_0}{2} [\hat{Y}_1(\omega) e^{i\omega t} + \hat{Y}_1(\omega) e^{-i\omega t}]$$

$$= \epsilon_0 [\hat{Y}'(\omega) \cos(\omega t) - \hat{Y}''(\omega) \sin(\omega t)].$$

$$\therefore e^{i\omega t} Y_1(\omega) = [\hat{Y}'(\omega) + i\hat{Y}''(\omega)] [\cos(\omega t) + i \sin(\omega t)]$$

$$\text{Re}(\quad) = \hat{Y}'(\omega) \cos(\omega t) - \hat{Y}''(\omega) \sin(\omega t)$$

$$-d\sigma = \omega \epsilon_0 \sin(\omega t) dt$$

$$-\omega \epsilon_0^2 \int_{\text{cycle}} [\hat{Y}'(\omega) \cos(\omega t) - \hat{Y}''(\omega) \sin(\omega t)] \sin(\omega t) dt$$

$$\text{work} = W \text{ in a cycle}$$

$$\text{we already show: } \epsilon_0 e^{i\omega t} \rightarrow \epsilon_0 \hat{Y}_1(\omega) e^{i\omega t}.$$

$$1^{\text{st integral}}$$


$$\hat{Y}_1(\omega) \cos(\omega t) ds \sin(\omega t)$$

$$\omega \epsilon_0^2 \hat{Y}''(\omega) \int_{\text{cycle}} \sin^2(\omega t) dt$$


Some number

$$\frac{d \cos^2 \omega t}{2\omega}$$

if you plot the last modulus @ this freq.



Nov. 17, 2021. Wed., Week 13.



$$\hat{Y}_1(\omega) = \hat{Y}'_1(\omega) + i \hat{Y}''_1(\omega)$$

↑  
 $\sqrt{1 - \tan^2 \delta}$   
 loss modulus  $\rightarrow$  odd function.

Storage modulus

Energy loss per cycle  $= \pi \sigma_0^2 |\hat{Y}''_1(\omega)|$


$\rightarrow$  even function.

loss tangent.

$$\hat{Y}_1 = |\hat{Y}_1| e^{i\delta}$$

$$\tan \delta = \frac{\hat{Y}''_1}{\hat{Y}'_1}$$

loss tangent.



$$\hat{Y}_1(\omega) = \hat{Y}_1(\infty) + i\omega \int_0^\infty [\hat{Y}_1(\eta) - \hat{Y}_1(\infty)] e^{-i\omega\eta} d\eta$$

complex relaxation function  
 in time domain

creep modulus.

long time shear strain.  
 $\epsilon = \epsilon_0 \hat{C}_1(\omega) e^{i\omega t}$

$\rightarrow \hat{C}_1(\omega) = C_1(\infty) + \int_0^\infty [C_1(\eta) - C_1(\infty)] e^{-i\eta\omega} d\eta$

$$\sigma_0 e^{i\omega t} \rightarrow \boxed{\quad} \rightarrow \epsilon_0 \hat{C}_1(\omega) e^{i\omega t} = 0$$

$$\sigma = \sigma_0 e^{i\omega t} \rightarrow \boxed{\quad} \rightarrow \sigma_0 \hat{C}_1(\omega) e^{i\omega t}$$

$$\sigma_0 = \epsilon_0 \hat{Y}_1(\omega)$$

$$\hat{Y}_1(\omega) = \frac{1}{\hat{C}_1(\omega)}$$


$$\int_0^t C_1(t-\tau) Y_1(\tau) d\tau = t$$

$$s^2 \hat{C}_1 \hat{Y}_1 = 1$$

$\hookrightarrow$  Laplace transform

$$\int_0^\infty e^{-st} C_1(t) dt = \hat{C}_1(s)$$

Standard model




$$Y_1(t) = Y_\infty + (Y_0 - Y_\infty) e^{-t/t_0}$$

$Y_\infty \equiv Y_1(t \rightarrow \infty) \rightarrow$  long time shear modulus

$Y_0 = Y_1(t \rightarrow 0) \rightarrow$  short time

$$\begin{aligned} \hat{Y}_1(\omega) &= Y_\infty + \frac{i\omega(Y_0 - Y_\infty)}{\tau_R^2 + \omega^2} \\ \hat{Y}_1(\omega) &= Y_\infty + \frac{\omega^2 \tau_R^2 (Y_0 - Y_\infty)}{1 + \omega^2 \tau_R^2} \\ \hat{Y}_1''(\omega) &= \frac{\omega \tau_R (Y_0 - Y_\infty)}{1 + \omega^2 \tau_R^2} \end{aligned}$$




Time Temp. Superposition

$\omega: 10^{-2}$  Radians/s. +  $\sim 10^2$  rad/s.


$$\begin{aligned} Y'_1(\omega, T) &= b(T, T_0) \phi_1(a(T, T_0) \omega) \\ Y'_2(\omega, T) &= b(T, T_0) \phi_2(a(T, T_0) \omega) \end{aligned}$$

↑ Ref. Temp.  
Shift Factors.



$$\log \frac{\hat{Y}_1}{b(T, T_0)} = \log \frac{1}{1 - \log b(T, T_0)}$$

Universal curve.



$$\log [a(T, T_0) \omega]$$

$$= \log a(T, T_0) + \log (\omega)$$

WLF - shift factor.

$$a(T, T_0) = \frac{C_1(T_0)(T-T_0)}{C_2(T_0)+(T-T_0)}$$

Normally,  $T_0 \rightarrow$  glass transition temp. of polymer

$$\begin{aligned} \hat{Y}_1(\omega) &= Y_\infty + \\ i\omega \int_0^\infty & [Y_1(\eta) - Y_1(\omega)] e^{i\omega\eta} d\eta \end{aligned}$$

complex modulus.


time domain (relaxation fct.)

Gruen.

$\hat{Y}'_1$  &  $\hat{Y}'_2$  are not independent to each other

If u know one, you know the other.

$$\frac{1}{\pi} PV \int_{-\infty}^{\infty} \frac{\hat{Y}'_1(r) - \hat{Y}'_1(\infty)}{r \omega} dr$$



$$2G_1\varepsilon = \tau$$

$$\gamma$$

$$\tau = G\gamma$$

$$e_{ij} = S Y_i^*$$

$$S Y_j = S \sum_i e_{ij}$$

$$\sigma_{kk} = S \sum_i e_{kk}$$

$$E = 2G(1+2)$$

linear Elasticity.

$G, v$ .

linear Viscoelasticity.

$G, v, E, k$ .

bulk (relaxation).

OH: Superposition principle.


want to stress in tension test.

$$\tilde{\sigma}(t) = \tilde{\epsilon}(0^+) Y(t) + \int_{0^+}^t Y(t-\tau) \frac{d\epsilon}{d\tau} d\tau$$

$$= \epsilon(0^+) Y(t) + Y \times \frac{d\epsilon}{dt}$$

strain history

$\downarrow$   
stress history




asked to evaluate the stress history.


load fast  $\rightarrow$  strain rate  $\rightarrow$  high  $\rightarrow$

End: should not have stress in  
Spring 1 & Spring 2.

After 2b. you should be able to see.



Q:



You have:

creep function  $C(\epsilon) \cdot Y(t)$

find one equation of how

only one disp. field ( $u$ )

Strain  $\rightarrow 3$

$u_t$   $\epsilon_{tt}$   $\sigma_{tt}$



$$u_r \rightarrow \varepsilon_{rr}, \varepsilon_{\theta\theta} = \varepsilon_{\phi\phi}$$

$\nabla$  const. model

$$\sigma_{rr}, \sigma_{\theta\theta}, \sigma_{\phi\phi}, \psi,$$

Equilibrium Eq.

Incompressible.

$$\varepsilon_{rr} + \varepsilon_{\theta\theta} + \varepsilon_{\phi\phi} = 0$$



pressure = const.


$$r = r_0, \sigma_{rr} = -P.$$

integrate incompressibility.

$$\sigma_{ij} = 2G\varepsilon_{ij} + P \delta_{ij}$$

hydrostatic.  
incompressibility

$$\varepsilon_{kk}=0$$



only difference:

$$\sigma = \frac{(\cos \omega t) e^t}{(1+t^3)}$$

strain

$$\sigma = \sigma_0 \cos \omega t$$


$$\varepsilon = \frac{\sigma_0 \cos \omega t}{E}$$

elastic.

$$\varepsilon = \sigma(0^+) \frac{C}{E} \delta(t)$$

$$+ \int_0^t C(t-\tau) \frac{\partial \sigma}{\partial \tau} d\tau$$

$$\xi = \sigma_1 / E_1$$



$$\dot{\xi} = \frac{\dot{\sigma}_2}{E_2} + \frac{\eta}{\eta}$$

$$\int_0^\infty \frac{e^{-i\omega\eta}}{1+n/\tau_k} d\eta$$

$G_p - G_\infty$

Exponential Integral

$$= \int_0^\infty \frac{e^{-i\omega\eta}}{1+u} du$$

$du = u \tau_k$

$$\hat{\omega} = \omega \tau_k$$



basic idea  $\mapsto$  integrate this term.

Compute integral by picking ~~path~~ ~~contour~~

$$\int_0^\infty \frac{\omega \tau_k u du}{(1+u)} - i \int_0^\infty \frac{\sin \omega u du}{(1+u)}$$

infinite value

Riemann - hairy theory



Nov. 22, Mon, 2021. Wk 14.

Linear visco-isotropic material.

$$\epsilon_{ij} = \epsilon_{ij} - \frac{1}{3} \epsilon_{kk} \delta_{ij} = \frac{1}{2G} S_{ij} \text{ elasticity.}$$

$$\epsilon_{kk} = \frac{1}{K} \cdot \frac{\sigma_{kk}}{3}$$


$\downarrow$

bulk deformation.

$$\sigma_{ij} - \frac{1}{3} \sigma_{kk} \delta_{ij}$$

$\downarrow$   
shear deformation

$$= \frac{s^3 \tilde{C}_1 \tilde{C}_2}{2\tilde{C}_2 + \tilde{C}_1} = \tilde{S} \tilde{E}(s)$$



Plane strain problem.

Visco.  $\epsilon_{ij} = C_1(t) S_{ij}(t=0^+) + \int_{0^+}^t C_1(t-\tau) \frac{\partial S_{ij}}{\partial \tau} d\tau$

$\downarrow$

$$\epsilon_{kk} = C_2(t) \sigma_{kk}(t=0^+) + \int_{0^+}^t C_2(t-\tau) \frac{\partial \sigma_{kk}}{\partial \tau} d\tau$$

$\downarrow$   
transform variable.

$$\tilde{\epsilon}_{ij} = S \tilde{C}_1(s) \tilde{S}_{ij}$$


$$\tilde{\epsilon}_{kk} = S \tilde{C}_2(s) \tilde{\sigma}_{kk}$$

$$: \frac{s^3 \tilde{C}_2(\tilde{C}_1/2)}{\tilde{C}_2 + (\tilde{C}_1/2)}$$

$$\frac{1}{2G} \longleftrightarrow S \tilde{C}_1(s)$$

$$\frac{1}{3K} \longleftrightarrow S \tilde{C}_2(s)$$

$$\epsilon = \frac{9KG}{3(K+G)}$$




assume infinitely long.

$$F = \frac{P}{L}$$

$$F, G, r, \theta. (90^\circ \text{ away})$$

$$\Omega = \sqrt{\frac{F}{r} f(F/G, \theta)}$$

force per unit length.



solution has to be,

$$\sigma = \frac{F}{r} f(\theta) = 0$$

$$\epsilon_{11} = \frac{\sigma_{11}}{E} - \frac{1}{2G} (\sigma_{12} + \sigma_{33}) \quad \text{with } \epsilon_{12}, \epsilon_{33}, \epsilon_{13}$$

$$\sigma_{11} = \frac{\sigma_{11}}{E} - \frac{1}{2G} (\sigma_{12} + \sigma_{33}) \quad \tan(\frac{\epsilon}{2}) = \epsilon_3 + \epsilon_{12}/2$$

$$\Rightarrow \sigma_{11} = [1 - \frac{1}{4}] - \frac{1}{2G} \left[ \frac{B(0.052)}{2} \right].$$


$$\frac{3}{4G} = \frac{1}{4G} = \frac{3\sigma_{11}}{4E} - \frac{3\sigma_{33}}{4E}$$

$$= \frac{1}{4G} [\sigma_{11} - \sigma_{33}]$$



$$\sigma = \frac{F}{r} f(\theta)$$

$$\epsilon = \frac{F}{Gr} g(\theta)$$


displacement.  $u$ .



$\ln r$







$$\sigma_{ij}(x, y) = \frac{F}{\sqrt{x^2+y^2}} f_{ij}\left(\frac{y}{x}\right)$$



$$d\sigma_{ij}(x, y, x') = \frac{F}{\sqrt{(x-x')^2 + y^2}} f_{ij}\left(\frac{y}{x-x'}\right)$$

$$\sigma_{ij}(x, y) = \int_{-\infty}^{\infty} \frac{-t(x') f_{ij}\left(\frac{y}{x-x'}\right) dx'}{\sqrt{(x-x')^2 + y^2}}$$

$\rightarrow$  general solution.  $\rightarrow$  you need to find



$$\text{gradient of disp. } \nabla_x = - \frac{1}{2\pi G} \int_{-a}^a \frac{t(x') dx'}{x - x'} = 0.$$

SOLUTION :  $t(x) = \frac{A}{\sqrt{a^2 - x^2}} = \frac{F}{\pi \sqrt{a^2 - x^2}}$

HW 11. Q3.

First, given. substitute the BCs :

$$\sigma_{rr}(r=b) = -P$$

compatibility eq.

$$\frac{\partial^2 \epsilon_{xx}}{\partial y^2} + \frac{\partial^2 \epsilon_{yy}}{\partial x^2} = \frac{\partial^2 \epsilon_{xy}}{\partial x \partial y} \quad \dots (1)$$

constitutive eq.

$$\sigma_{ij} = 2G \epsilon_{ij} + P \delta_{ij} \quad \dots (2)$$

equilibrium eq.

$$\sigma_{ij,j} = 0 \quad \dots (3)$$

Substitute the BCs into Eqs. (1), (2), (3), we can hence compute the stress (radial).

► Taking BG's advice, we take  $\sim$

$$\text{from Eq. 12). } \epsilon_{ij} = (\sigma_{ij} - P \delta_{ij}) / 2G.$$

From compatibility eq. (1) :

$$\sigma_{rr,rr} - P \sigma_{rr,\theta\theta} + \sigma_{\theta\theta,rr} - P \sigma_{\theta\theta,rr} = \sigma_{rr,rr} - P \sigma_{\theta\theta,rr}$$

▷ Equilibrium:

$$\sigma_{rr, \theta} + \sigma_{\theta\theta, r} + \sigma_{rr, \theta} + \sigma_{\theta\theta, \theta} = 0 \dots (4)$$

▷ Modified compatibility

$$\sigma_{rr, \theta\theta} + \sigma_{\theta\theta, rr} - \sigma_{rr, r\theta} = P \dots (5)$$

→ Now, substitute BCs  $\Rightarrow$  Nah

Equilibrium:  $\int (\sigma_{rr} + \sigma_{\theta\theta}) d\theta - \int (\sigma_{\theta\theta} + \sigma_{rr}) d\theta$

Laplace trans.

$$\tilde{\sigma}_{ij,i} = 0$$

$$\tilde{\varepsilon}_{ij} = (\tilde{u}_{i,j} + \tilde{u}_{j,i})/2.$$

$$\tilde{\sigma}_{kk} = S \tilde{C}_2 \tilde{\sigma}_{kk}, \quad \tilde{\sigma}_{ij} = S \tilde{C}_1 \tilde{\sigma}_{ij}$$

$$\tilde{\sigma}_r(r=b) = -\frac{P}{S}.$$

$$\frac{d\sigma_{rr}}{dr} + \frac{1}{r}(\sigma_r - \sigma) = 0.$$

Same in Laplace space:

$$\frac{d\tilde{\sigma}_m}{dr} + \frac{1}{r}(\tilde{\sigma}_m - \tilde{\sigma}) = 0.$$

$$\frac{\partial^2 \Sigma_{xx}}{\partial y^2} + \frac{\partial^2 \Sigma_{yy}}{\partial x^2} = \frac{\partial^2 \Sigma_{xy}}{\partial x \partial y}.$$

$$\sigma_{ij} = 2G \varepsilon_{ij} + P \delta_{ij}$$

$$\frac{\partial^2 \sigma_{ij}}{\partial x_j^2} + \frac{\partial^2 \sigma_{ij}}{\partial x_i^2} = 2 \frac{\partial^2 \sigma_{ij}}{\partial x_i \partial x_j}.$$

$$\sigma_{ii} = 2G \varepsilon_{ii} + P \delta_{ii}$$

$$\sigma_{jj} = 2G \varepsilon_{jj} + P \delta_{jj}$$

$$\sigma_{ij} = 2G \varepsilon_{ij} + P \delta_{ij}$$

$$\varepsilon_{ii} = \frac{\sigma_{ii} - P \delta_{ii}}{2G}$$

$$\varepsilon_{jj} = \frac{\sigma_{jj} - P \delta_{jj}}{2G}$$

$$\varepsilon_{ij} = \frac{\sigma_{ij} - P \delta_{ij}}{2G}$$

spherical:  

$$\frac{\partial^2 \tilde{\sigma}_{rr}}{\partial \theta^2} + \frac{\partial^2 \tilde{\sigma}_{\theta\theta}}{\partial r^2} = \frac{\partial^2 \tilde{\sigma}_{\theta r}}{\partial r \partial \theta}$$


$$\rightarrow \frac{\partial^2 \sigma_{ii}}{\partial x_j^2} + \frac{\partial^2 \sigma_{jj}}{\partial x_i^2} = \frac{\partial^2 \sigma_{ij}}{\partial x_i \partial x_j}.$$

in Laplace domain:  $\frac{\partial^2 \tilde{\sigma}_{ii}}{\partial \tilde{x}_j^2} + \frac{\partial^2 \tilde{\sigma}_{jj}}{\partial \tilde{x}_i^2} = \frac{\partial^2 \tilde{\sigma}_{ij}}{\partial \tilde{x}_i \partial \tilde{x}_j}$


Nov. 29, Mon. wk 15.

★ Exam: Dec. 11. 9am - 9pm.

## HW Review




~~After~~ Setup the traction free BCs



Remember how the setup  
the traction free BC

$$\underline{n} = \cos\theta \underline{e}_1 + \sin\theta \underline{e}_2$$

N should always normal to the surface  
BECAUSE it identifies the surface




$$P = \sqrt{r^2 + z^2}$$

$$\stackrel{\Delta}{=} (\rho \rightarrow \infty) \rightarrow 0.$$

frictionless BCs: Cannot take any load.





~~there are no shear~~



$$\text{BC: } \sigma_{rz} = \sigma_{\theta z} = \tau_{\theta z} = 0, \quad r > a, \quad z = 0.$$

~~traction free~~

inside the contact region:  $\sigma_{rz} = \sigma_{\theta z} = 0,$   
 $r < 0, z = 0$



$$R^2 - 2R\Delta + \Delta^2 + a^2 = R^2$$

$$a^2 \approx 2R\Delta$$

$$\Delta = \frac{a^2}{2R}$$

like a fluid.

Actual Hertz soln.  $\Delta = \frac{a^2}{R}$

$$\Delta = \frac{P}{G \pi a} \quad \text{numerical const.}$$



measure the load F

$$\Delta = \left[ \frac{9}{16R(4G)^2} \right] F^{2/3}$$


incompressible solid.

$$4G \rightarrow E^* = \frac{E}{1-2\nu^2}$$

shear modulus



Standard Bushiness soln.  $u_3 = \frac{P}{4\pi G} \cdot \frac{2(1-\nu)}{r} \frac{1}{\sqrt{x^2+y^2}}$



$u_3(r, x_0, y_0) = \frac{P(x_0, y_0)}{4\pi G} \frac{2(1-\nu)}{\sqrt{(x-x_0)^2 + (y-y_0)^2}}$

line load

$u_3(r, z=0) = \frac{P}{4\pi G} \frac{2(1-\nu)}{\sqrt{x^2+y^2}}$

Superposition:  $P(x_0, y_0) \Rightarrow P(x_0, y_0) dx_0 dy_0$  distributed load

$u_3 = \frac{1-\nu}{4\pi G} \iint_A \frac{P(x_0, y_0) dx_0 dy_0}{\sqrt{(x-x_0)^2 + (y-y_0)^2}}$  very small area

w.d.

Nov. 24, Wed., 2021. Wk 13.

## Introduction to anisotropic Elasticity

Isotropic Elasticity: 2 materials consts

anisotropic:

▷ Worst: 21 materials consts.

$$\text{linear elasticity: } \underline{\Sigma} = \underline{K} \underline{\epsilon} \quad (1)$$

Fourth order tensor

(stiffness tensor).

$$\underline{K} = k_{ijkl} \epsilon_i \epsilon_j \epsilon_k \epsilon_l$$

$$k_{ijkl} = k_{jikl} = k_{ijlk}$$

(due to the symmetry of  
stress & strain tensors).

36 characteristics.

Existence of strain energy density  $W$ :

$$\sigma_{ij} = \frac{\partial W}{\partial \epsilon_{ij}} \quad \underline{K} \text{ has 21 independent consts.}$$

$$\sigma_{ij} \rightarrow \underline{\sigma} = \begin{pmatrix} \sigma_{11} \\ \sigma_{22} \\ \sigma_{33} \\ \sigma_{12} \\ \sigma_{13} \\ \sigma_{23} \end{pmatrix} = \begin{pmatrix} \sigma_1 \\ \sigma_2 \\ \sigma_3 \\ \sigma_4 \\ \sigma_5 \\ \sigma_6 \end{pmatrix}$$

$$\underline{\epsilon} = \epsilon_{ij} \epsilon_i \epsilon_j$$

$$\epsilon_{ij} \rightarrow \underline{\epsilon} = \begin{pmatrix} \epsilon_{11} = \epsilon_1 \\ \epsilon_{22} = \epsilon_2 \\ \epsilon_{33} = \epsilon_3 \\ \epsilon_{12} = \epsilon_4 \\ \epsilon_{13} = \epsilon_5 \\ \epsilon_{23} = \epsilon_6 \end{pmatrix}$$

$$\text{Eq. (1) } \Rightarrow \underline{\sigma} = \underline{K} \underline{\epsilon}$$


$$\underline{K} = \begin{pmatrix} k_{11} & k_{12} & k_{13} & k_{14} & k_{15} & k_{16} \\ k_{21} & k_{22} & k_{23} & k_{24} & k_{25} & k_{26} \\ k_{31} & k_{32} & k_{33} & k_{34} & k_{35} & k_{36} \\ k_{41} & k_{42} & k_{43} & k_{44} & k_{45} & k_{46} \\ k_{51} & k_{52} & k_{53} & k_{54} & k_{55} & k_{56} \\ k_{61} & k_{62} & k_{63} & k_{64} & k_{65} & k_{66} \end{pmatrix}$$

$$\sigma_{ii} = k_{111} \varepsilon_{11} + k_{1112} \varepsilon_{12} + k_{1113} \varepsilon_{13} + k_{1114} \varepsilon_{14} \\ + k_{1122} \varepsilon_{22} + k_{1123} \varepsilon_{23} + k_{1131} \varepsilon_{31} + k_{1132} \varepsilon_{32} \\ + k_{1133} \varepsilon_{33}.$$

$$\sigma_i = k_{11} \varepsilon_1 + k_{16} \varepsilon_6 + k_{15} \varepsilon_5 + k_{14} \varepsilon_4 + k_{12} \varepsilon_2 \\ + k_3 \varepsilon_3 \Rightarrow \underline{\sigma} = K \underline{\varepsilon}.$$

Plane of symmetry: (material).

Anisotropic 2 bases:  $\{e_1, e_2, e_3\} = B_1$ ,  $\{e'_1, e'_2, e'_3\} = B_2$ .



(Reflection).

transform into  $B'$  basis

$$K'_{ijkl} = k_{ijkl}.$$

$$K'_{stu} = k_{ijkl} (e_i \cdot e'_i) (e_j \cdot e'_j) (e_k \cdot e'_k) (e_l \cdot e'_l)$$

$\underbrace{(e_i \cdot e'_i)}_{P_{iu}}$

general transformation formula  
 $P_{lu}$ .

$P$  matrix is simple

$$P = \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & -1 \end{bmatrix}.$$

$$K_{ii} = K_{1111} = k_{ijkl} P_{ii} P_{jj} P_{kk} P_{ll} \\ \downarrow \quad \downarrow \quad \downarrow \quad \downarrow \\ \delta_{ii} \quad \delta_{jj} \quad \delta_{kk} \quad \delta_{ll}$$

(Hypothesis)

$$= k_{1111}$$

$$K'_{2222} = k_{2222} = k_{ijkl} P_{11} P_{22} P_{33} P_{44} = k_{2222}.$$

$$K'_{1122} = k_{ijkl} P_{11} P_{22} P_{33} P_{44} = k_{1122} \\ \downarrow \quad \downarrow \quad \downarrow \quad \downarrow \\ \delta_{11} \quad \delta_{22} \quad \delta_{33} \quad \delta_{44}.$$

In the same way you can show for all.

I already have material plane of symmetry

$$k'_{1123} = k_{ijkl} P_{1i} P_{2j} P_{3k} P_{4l} = -k_{1123}$$

~~$\delta_{11} \delta_{2j}$~~

$\delta_{11} \delta_{2j} \delta_{2k} (-\delta_{3l})$

we know in polar:  $k'_{1123} = k_{1123}$

Hence:  $k_{1123} = -k_{1123}$ .

$\therefore k_{1123} = 0$ .

$k_{14} = 0$ .

$k_{24} = k_{25} = k_{34} = k_{35} = k_{46} = k_{56} = 0$

reduce the num. of const. to 8.

$$\begin{matrix} k_{11} & k_{12} & k_{13} & 0 & 0 & k_{16} \\ k_{21} & k_{22} & k_{23} & 0 & 0 & k_{26} \\ k_{31} & 0 & 0 & k_{36} \\ k_{44} & k_{45} & k_{46} & 0 \\ k_{55} & k_{56} & 0 \\ k_{66} & 0 \end{matrix}$$

13 Material constants.

$$\sigma_1 = k_{11} \epsilon_{11} + k_{12} \epsilon_{21} + k_{13} \epsilon_{31} + k_{16} \epsilon_{61} \quad (3)$$

$$\sigma_2 = k_{12} \epsilon_{12} + k_{22} \epsilon_{22} + k_{23} \epsilon_{32} + k_{26} \epsilon_{62}$$

$$\sigma_3 = k_{13} \epsilon_{13} + k_{23} \epsilon_{23} + k_{33} \epsilon_{33} + k_{36} \epsilon_{63}$$

$$\sigma_4 = k_{44} \epsilon_{44} + k_{45} \epsilon_{45}$$

$$\sigma_5 = k_{54} \epsilon_{54} + k_{55} \epsilon_{55}$$


$$\sigma_6 = k_{61} \epsilon_{61} + k_{62} \epsilon_{62} + k_{63} \epsilon_{63} + k_{66} \epsilon_{66}$$

define a new basis:

$$\underline{e}_1' = -\underline{e}_1$$

$$\underline{e}_2' = \underline{e}_2$$

$$\underline{e}_3' = \underline{e}_3$$



put an additional plane of symmetry.

$$\sigma_{ij} \rightarrow \sigma'_{ij}$$

$$\epsilon_{ij} \rightarrow \epsilon'_{ij}$$

$$\sigma'_4 = \sigma_4 = k_{44} \epsilon'_{22}$$

$$-k_{45} \epsilon'_{35}$$

$$[\sigma'_{ij}] = \begin{bmatrix} \sigma_{11} & -\sigma_{12} & -\sigma_{13} \\ -\sigma_{12} & \sigma_{22} & \sigma_{23} \\ -\sigma_{13} & \sigma_{23} & \sigma_{33} \end{bmatrix}$$

$$\sigma_{46} = k_{44} \epsilon_{22} - k_{45} \epsilon_{35}$$

$$k_{40} = 0 \quad k_{36} = 0$$

$$k_{16} = 0 \quad k_{26} = 0$$

$$K = \begin{bmatrix} k_{11} & k_{12} & k_{13} & 0 & 0 & 0 \\ k_{21} & k_{22} & k_{23} & 0 & 0 & 0 \\ k_{31} & k_{32} & k_{33} & 0 & 0 & 0 \\ k_{41} & k_{42} & k_{43} & 0 & 0 & 0 \\ k_{51} & k_{52} & k_{53} & 0 & 0 & 0 \\ k_{61} & k_{62} & k_{63} & 0 & 0 & 0 \end{bmatrix}$$

HW 11

In torsion rheology test, circular cylinder

$$R, h \quad \gamma(t) = \gamma_0 e^{i\omega t}$$

use cylinder coordinate,

only stress exist:  $\sigma_{\theta z}$ .

Initial condition:  $\epsilon_{ij} = \sigma_{ij} = 0, t=0$ .

boundary condition:

$$\{ u_i : (r, \theta, z=0, t>0) = 0,$$

$$u_r(r, \theta, z=h, t>0) = 0, u_\theta(r, \theta, z=h, t>0) = 0, \\ u_\theta(r \leq R, \theta, z=h, t>0) = rh\gamma = rh\gamma_0 e^{i\omega t}.$$

$$\sigma_{rr}(r=R, \theta, 0 < z < h, t>0) \dots$$

$$= \sigma_{\theta r}(r=R, \theta, 0 < z < h, t>0) = 0.$$

(traction free on side walls).

governing eqs. for torsion:

$$u_r = u_z = 0, u_\theta = \gamma r z.$$

the only non-vanishing strain:  $\epsilon_{\theta\theta} = \frac{\gamma r}{2}$

In cylindrical coor., all equilibrium satisfied!

\* constitutive model: here linear viscoelasticity comes in

$$\sigma_{\theta\theta}(r, t) = 2G(t)\epsilon_{\theta\theta}(r, t=0^+) + 2 \int_0^t G(t-\tau) \frac{d\epsilon_{\theta\theta}(r, \tau)}{d\tau} d\tau$$

$$\rightarrow \sigma_{\theta\theta}(r, t) = G(t)r\delta(t=0^+) + r \int_0^t G(t-\tau) \frac{d\delta(t)}{d\tau} d\tau$$

$$= G(t) \tau_0 + i\omega \int_{0^+}^t G(t-\tau) \frac{d\tau_0 e^{i\omega\tau}}{d\tau} d\tau.$$

$$= \left[ G(t) + i\omega \int_{0^+}^t G(t-\tau) e^{i\omega\tau} d\tau \right] \tau_0 = \varphi(\omega, t) \tau_0.$$

the torque  $M(t)$ :

$$M(t) = 2\pi \int_0^R \overline{G}_B r^3 dr = \pi \tau_0 \varphi(\omega, t) \int_0^R r^3 dr \\ = \frac{\pi \varphi(\omega, t) R^4 \tau_0}{2}.$$

$$1b. \varphi(\omega, t) = G(t) + i\omega \int_{0^+}^t G(t-\tau) e^{i\omega\tau} d\tau.$$

integral term:  $\int_{0^+}^t G(t-\tau) e^{i\omega\tau} d\tau = e^{i\omega t} \int_0^t G(t-\tau) e^{-i\omega(t-\tau)} d\tau$   
as  $t \rightarrow \infty$ ,

$$= e^{i\omega t} \int_0^t G(\eta) e^{-i\omega\eta} d\eta = e^{i\omega t} \left[ \int_0^t [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta \right]$$

$$= e^{-i\omega\eta} d\eta + \int_0^t G_\infty e^{-i\omega\eta} d\eta$$

$$= e^{i\omega t} \left[ \int_0^t [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta \right]$$

$$+ \frac{G_\infty}{-i\omega} e^{-i\omega t} \Big|_0^t$$

$$= e^{i\omega t} \int_0^t [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta + \frac{G_\infty}{i\omega} (e^{i\omega t} - 1)$$

then we have  $\varphi$ :

$$\varphi(\omega, t) = G(t) + i\omega \left[ e^{i\omega t} \int_0^t [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta \right. \\ \left. + \frac{G_\infty}{i\omega} (e^{i\omega t} - 1) \right].$$

$$= (G(t) - G_\infty) + G_\infty e^{i\omega t} + i\omega e^{i\omega t} \int_0^t [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta$$

We already know:

$$\int_0^t [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta$$

$$= \int_0^\infty [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta - \int_t^\infty [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta$$

$$\varphi(\omega, t) = [(G(t) - G_\infty) - i\omega e^{i\omega t} \int_t^\infty [G(\eta) - G_\infty]$$

$$e^{-i\omega\eta} d\eta] + \{G_\infty + i\omega \int_0^\infty [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta\} e^{i\omega t}$$

Since  $G(\eta \rightarrow \infty) - G_\infty = 0$ .

$$\varphi(\omega, t \rightarrow \infty) = \{G_\infty + i\omega \int_0^\infty [G(\eta) - G_\infty] e^{-i\omega\eta} d\eta\} e^{i\omega t}$$

$$= M(\omega) e^{i\omega t}$$

$$M_{ss}(\omega) = \frac{\pi R^4 \tau_0}{2} M(\omega) e^{i\omega t}$$

Assuming  $G(t) = G_{\infty} + \frac{G_0 - G_{\infty}}{(1 + \frac{t}{\tau_p})^n}$ , find storage & loss modulus.

- Storage modulus:

$$n'(w) = \operatorname{Re}[\mu(w)] = \operatorname{Re}\left[G_{\infty} + i\omega \int_0^{\infty} \frac{G_0 - G_{\infty}}{(1 + \eta/\tau_p)^n} e^{-i\omega\eta} d\eta\right]$$

$$= G_{\infty} + (G_0 - G_{\infty})\omega \operatorname{Re}\left[i \int_0^{\infty} (1 + \eta/\tau_p)^{-n} e^{-i\omega\eta} d\eta\right]$$

- Loss modulus:

$$n''(w) = \operatorname{Im}[\mu(w)]$$

$$= (G_0 - G_{\infty})\omega \operatorname{Im}\left[i \int_0^{\infty} (1 + \eta/\tau_p)^{-n} e^{-i\omega\eta} d\eta\right]$$

To evaluate the integrals, let  $\eta/\tau_p = p$ .

so that  $\int_0^{\infty} (1 + \eta/\tau_p)^{-n} e^{-i\omega\eta} d\eta$

$$= \tau_p \int_0^{\infty} (1 + p)^{-n} e^{-i\omega p} dp.$$

For our case,  $n = 1$ .

$$\int_0^{\infty} (1 + p)^{-1} e^{-i\omega p} dp = \int_0^{\infty} (1 + p)^{-1} \cos(\omega p) dp$$

$$- i \int_0^{\infty} (1 + p)^{-1} \sin(\omega p) dp ..$$

$$= \int_0^{\infty} (\omega + p)^{-1} \cos q dq - i \int_0^{\infty} (\omega + q)^{-1} \sin q dp.$$

$$= \{-C_i(\omega) \cos \omega - S_i(\omega) \sin \omega\} - i\{C_i(\omega) \sin \omega - S_i(\omega) \cos \omega\}.$$

$C_i$  &  $S_i$ : sine and cosine integrals.

normalize the storage & loss modulus:

$$\bar{n}'(w) = 1 + \left(\frac{G_0}{G_{\infty}} - 1\right)\omega \operatorname{Re}\left[i \int_0^{\infty} (1 + p)^{-1} e^{-i\omega p} dp\right]$$

$$= 1 + \left(\frac{G_0}{G_{\infty}} - 1\right)\omega \{C_i(\omega) \sin \omega - S_i(\omega) \cos \omega\},$$

$$\bar{n}''(w) = \left(\frac{G_0}{G_{\infty}} - 1\right)\omega \operatorname{Im}\left[i \int_0^{\infty} (1 + p)^{-1} e^{-i\omega p} dp\right]$$

$$= -\left(\frac{G_0}{G_{\infty}} - 1\right)\omega \{C_i(\omega) \cos \omega + S_i(\omega) \sin \omega\}.$$


$$\therefore \tan \delta = \frac{-\left(\frac{G_0}{G_{\infty}} - 1\right)\omega \{C_i(\omega) \cos \omega + S_i(\omega) \sin \omega\}}{1 + \left(\frac{G_0}{G_{\infty}} - 1\right)\omega \{C_i(\omega) \sin \omega - S_i(\omega) \cos \omega\}}$$

Dec. 6., Mon., 2021. We 16.

Orthotropic material. 9 constants.

$$K = \begin{bmatrix} K_{11} & K_{12} & K_{13} & 0 & 0 & 0 \\ K_{21} & K_{22} & K_{23} & 0 & 0 & 0 \\ K_{31} & K_{32} & K_{33} & 0 & 0 & 0 \\ 0 & 0 & 0 & K_{44} & 0 & 0 \\ 0 & 0 & 0 & 0 & K_{55} & 0 \\ 0 & 0 & 0 & 0 & 0 & K_{66} \end{bmatrix}$$

Transversely Isotropic



$$[R] = \begin{bmatrix} \cos\theta & -\sin\theta & 0 \\ \sin\theta & \cos\theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \quad \left\{ \begin{array}{l} e'_1 = \cos\theta e_1 + \sin\theta e_2 \\ e'_2 = -\sin\theta e_1 + \cos\theta e_2 \\ e'_3 = e_3 \end{array} \right.$$

$\begin{array}{c} e_3 \\ e_2 \\ e_1 \end{array}$        $\theta$

$[P] = \begin{bmatrix} \cos\theta & \sin\theta & 0 \\ -\sin\theta & \cos\theta & 0 \\ 0 & 0 & 1 \end{bmatrix}$

standard isotropic material

$$\left\{ \begin{array}{l} \sigma_1 = K_{11}\epsilon_1 + K_{12}\epsilon_2 + K_{13}\epsilon_3 \\ \sigma_2 = K_{21}\epsilon_1 + K_{22}\epsilon_2 + K_{23}\epsilon_3 \\ \sigma_3 = K_{31}\epsilon_1 + K_{32}\epsilon_2 + K_{33}\epsilon_3 \\ \sigma_4 = K_{44}\epsilon_4 \\ \sigma_5 = K_{55}\epsilon_5 \\ \sigma_6 = K_{66}\epsilon_6 \end{array} \right.$$

$$\underline{\sigma}' = \underline{P} \underline{\sigma} \underline{P}^T$$

$$\underline{\epsilon}' = \underline{P} \underline{\epsilon} \underline{P}^T$$

$$\sigma'_1 = \sigma_2, \sigma'_2 = \sigma_1, \sigma'_3 = \sigma_3$$

$$\sigma'_4 = \sigma_5 - \sigma_6, \sigma'_5 = \sigma_4$$

$$\sigma'_6 = -\sigma_6$$

same thing for strain.

$$\sigma'_1 = K_{11}\epsilon'_1 + K_{12}\epsilon'_2 + K_{13}\epsilon'_3$$

$$\rightarrow \sigma'_2 = K_{11}\epsilon'_2 + K_{12}\epsilon'_1 + K_{13}\epsilon'_3$$

$$\sigma'_2 = K_{21}\epsilon'_1 + K_{22}\epsilon'_2 + K_{23}\epsilon'_3$$

$$\sigma'_3 = K_{31}\epsilon'_1 + K_{32}\epsilon'_2 + K_{33}\epsilon'_3$$

$$\sigma'_4 = K_{44}\epsilon'_4 + K_{55}\epsilon'_5 + K_{66}\epsilon'_6$$

$$\sigma_1 = k_{11}\varepsilon_1 + k_{21}\varepsilon_2 + k_{31}\varepsilon_3$$

$$k_{12}\varepsilon_2 + k_{22}\varepsilon_1 = k_{12}\varepsilon_1 + k_{22}\varepsilon_2.$$

$$k_{11}\varepsilon_2 = k_{22}\varepsilon_1.$$

$$k_{11}\varepsilon_2 + k_{13}\varepsilon_3 = k_{22}\varepsilon_2 + k_{23}\varepsilon_3.$$

$$(k_{11} - k_{22})\varepsilon_2 + (k_{13} - k_{23})\varepsilon_3 = 0.$$

$$k_{11} = k_{22}$$

$$k_{13} = k_{23}.$$

$$\sigma_4 = k_{44}\varepsilon_4.$$

$$\sigma_5' = k_{55}\varepsilon_5'.$$

$$\sigma_4' = -\sigma_5 = -k_{44}\varepsilon_5'.$$

$$\sigma_5 = k_{44}\varepsilon_5'$$

$$k_{44} = k_{55}$$

$$k_{44} = k_{55} \Rightarrow k_{11} = k_{22}, \\ k_{13} = k_{23}.$$

$$\begin{bmatrix} k_{11} & k_{12} & k_{13} & 0 & 0 & 0 \\ k_{11} & k_{13} & 0 & 0 & 0 & 0 \\ k_{21} & 0 & k_{23} & 0 & 0 & 0 \\ 0 & 0 & 0 & k_{44} & 0 & 0 \\ 0 & 0 & 0 & 0 & k_{55} & 0 \\ 0 & 0 & 0 & 0 & 0 & k_{66} \end{bmatrix}$$

$$\theta = 45^\circ \rightarrow \pi/4.$$

$$[P] = \begin{pmatrix} \frac{1}{\sqrt{2}} & \frac{1}{\sqrt{2}} & 0 \\ -\frac{1}{\sqrt{2}} & \frac{1}{\sqrt{2}} & 0 \\ 0 & 0 & 1 \end{pmatrix}$$

$$\varepsilon_{12}', \varepsilon_{12}'$$

$$k_{66} = \frac{1}{2}(k_{11} - k_{22}).$$

$$\frac{1}{2}[k_{11} - k_{22}]$$

$$k^{-1} \cdot \Omega = \underline{\varepsilon}$$

S matrix compliance index

Poisson's ratio for anisotropic elastic material.  
Can leave no bounds. Tug, TCT.


## Linear Viscoelasticity

Correspondence Principle

↳ stress dependent of underlying

$$\epsilon_{ij} = \sigma_{ij}(0^+) C_1(t) + \int_{0^+}^t C_1(t-\tau) \cdot \frac{\partial \sigma_{ij}}{\partial \tau} d\tau.$$

$$\sigma_{kk} = \sigma_{kk}(0^+) \cdot C_2(t) + \int_{0^+}^t C_2(t-\tau) \cdot \frac{\partial \sigma_{kk}}{\partial \tau} d\tau.$$




Creep modulus.

$$P_\infty(t) =$$

remote hydrostatic tension.

$$P_\infty(t=0) = 0$$

Elastic problem:



$$\sigma_{rr} = \frac{A}{r^2} + P_\infty$$

$$\sigma_{\theta\theta} = -\frac{A}{r^2} + P_\infty$$

$$\sigma_{r\theta} = 0$$

$r > A$

$$\sigma_{rr} = \sigma_{\theta\theta} = \sigma_{in}$$

$r < A$

Continuity of traction.

$$\frac{A}{r^2} + P_\infty = \sigma_{in}$$

$A, P_\infty \rightarrow \text{unknown}$

$$2G_{out} \epsilon_{00} = \sigma_{00} - \frac{1}{2} \sigma_{rr}, \quad r > a.$$

$$(r > a) \quad \epsilon_{00} = \frac{1}{3G_{out}} \left[ \frac{-3A}{2r^2} + \frac{P_\infty}{r} \right].$$

$$\epsilon_{00} = \frac{u}{r}$$

$$r < a, \quad \epsilon_{in} = \epsilon_{00} = \epsilon_{in} = \frac{u}{r}.$$

$$u = \epsilon_{in} r$$

$$3G_{in} \epsilon_{in} = \sigma_{00} - \frac{1}{2} \sigma_{rr}, \\ = \sigma_{in}/2.$$

$$\therefore \dot{\epsilon}_{in} = \frac{\sigma_{in}}{6G_{in}} = \frac{u}{r}$$

continuity of Hooke's strain.

$$\frac{1}{2G_{out}} \left[ \frac{-3A}{2a^2} + \frac{P_\infty}{r} \right] = \frac{\sigma_{in}}{6G_{in}}$$

$$\frac{A}{a^2} = \frac{(p-1)P_\infty}{(1+3p)}, \quad p = \frac{G_{in}}{G_{out}}$$

$$\dot{\epsilon}_{in} = \frac{4p}{1+3p} P_\infty$$

$$\frac{G_{in}}{G_\infty} \rightarrow \infty \Rightarrow \underbrace{\frac{A}{a^2}}_{\sim} = \frac{1}{3} P_\infty$$

$$\sigma_{in} (r = a+) = -\frac{2}{3} P_\infty$$

$$G_{in} = \frac{1}{r} s \tilde{Y}_{in}(s)$$

$$G_{out} = \frac{1}{r} s \tilde{Y}_{out}(s)$$

$$\tilde{\sigma}_{in} = \frac{4 \frac{\tilde{Y}_{in}(s)}{\tilde{Y}_{out}(s)}}{1 + 3 \frac{\tilde{Y}_{in}(s)}{\tilde{Y}_{out}(s)}} \tilde{P}_\infty(s)$$

$$Y_{in}(t) = Y_{in,\infty} + (Y_{in,\infty} - Y_{in,0}) e^{-t/t_{in}}$$

$$L(Y_{in}(t)) = \tilde{Y}_{in}(s) = \int_0^\infty e^{-st} Y_{in}(t) dt$$

$$\tilde{Y}_{in}(s) = \frac{Y_{in,\infty}}{s} + \frac{(Y_{in,0} - Y_{in,\infty})}{s + t/t_{in}}$$

$$\tilde{Y}_{out}(s) = \frac{Y_{out,\infty}}{s} + \frac{(Y_{out,0} - Y_{out,\infty})}{s + t/t_{out}}$$

$$\tilde{\sigma}_{in}(t) = \frac{1}{2\pi i} \int_{\delta-i\infty}^{\delta+i\infty} e^{st} \tilde{\sigma}_\infty(t) ds$$

\* Solve ODE with MATLAB.

HW 10. Review:

a. Problem formulation:

$$\nabla^2 \phi = 0, \text{ in } |x| < \frac{a}{2} \text{ & } |y| < \frac{b}{2}.$$

BCs:

$$\phi(x = \pm \frac{a}{2}, |y| < \frac{b}{2}) = \frac{1}{2} \left( \frac{a^2}{4} + y^2 \right).$$

$$\phi(|x| < \frac{a}{2}, y = \pm \frac{b}{2}) = \frac{1}{2} \left( \frac{b^2}{4} + x^2 \right)$$

b.  $f = \nabla_{xx} \phi + 1$ .

on the boundary  $y = \pm \frac{b}{2}$ ,

$$\Rightarrow f(|x| < \frac{a}{2}, y = \pm \frac{b}{2}) = 2.$$

on the boundary  $x = \pm \frac{a}{2}$ .

we know  $\partial_{xx} \phi = -\partial_{yy} \phi$ .

$$\Rightarrow f(x = \pm \frac{a}{2}, |y| < \frac{b}{2}) = 0.$$

c. find  $f$ :

$$f(x, y) = X(x) Y(y)$$

Substitute into  $\nabla^2 f = 0$ :

$$\ddot{X}(x) Y(y) + X(x) \ddot{Y}(y) = 0.$$

$$\Rightarrow \frac{\ddot{X}(x)}{X(x)} = -\frac{\ddot{Y}(y)}{Y(y)} = C = -k^2$$

we look for solution: satisfy  $x = \pm \frac{a}{2}$ .

$$\begin{cases} \ddot{X}(x) + k^2 X(x) = 0 \\ \ddot{Y}(y) - k^2 Y(y) = 0 \end{cases}$$

$$\begin{cases} X(x) = B \sin kx + A \cos kx \xrightarrow{x = \pm \frac{a}{2}, X=0} \\ Y(y) = C \cosh ky + D \sinh ky. \end{cases}$$

$$f(x, y) = \sum a_n \cos(k_n x) \cosh(k_n y).$$

$$\text{BCs: } \int (x < \frac{a}{2}, y = \pm \frac{b}{2}) = 2.$$

$$\sum a_n \cos(k_n x) \cosh(k_n b/2) = 2.$$

Method of Fourier series:

$$a_n = \frac{2}{a \cosh(k_n b/2)} \int_{-a/2}^{a/2} 2 \cos(k_n x) dx$$

$$= \frac{8(-1)^n}{\pi(2n+1) \cosh(kab/\nu)}$$

Thus:

$$f(x,y) = \frac{8}{\pi} \sum_{n=0}^{\infty} \frac{(-1)^n}{2n+1} \cdot \frac{\cosh(k_n y)}{\cosh(kab/\nu)} \cos(k_n x),$$

$$k_n = \frac{2n+1}{a}\pi$$

d: find max stress:

Shear stresses:

$$\sigma_{13} = G\gamma(-y + \phi_{21})$$

$$\tau_{13} = G\gamma(y - \phi_{21})$$

$$\frac{\sigma_{13}}{G\gamma} + y = \phi_{21}$$

$$-\frac{\tau_{13}}{G\gamma} + x = \phi_{21}$$

on the boundary  $x = \pm \frac{a}{2}$ ,  $\phi_{21} \Big|_{x=\pm \frac{a}{2}} = y$ .

$$\sigma_{13} = 0 \text{ on } x = \pm \frac{a}{2}.$$

$$\tau_{13} = 0 \text{ on } y = \pm \frac{b}{2}.$$

$$\phi_{21} \Big|_{y=\pm \frac{b}{2}} = x.$$