

F4

USER GUIDE



TRIPLE SCREEN

LAPTOP SCREEN EXTENDER

Warm tips:

1. Please ensure Type-c data wire is connected well with device interface.
2. This product supports whole function of Type-c (charging and video), integrated one line. If screen cannot be powered on or restarted, please supply external power of 5V, 3A.
3. The PD interface used to connect the product must use the HDMI TO TYPE-C data cable in the package and be externally powered.

Windows

Mac

Android

Product Introduction

The F4 is a magnetic, multi-function, plug-and-play dual-screen laptop monitor. The product features a portable foldable design, allowing you to quickly set up a personal mobile workstation. It provides laptop users with the perfect multi-screen mirroring and multi-screen independent display solution, boosting work efficiency by up to 50% and enabling efficient multitasking. It supports screen mirroring with select Samsung, Huawei, and other branded smartphones, while also being compatible with smartphone system modes and equipped with audio and video transmission capabilities.

The F4 bracket is easy to use — simply secure the bracket to the top of your laptop screen for a quick, secure installation. Attach the left and right screens magnetically into the bracket and you're ready to go. It supports laptops from 13-inch to 17.3-inch and can be detached for single-screen use. The screens feature an independent stand structure with adjustable angles, providing a versatile user experience for professionals, office workers, gamers, stock traders, entrepreneurs, programmers, and students.

The F4 screens allow independent adjustment of parameters such as brightness, volume, and contrast. Equipped with a Type-C interface, flexible video and data transmission is possible without the need for an external docking station. As long as your laptop has a Type-C port that supports both signal and power delivery, seamless connection and display are achieved. Desktop computers, laptops, mini PCs, set-top boxes, and gaming consoles with HDMI output ports can all connect directly to the monitor. However, the screen requires external power to turn on (use a dedicated HDMI to Type-C cable to connect your device to the monitor).

Finally, the F4 screen splitter offers a full 235° rotation on a single screen, allowing you to choose the optimal viewing angle for the best visual experience.

Contents of Instruction

Product Attributes

1. Product host	1
2. Accessories	1
3. Parameters	1

Installation and Storage

1. Stand Installation	2
2. Screen Installation	2
3. Single Screen Stand Installation	3
4. Multiple Combinations of Screens and Stands	3
5. Storage	4

Key Definitions	5
-----------------------	---

Connection Mode

1. Connect F4 with Laptop	6
2. Single Screen Bracket Connection Setup	7
3. Device power supply connection mode	8

Audio Settings

1. Change sound settings of Windows 10 / Windows 11	8
2. Change sound settings of MAC OS PC	9


Display Mode

1. Windows 10 / Windows 11 Display Settings	10
2. MacOS 13 Ventura Display Settings	11


Transportation, Storage and Safety Information	12
--	----

Product Attributes

1. Product host



2. Accessories




3. Parameters

Weight:	1.61 Kg	Screen Size:	15.6 Inches
Aspect Ratio:	16:9	Panel Type:	IPS Wide Viewing Angle
Size:	359.7×222.5×45.6 MM	Average Brightness:	300CD/M ²
Refresh Rate:	60Hz	Type-C Input:	5V-20V / 5A Max
Resolution:	1920x1080 P	Type-C Output:	5V-20V / 4 Max
Speaker:	1	Ports:	TYPE-C*2+TYPE-C (PD Power Supply)


Installation and Storage

1. Stand Installation



Step1: Separate the screen from the stand.



Step2: Expand the stand.



2. Screen Installation




1. First open the support rod, and then stretch the support to the appropriate size;
2. The support rod only supports clockwise rotation of 90 degrees;
3. The maximum opening angle of the support rod is 90 degrees, and excessive folding will damage the support rod.

*Note:Open the stand, adjust it to the appropriate supporting angle, place it Above the computer screen,and complete the installation of the dual-screen support.

3. Single Screen Stand Installation

Install the single screen stand.




The single screen stand supports 180° rotation.



4. Multiple Combinations of Screens and Stands

Supports 90° rotation.


Supports 90° rotation.



When rotating the screen, the screen and the stand must be parallel to avoid scratching.



Landscape Display



Portrait Display




Portrait & Landscape Display




Detached Display

5. Storage

Step1: Remove the left and right screens.




Step2: Fold up the stand.



Step3: Combined storage the screen and stand

Note: Align the boss (protrusion) on the right screen with the boss on the left screen for combined storage.

*Note: The right screen's silicone should align with the left screen's limit hole for combined storage.



Note: For a better user experience, when inserting into the leather case, align the screen boss with the recessed hole in the case before inserting.

Key Definitions

Menu/Selection/Confirmation Button
Press and hold for 2 seconds to return
Press and hold for 3 seconds to shut down



Toggle left "Plus"
Volume Adjustment

Toggle right "Minus"
Backlight Adjustment



Menu/Selection/Confirmation Button
Press and hold for 2 seconds to return
Press and hold for 3 seconds to shut down.



Toggle right "Minus"
Backlight Adjustment

Toggle left "Plus"
Volume Adjustment



Connection Mode

1. Connect F4 with Laptop


To start, determine how many video output ports your laptop has. It is important to note that only Full-featured USB Type-C and HDMI ports are compatible with this setup. Full-featured Type-C ports can transfer power, video, and data simultaneously. Below are the available options based on your laptop's ports:

Two Full-Featured Type-C Connection:

Please note that two USB-C to USB-C cables will be required.




Hoe type terminal head, connected in the direction shown in the figure.



- Note:
1. If the product does not function properly or the brightness is insufficient during use, please connect a 5V/3A or higher adapter to the power supply interface of the product.
 2. The included adapter is only suitable for powering this product. Please do not use it to power other devices.
 3. If you need to power your laptop through the F4 screen extender during use, please connect an external PD 65W or higher power adapter to the screen extender's power port and connect it to the Type-C port of your laptop using a USB-C to USB-C cable.

1.1 One Full-Featured Type-C and One HDMI Connection:

Please note that you will need one USB-C to USB-C cable and one HDMI cable.





- Note:
1. The included adapter is only suitable for powering this product. Please do not use it to power other devices.
 2. If the product does not function properly or the brightness is insufficient during use, please connect a 5V/3A or higher adapter to the power supply interface of the product.

Connection Mode

2. Single Screen Bracket Connection Setup

TYPE-C Connection:


If your laptop has one full-functioned Type-C port, you can use one USB-C to USB-C cable to connect the product to your laptop. Please connect the USB-C cable to the screen extender's port with TYPE-C1 or TYPE-C2 marked.



If power supply to the computer via the screen splitter is required, use a TYPE-C cable to connect the screen splitter to the computer. Meanwhile, the screen splitter must be connected to an external PD adapter with a power rating of 65W or higher, and the computer's TYPE-C port must support PD protocol for charging.

USB and HDMI port Connection:

If your laptop has one USB-A or USB-C port and one HDMI port, please use two cables (one HDMI to MINI HDMI cable + one USB-A or USB-C to USB-C cable) to connect the screen.




Note:

1. The HDMI-to-MINI HDMI cable must be connected to the MINI HDMI port of the video screen extender. Please connect the USB-C cable to the screen extender's port with TYPE-C1 or TYPE-C2 marked.
2. If the display has no signal or the signal is unstable after connection, please connect an external 5V/2A power adapter to power the screen extender.

Connection Mode

3. Connect F4 with Mobile Phone with Other Devices




Note: When connecting to the Nintendo Switch, a PD power supply must be used to power the device for proper video output

Audio Settings

1. Change sound settings of Windows 10 / Windows 11

1.1 Right click the loudspeaker icon located in the bottom-right corner.



1.2 Select "switch on sound " in pop-up dialog box

1.3 Left click "turn on sound settings" and pop-up the box as provided, here users can set about sound

Here users can set about sound

1. Master volume;
2. Select output device: [F4 / Speaker];
3. Device attributes.




Audio Settings

2. Change sound settings of MAC OS PC

2.1. Choose Apple menu > System Settings



2.2. Click "Output", then select the device you want use for the list of sound output devices: [F4 / Speaker]




Display Mode

1. Windows 10 / Windows 11 Display Settings

1.1 Right-click a blank area of the desktop. Select 'Display Settings' from the pop-up dialogue box.

Left click "Display Settings" to open the settings dialogue box, shown in the figure:



1.2 Under the "Rearrange displays" section, drag and drop each display to rearrange them according to their physical layout of your desktop. Scroll down to the bottom of the page to further configure the display for extended or mirrored mode.

NOTE: When installing vertically, the display direction needs to be rotated (right screen 270°, left screen 90°) in the computer display settings.

2. MacOS 13 Ventura Display Settings

2.1 Enter the "System Preferences" menu



2.2 Configure your monitor

In this menu, you can set the resolution and mirror/extend the display you want.



2.3 Arrange Displays

- To rearrange displays, drag them to the desired position.
- To mirror displays, hold Option key while dragging them on top of each other.
- To relocate the menu bar, drag it to a different display.



Transportation, Storage And Safety Information

To ensure the safe and proper usage of this product and to prevent potential accidents such as electric shock or fire, it is essential to thoroughly read and comprehend all usage requirements and operational procedures before utilizing it. Kindly adhere strictly to the following guidelines:

1. Before use, kindly remove the protective film covering the screen surface.
2. The DC power supply required for this product is an AC/DC power adapter. Ensure it is positioned far away from heat sources and placed in a well-ventilated area. The AC power socket and AC power line must be properly grounded and capable of handling the necessary current demand.
3. The DC power input required for this product is 5V-20V±2V.
4. Take care to prevent excessive humidity and dust accumulation to avoid circuit corrosion and potential failures.
5. Avoid subjecting the screen to external forces.
6. Refrain from using sharp tools that may damage the screen.
7. This product is suitable for general business and domestic use, with a recommended ambient temperature ranging from -20°C to 60°C.
8. Remember to power off the device when not in use.

