

Z3 USER'S GUIDE



LAPTOP SCREEN EXTENDER

Warm tips:

1. Please ensure type-c data wire is connected well with device interface.
2. Before using the product, please install the appropriate driver according to your computer's operating system version.
3. When using the product, you must connect a PD adapter of 30W or higher for power supply otherwise, the product will not function properly.

Windows

Mac

Android

Product Introduction

The Z3 is a foldable triple-screen workstation featuring an innovative structure, foldability, large size, compact storage, and suitability for multiple scenarios and applications. It supports three-screen expansion and various usage scenarios, helping you quickly set up a personal mobile studio. It offers a perfect solution for laptop users, enabling multi-screen synchronization and multi-screen extended display, with work efficiency potentially increased by up to 150%, and supports efficient multitasking. It also supports computer mode and audio/video transmission with certain smartphones from brands like Samsung and Huawei, as well as the use of computer mode on smart devices.

The Z3 stand is easy to use—simply unfold the stand in sequence, install the support rod, and adjust to the desired angle to start using. It supports laptops, desktop computers, mini PCs, gaming consoles, and more. It is suitable for various environments, providing a tailored experience for professionals, office workers, gamers, stock traders, entrepreneurs, programmers, and students.

The Z3 screens allow adjustment of brightness, volume, contrast, and other settings. It features full-function Type-C and PD power interfaces, supporting versatile video and data expansion without the need for a docking station. Devices with Type-C, HDMI, or USB-A ports are supported (driver installation required). Note: The screens require an external power supply to operate.

Finally, the left and right screens of the Z3 support 360-degree rotation, and both the stand and screens support multi-angle adjustment, allowing users to freely adjust to their preferred viewing angle for the best visual experience.

Contents of Instruction

Product Attributes

1. Product host	1
2. Accessories	1
3. Parameters	1

Installation and Storage

1. Installation and Storage	2
2. Adjust the kickstand	3
3. Closing Sequence	4

Key Definitions	5
-----------------	---

Driver Installation	6
---------------------	---

Connection

1. Connect Z3 with Laptop	6
---------------------------	---

Audio Settings

1. Change sound settings of Windows 10 / Windows 11	8
2. Change sound settings of MAC OS PC	9


Display Mode

1. Windows 10 / Windows 11 Display Settings and Configuration	10
2. macOS Ventura 13 Display Settings and Configuration	11

Transportation, Storage and Safety Information	12
--	----

Product Attributes

1. Product host




Note: The external adapter power supply must be connected to the product's PD interface.


2. Accessories




Monitor



USB-A to USB-C



USB-C to USB-C



HDMI to MINI HDMI



Power Adapter




USB Flash Disk

3. Parameters


Weight:	3.5 Kg	Screen Size:	15.3 Inches
Aspect Ratio:	16:10	Panel Type:	IPS Wide Viewing Angle
Size:	358.7×303.4×47.9mm	Average Brightness:	300cd/m ²
Refresh Rate:	60Hz	Type-C Input:	5V-20V / 5A Max
Resolution:	1920×1200	Type-C Output:	5V-20V / 3.5A Max
Speaker:	1	Ports:	Type-C×2+MINI HDMI

Installation and Storage


1. Expand the monitor




Step 1: Open the storage clasp.




Step 2: Open the screen assembly and bracket assembly.



Step 3: Open the base.



Step 4: Open the support rod and adjust to the desired angle.




Step 5: Open the left and right screens and adjust to the desired angle.




Installation and Storage

2. Adjust the kickstand




1. When adjusting the screen angle, ensure the angle between the stand and screen is properly aligned to maintain stable balance.
2. The stand supports three-level adjustment.
3. During installation, ensure the stand is securely fastened to the base unit to prevent tipping.
4. Hold the base with your right hand and slide the screen assembly to the left to deploy the support stand.



1. When adjusting the screen angle, manipulate the bottom-left and top-right corners of the center screen to prevent display damage.
2. After each screen angle adjustment, verify that the support rod is properly engaged to prevent collapse.
3. When storing the product, place it with the silicone surface facing downward to avoid scratches.

Usage scenarios

Scenario 1



Landscape Display Mode

Scenario 2




Dual-screen mode


The Z3 supports one-click shutdown of the middle screen, which not only reduces power consumption by 30% but also allows the device to be folded backward and placed behind the computer monitor, instantly transforming it into a dual-screen splitter. This multi-functional feature adapts to different work scenarios. For a better user experience, you need to set the horizontal folding option in the display settings.

Installation and Storage


3. Closing Sequence




1. Fold the screen inward in sequence;




2. Hold the base with your right hand and slide the screen assembly to the left to unfold the support bracket. To store the bracket;



3. Fold the base inward toward the center;



4. Store the screen assembly and the bracket assembly;



5. Close the latch;

*NOTE:

1. Please follow the sequence of opening and closing to avoid damage.
2. When storing the product, the latch must be securely locked before carrying it by hand; otherwise, there is a risk of the screen detaching and breaking.


Key Definitions

1. Menu Key / Plus Key / Minus Key Usage:

1. Press the middle button to enter the settings menu.
2. In the settings menu, press the button upward to move up, downward to move down. Press the middle button to confirm selection.
3. Press the button upward to increase parameter values, downward to decrease parameter values, then press the middle button to confirm. The same method applies to adjusting other parameters.
4. Press the middle button for 2 seconds to return to the previous menu.



Menu/Selection/Confirmation Button
Press and hold for 2 seconds to return.



Toggle upward "Plus"
Volume Adjustment
Toggle downward "Minus"
Backlight Adjustment

2. POWER Key Usage



1. Press the button for 1 seconds to turn off the middle screen.
2. Press the button for 1 seconds to turn on the middle screen.

turn off the middle screen

Driver Installation

1.Driver Installation for Computers



Note: When connected, your laptop will automatically install the necessary drivers. To manually install, run the **(SMIUSBdisplaysW.exe)** file located in the USB Flash Disk drive. For MacOS Systems, install the appropriate **(InstantView.exe)** driver and follow the on-screen instructions.

Connection Mode

1. Connect Z3 with Laptop


Note: The external adapter power supply must be connected to the product's PD interface.

TYPE-C Connection:

If your laptop has a full-featured Type-C port, use a USB-C to USB-C cable to connect the device to the laptop. Simultaneously, power the device via the included PD adapter and USB-C to USB-C charging cable.




Full-Featured USB-C



Connection Mode


USB-A+HDMI Port Connection:

If your laptop has USB-A+HDMI ports, you can directly connect the Z3 to the laptop's USB-A and HDMI ports using a USB-A to USB-C and HDMI to MINI HDMI cable. Please connect the external adapter to the product's PD interface via USB-C to USB-C for power supply the adapter is included in the package.




HDMI Port Connection:

If your laptop has an HDMI port, connect the screen using an HDMI-to-Mini HDMI cable. Simultaneously, power the device via the included PD adapter and USB-C to USB-C charging cable.



USB-A Port Connection:

If your laptop has a USB-A port, you can directly connect the Z3 to the laptop's USB-A port with a USB-A TO USB-C cable. please connect an external adapter to the product's PD interface for power supply. The adapter is included in the package.



Audio Settings

1. Change sound settings of Windows 10 / Windows 11

1.1 Right click the Loudspeaker icon located in the bottom-right corner;




1.2 Select "switch on sound" in pop-up dialog box;

1.3 Left click "turn on sound settings" and pop-up the box as provided, Here users can set about sound.

Here users can set about sound

1. Master volume;
2. Select output device: { Z3 / Speaker };
3. Device attributes.



Audio Settings


2. Change sound settings of MAC OS PC

2.1. Choose Apple menu > System Settings



2.2. Click on "Output", and then choose the desired device from the list of available sound output options.

Output devices: { Z3 / Speaker }



Display Mode


1. Windows 10 / Windows 11 Display Settings

1.1 Right-click a blank area of the desktop. Select 'Display Settings' from the pop-up dialogue box.

Left-click "Display Settings" to open the settings dialogue box, as shown.

1.2 Under the "Rearrange your displays" section, drag and drop each display to rearrange them according to their physical layout of your desktop. Scroll down to the bottom of the page to further configure the display for extended or mirrored mode.

1.3 Under the extended mode, drag the files, video or others from your laptop and move right to the screen extender; or drag the file or video you need from the screen extender and move left back to your laptop.



Display Mode

2. macOS Ventura 13 Display Settings

2.1 Enter the "System Preferences" menu



2.2 Configure your monitor

In this menu, you can set the resolution and mirror / extend the display as you want.




2.3 Arrange Displays

To rearrange displays, drag them to the desired position.

To mirror displays, hold Option key while dragging them on top of each other.

To relocate the menu bar, drag it to a different display.



Transportation, Storage and Safety Information

To ensure the safe and proper use of this product and to prevent potential accidents such as electric shock or fire, please carefully read and understand all usage requirements and operational procedures before using. Adhere strictly to the following guidelines:

1. Before use, remove the protective film from the screen surface.
2. This product requires a DC power supply through an AC/DC power adapter. Ensure that the adapter is placed away from heat sources in a well-ventilated location. The AC power socket and AC power line should be adequately grounded to handle the current demands.
3. The power requirement for this product is PD30W or higher.
4. Take precautions to prevent excessive humidity and dust accumulation, as they can lead to circuit corrosion and malfunction.
5. Avoid subjecting the screen surface to external forces or impacts.
6. Do not use sharp tools that may damage the screen surface.
7. This product is suitable for general business and domestic use, and it is recommended to operate it within an ambient temperature range of -20°C to 60°C.
8. Remember to power off the device by disconnecting the power source when not in use.

