

DE1-SoC Computer System with Nios II

For Quartus Prime 17.0

1 Introduction

This document describes a computer system that can be implemented on the Intel DE1-SoC development and education board. This system, called the *DE1-SoC Computer*, is intended for use in experiments on computer organization and embedded systems.

To support such experiments, the system contains embedded processors, memory, audio and video devices, and some simple I/O peripherals. The FPGA programming file that implements this system, as well as its design source files, can be obtained from the University Program section of Intel's web site.

2 DE1-SoC Computer Contents

A block diagram of the DE1-SoC Computer system is shown in Figure 1. As indicated in the figure, the components in this system are implemented utilizing both the FPGA and the *Hard Processor System* (HPS) inside Intel's Cyclone® V SoC chip. The FPGA implements two Nios II processors and several peripheral ports: memory, timer modules, audio-in/out, video-in/out, PS/2, analog-to-digital, infrared receive/transmit, and parallel ports connected to switches and lights. The HPS comprises an ARM Cortex A9 dual-core processor and a set of peripheral devices. Instructions for using the HPS and ARM processor are provided in a separate document, called *DE1-SoC Computer System with ARM Cortex-A9*.

2.1 Nios II Processor

The Intel Nios®II processor is a 32-bit CPU that can be implemented in an Intel FPGA device. Two versions of the Nios II processor are available, designated economy (/e) and fast (/f). The DE1-SoC Computer includes two instances of the Nios II/f version, configured with floating-point hardware support.

An overview of the Nios II processor can be found in the document *Introduction to the Intel Nios II Processor*, which is provided in the University Program's web site. An easy way to begin working with the DE1-SoC Computer and the Nios II processor is to make use of a utility called the *Intel FPGA Monitor Program*. It provides an easy way to assemble/compile Nios II programs written in either assembly language or the C language. The Monitor Program, which can be downloaded from Intel's web site, is an application program that runs on the host computer connected to the DE1-SoC board. The Monitor Program can be used to control the execution of code on Nios II, list (and edit) the contents of processor registers, display/edit the contents of memory on the DE1-SoC board, and similar operations. The Monitor Program includes the DE1-SoC Computer as a predesigned system that can be downloaded onto the DE1-SoC board, as well as several sample programs in assembly language and C that show how to use the DE1-SoC Computer's peripherals. Some images that show how the DE1-SoC Computer is integrated with the




Figure 1. Block diagram of the DE1-SoC Computer.

Monitor Program are described in Section 8. An overview of the Monitor Program is available in the document *Intel FPGA Monitor Program Tutorial*, which is provided in the University Program web site.

All of the I/O peripherals in the DE1-SoC Computer are accessible by the processor as memory mapped devices, using the address ranges that are given in the following subsections.

2.2 Memory Components

The DE1-SoC Computer has DDR3 and SDRAM ports, as well as two memory modules implemented using the on-chip memory inside the FPGA. These memories are described below.

2.2.1 SDRAM

An SDRAM Controller in the FPGA provides an interface to the 64 MB synchronous dynamic RAM (SDRAM) on the DE1-SoC board, which is organized as 32M x 16 bits. It is accessible by the Nios II processor using word (32-bit), halfword (16-bit), or byte operations, and is mapped to the address space 0x00000000 to 0x03FFFFFF.

2.2.2 DDR3 Memory

The DE1-SoC Computer includes a 1 GB DDR3 memory that is connected to the HPS part of the Cyclone[®] V SoCchip. The memory is organized as 256M x 32-bits, and is accessible using word accesses (32 bits), halfwords, and bytes. The Nios II processor can access the DDR3 memory through the FPGA bridge, using the addresses space 0x40000000 to 0x7FFFFFFF.

2.2.3 On-Chip Memory

The DE1-SoC Computer includes a 256 KB memory that is implemented inside the FPGA. This memory is organized as 64K x 32 bits, and spans addresses in the range 0x08000000 to 0x0803FFFF. The memory is used as a pixel buffer for the video-out and video-in ports.

2.2.4 On-Chip Memory Character Buffer

The DE1-SoC Computer includes an 8 KB memory implemented inside the FPGA that is used as a character buffer for the video-out port, which is described in Section 4.2. The character buffer memory is organized as 8K x 8 bits, and spans the address range 0x09000000 to 0x09001FFF.

2.3 Parallel Ports

There are several parallel ports implemented in the FPGA that support input, output, and bidirectional transfers of data between the Nios II processor and I/O peripherals. As illustrated in Figure 2, each parallel port is assigned a *Base* address and contains up to four 32-bit registers. Ports that have output capability include a writable *Data* register, and ports with input capability have a readable *Data* register. Bidirectional parallel ports also include a *Direction* register that has the same bit-width as the *Data* register. Each bit in the *Data* register can be configured as an input by setting the corresponding bit in the *Direction* register to 0, or as an output by setting this bit position to 1. The *Direction* register is assigned the address *Base* + 4.




Figure 2. Parallel port registers in the DE1-SoC Computer.

Some of the parallel ports in the DE1-SoC Computer have registers at addresses *Base* + 8 and *Base* + C, as indicated in Figure 2. These registers are discussed in Section 3.

2.3.1 Red LED Parallel Port

The red lights $LEDR_{9-0}$ on the DE1-SoC board are driven by an output parallel port, as illustrated in Figure 3. The port contains a 10-bit Data register, which has the address 0xFF200000. This register can be written or read by the processor using word accesses, and the upper bits not used in the registers are ignored.




Figure 3. Output parallel port for *LEDR*.

2.3.2 7-Segment Displays Parallel Port

There are two parallel ports connected to the 7-segment displays on the DE1-SoC board, each of which comprises a 32-bit write-only *Data* register. As indicated in Figure 4, the register at address 0xFF200020 drives digits *HEX3* to *HEX0*, and the register at address 0xFF200030 drives digits *HEX5* and *HEX4*. Data can be written into these two registers, and read back, by using word operations. This data directly controls the segments of each display, according to the bit locations given in Figure 4. The locations of segments 6 to 0 in each seven-segment display on the DE1-SoC board is illustrated on the right side of the figure.




Figure 4. Bit locations for the 7-segment displays parallel ports.

2.3.3 Slider Switch Parallel Port

The SW_{9-0} slider switches on the DE1-SoC board are connected to an input parallel port. As illustrated in Figure 5, this port comprises a 10-bit read-only *Data* register, which is mapped to address 0xFF200040.




Figure 5. Data register in the slider switch parallel port.

2.3.4 Pushbutton Key Parallel Port

The parallel port connected to the KEY_{3-0} pushbutton switches on the DE1-SoC board comprises three 4-bit registers, as shown in Figure 6. These registers have the base address 0xFF200050 and can be accessed using word operations. The read-only *Data* register provides the values of the switches KEY_{3-0} . The other two registers shown in Figure 6, at addresses 0xFF200058 and 0xFF20005C, are discussed in Section 3.




Figure 6. Registers used in the pushbutton parallel port.

2.3.5 Expansion Parallel Port

The DE1-SoC Computer includes two bidirectional parallel ports that are connected to the JP1 and JP2 40-pin headers on the DE1-SoC board. These parallel ports include the four 32-bit registers that were described previously for Figure 2. The base address of the port for JP1 is 0xFF200060, and for JP2 is 0xFF200070. Figure 7 gives a diagram of the 40-pin connectors on the DE1-SoC board, and shows how the respective parallel port Data register bits, D_{31-0} , are assigned to the pins on the connector. The figure shows that bit D_0 of the parallel port is assigned to the pin at the top right corner of the connector, bit D_1 is assigned below this, and so on. Note that some of the pins on the 40-pin header are not usable as input/output connections, and are therefore not used by the parallel ports. Also, only 32 of the 36 data pins that appear on each connector can be used.




Figure 7. Assignment of parallel port bits to pins on *JP1* and *JP2*.

2.3.6 Using the Parallel Ports with Assembly Language Code and C Code

The DE1-SoC Computer provides a convenient platform for experimenting with Nios II assembly language code, or C code. A simple example of such code is provided in the Appendix in Listings 1 and 2. Both programs perform the same operations, and illustrate the use of parallel ports by using either assembly language or C code.

The code in the figures displays the values of the SW switches on the LED lights. A rotating pattern is displayed on the LEDs. This pattern is rotated to the left by using a Nios II *rotate* instruction, and a delay loop is used to make the shifting slow enough to observe. The pattern can be changed to the values of the SW switches by pressing a pushbutton KEY. When a pushbutton key is pressed, the program waits in a loop until the key is released.

The source code files shown in Listings 1 and 2 are distributed as part of the Intel FPGA Monitor Program. The files can be found under the heading *sample programs*, and are identified by the name *Getting Started*.

2.4 JTAG Port

The JTAG port implements a communication link between the DE1-SoC board and its host computer. This link can be used by the Intel Quartus Prime software to transfer FPGA programming files into the DE1-SoC board, and by the Intel FPGA Monitor Program, discussed in Section 8. The JTAG port also includes a UART, which can be used to transfer character data between the host computer and programs that are executing on the Nios II processor. If the Intel FPGA Monitor Program is used on the host computer, then this character data is sent and received through its *Terminal Window*. The programming interface of the JTAG UART consists of two 32-bit registers, as shown in

Figure 8. The register mapped to address 0xFF201000 is called the *Data* register and the register mapped to address 0xFF201004 is called the *Control* register.




Figure 8. JTAG UART registers.

When character data from the host computer is received by the JTAG UART it is stored in a 64-character FIFO. The number of characters currently stored in this FIFO is indicated in the field RAVAIL, which are bits 31-16 of the Data register. If the receive FIFO overflows, then additional data is lost. When data is present in the receive FIFO, then the value of RAVAIL will be greater than 0 and the value of bit 15, RVALID, will be 1. Reading the character at the head of the FIFO, which is provided in bits 7-0, decrements the value of RAVAIL by one and returns this decremented value as part of the read operation. If no data is present in the receive FIFO, then RVALID will be set to 0 and the data in bits 7-0 is undefined.

The JTAG UART also includes a 64-character FIFO that stores data waiting to be transmitted to the host computer. Character data is loaded into this FIFO by performing a write to bits 7–0 of the *Data* register in Figure 8. Note that writing into this register has no effect on received data. The amount of space, *WSPACE*, currently available in the transmit FIFO is provided in bits 31–16 of the *Control* register. If the transmit FIFO is full, then any characters written to the *Data* register will be lost.

Bit 10 in the *Control* register, called *AC*, has the value 1 if the JTAG UART has been accessed by the host computer. This bit can be used to check if a working connection to the host computer has been established. The *AC* bit can be cleared to 0 by writing a 1 into it.

The *Control* register bits *RE*, *WE*, *RI*, and *WI* are described in Section 3.

2.4.1 Using the JTAG UART with Assembly Language Code and C Code

Listings 3 and 4 give simple examples of assembly language and C code, respectively, that use the JTAG UART. Both versions of the code perform the same function, which is to first send an ASCII string to the JTAG UART, and then enter an endless loop. In the loop, the code reads character data that has been received by the JTAG UART, and echoes this data back to the UART for transmission. If the program is executed by using the Intel FPGA Monitor Program, then any keyboard character that is typed into the *Terminal Window* of the Monitor Program will be echoed back, causing the character to appear in the *Terminal Window*.

The source code files shown in Listings 3 and 4 are made available as part of the Intel FPGA Monitor Program. The files can be found under the heading *sample programs*, and are identified by the name *JTAG UART*.

2.5 Interval Timers

The DE1-SoC Computer includes a timer module implemented in the FPGA that can be used by the Nios II processor. This timer can be loaded with a preset value, and then counts down to zero using a 100-MHz clock. The programming interface for the timer includes six 16-bit registers, as illustrated in Figure 9. The 16-bit register at address 0xFF202000 provides status information about the timer, and the register at address 0xFF202004 allows control settings to be made. The bit fields in these registers are described below:

- *TO* provides a timeout signal which is set to 1 by the timer when it has reached a count value of zero. The *TO* bit can be reset by writing a 0 into it.
- *RUN* is set to 1 by the timer whenever it is currently counting. Write operations to the status halfword do not affect the value of the *RUN* bit.
- ITO is used for generating interrupts, which are discussed in section 3.




Figure 9. Interval timer registers.

- *CONT* affects the continuous operation of the timer. When the timer reaches a count value of zero it automatically reloads the specified starting count value. If *CONT* is set to 1, then the timer will continue counting down automatically. But if *CONT* = 0, then the timer will stop after it has reached a count value of 0.
- (START/STOP) is used to commence/suspend the operation of the timer by writing a 1 into the respective bit.

The two 16-bit registers at addresses 0xFF202008 and 0xFF20200C allow the period of the timer to be changed by setting the starting count value. The default setting provided in the DE1-SoC Computer gives a timer period of 125 msec. To achieve this period, the starting value of the count is $100 \text{ MHz} \times 125 \text{ msec} = 12.5 \times 10^6$. It is possible to capture a snapshot of the counter value at any time by performing a write to address 0xFF202010. This write operation causes the current 32-bit counter value to be stored into the two 16-bit timer registers at addresses 0xFF202010 and 0xFF202014. These registers can then be read to obtain the count value.

A second interval timer, which has an identical interface to the one described above, is also available in the FPGA, starting at the base address 0xFF202020.

Each Nios II processor has exclusive access to two interval timers.

2.6 G-Sensor

The DE1-SoC Computer includes a 3D accelerometer (G-sensor) that is connected to the HPS. The Nios II processor can access this device via an I2C serial interface at the base address 0xFFC04000. More details can be found in the tutorial *Using the DE1-SoC Accelerometer with Nios II*, available from Intel's FPGA University Program website.

2.7 Analog-to-Digital Conversion Port

The Analog-to-Digital Conversion (ADC) Port provides access to the eight-channel, 12-bit analog-to-digital converter on the DE1-SoC board. As illustrated in Figure 10, the ADC port comprises eight 12-bit registers starting at the base address 0xFF204000. The first two registers have dual purposes, acting as both data and control registers. By default, the ADC port updates the A-to-D conversion results for all ports only when instructed to do so. Writing to the control register at address 0xFF204000 causes this update to occur. Reading from the register at address 0xFF204000 provides the conversion data for channel 0. Reading from the other seven registers provides the conversion data for the corresponding channels. It is also possible to have the ADC port continually request A-to-D conversion data for all channels. This is done by writing the value 1 to the control register at address 0xFF204004. The *R* bit of each channel register in Figure 10 is used in Auto-update mode. *R* is set to 1 when its corresponding channel is refreshed and set to 0 when the channel is read.




Figure 10. ADC port registers.

Figure 11 shows the connector on the DE1-SoC board that is used with the ADC port. Analog signals in the range of 0 V to the V_{CC5} power-supply voltage can be connected to the pins for channels 0 to 7.

2.8 Floating-point Hardware

The Nios II processor in the DE1-SoC Computer includes hardware support for floating-point addition, subtraction, multiplication, and division. To use this support in a C program, variables must be declared with the type *float*. A simple example of such code is given in Listing 17. When this code is compiled, it is necessary to pass the special argument -mcustom-fpu-cfg=60-2 to the C compiler, to instruct it to use the floating-point hardware support.




Figure 11. ADC connector.

2.9 System ID

The system ID module provides a unique value that identifies the DE1-SoC Computer system. The host computer connected to the DE1-SoC board can query the system ID module by performing a read operation through the JTAG port. The host computer can then check the value of the returned identifier to confirm that the DE1-SoC Computer has been properly downloaded onto the DE1-SoC board. This process allows debugging tools on the host computer, such as the Intel FPGA Monitor Program, to verify that the DE1-SoC board contains the required computer system before attempting to execute code that has been compiled for this system.

3 Exceptions and Interrupts

The reset address of the Nios II processor in the DE1-SoC Computer is set to 0x00000000. The address used for all other general exceptions, such as divide by zero, and hardware IRQ interrupts is 0x00000020. Since the Nios II processor uses the same address for general exceptions and hardware IRQ interrupts, the Exception Handler software must determine the source of the exception by examining the appropriate processor status register. Table 1 gives the assignment of IRQ numbers to each of the I/O peripherals in the DE1-SoC Computer. The rest of this section describes the interrupt behavior associated with the interval timer, parallel ports, and serial ports in the DE1-SoC Computer.

I/O Peripheral	IRQ#
Interval timer	0
Pushbutton switch parallel port	1
Second Interval timer	2
Audio port	6
PS/2 port	7
JTAG port	8
IrDA port	9
Serial port	10
JP1 Expansion parallel port	11
JP2 Expansion parallel port	12
PS/2 port dual	23

Table 1. Hardware IRQ interrupt assignment for the DE1-SoC Computer.

3.1 Interrupts from Parallel Ports

Parallel ports implemented in the FPGA in the DE1-SoC Computer were illustrated in Figure 2, which is reproduced as Figure 12. As the figure shows, parallel ports that support interrupts include two related registers at the addresses Base + 8 and Base + C. The Interruptmask register, which has the address Base + 8, specifies whether or not an interrupt signal should be sent to the processor when the data present at an input port changes value. Setting a bit location in this register to 1 allows interrupts to be generated, while setting the bit to 0 prevents interrupts. Finally, the parallel port may contain an Edgecapture register at address Base + C. Each bit in this register has the value 1 if the corresponding bit location in the parallel port has changed its value from 0 to 1 since it was last read. Performing a write operation to the Edgecapture register sets all bits in the register to 0, and clears any associated interrupts.




Figure 12. Registers used for interrupts from the parallel ports.

3.1.1 Interrupts from the Pushbutton Keys

Figure 6, reproduced as Figure 13, shows the registers associated with the pushbutton parallel port. The *Interrupt-mask* register allows interrupts to be generated when a key is pressed. Each bit in the *Edgecapture* register is set to 1 by the parallel port when the corresponding key is pressed. An interrupt service routine can read this register to determine which key has been pressed. Writing any value to the *Edgecapture* register deasserts the interrupt signal being sent to the processor and sets all bits of the *Edgecapture* register to zero.




Figure 13. Registers used for interrupts from the pushbutton parallel port.

3.2 Interrupts from the JTAG UART

Figure 8, reproduced as Figure 14, shows the data and *Control* registers of the JTAG UART. As we said in Section 2.4, *RAVAIL* in the *Data* register gives the number of characters that are stored in the receive FIFO, and *WSPACE* gives the amount of unused space that is available in the transmit FIFO. The *RE* and *WE* bits in Figure 14 are used to enable processor interrupts associated with the receive and transmit FIFOs. When enabled, interrupts are generated when *RAVAIL* for the receive FIFO, or *WSPACE* for the transmit FIFO, exceeds 7. Pending interrupts are indicated in the Control register's *RI* and *WI* bits, and can be cleared by writing or reading data to/from the JTAG UART.




Figure 14. Interrupt bits in the JTAG UART registers.

3.3 Interrupts from the FPGA Interval Timer

Figure 9, in Section 2.5, shows six registers that are associated with the interval timer. As we said in Section 2.5, the *TO* bit in the *Status* register is set to 1 when the timer reaches a count value of 0. It is possible to generate an interrupt when this occurs, by using the *ITO* bit in the *Control* register. Setting the *ITO* bit to 1 causes an interrupt request to be sent to the processor whenever *TO* becomes 1. After an interrupt occurs, it can be cleared by writing any value into the *Status* register.

3.4 Using Interrupts with Assembly Language Code

An example of assembly language code for the DE1-SoC Computer that uses interrupts is shown in Listing 5. When this code is executed on the DE1-SoC board it displays a rotating pattern on the LEDs. The pattern's rotation can be toggled through pressing the pushbutton KEYs. Two types of interrupts are used in the code. The LEDs are controlled by an interrupt service routine for the interval timer, and another interrupt service routine is used to

handle the pushbutton keys. The speed of the rotation is set in the main program, by using a counter value in the interval timer that causes an interrupt to occur every 50 msec.

The reset and exception handlers for the main program in Listing 5 are given in Listing 6. The reset handler simply jumps to the _start symbol in the main program. The exception handler first checks if the exception that has occurred is an external interrupt or an internal one. In the case of an internal exception, such as an illegal instruction opcode or a trap instruction, the handler simply exits, because it does not handle these cases. For external exceptions, it calls either the interval timer interrupt service routine, for a level 0 interrupt, or the pushbutton key interrupt service routine for level 1. These routines are shown in Listings 7 and 8, respectively.

3.5 Using Interrupts with C Language Code

An example of C language code for the DE1-SoC Computer that uses interrupts is shown in Listing 9. This code performs exactly the same operations as the code described in Listing 5.

To enable interrupts the code in Listing 9 uses *macros* that provide access to the Nios II status and control registers. A collection of such macros, which can be used in any C program, are provided in Listing 10.

The reset and exception handlers for the main program in Listing 9 are given in Listing 11. The function called *the_reset* provides a simple reset mechanism by performing a branch to the main program. The function named *the_exception* represents a general exception handler that can be used with any C program. It includes assembly language code to check if the exception is caused by an external interrupt, and, if so, calls a C language routine named *interrupt_handler*. This routine can then perform whatever action is needed for the specific application. In Listing 11, the *interrupt_handler* code first determines which exception has occurred, by using a macro from Listing 10 that reads the content of the Nios II interrupt pending register. The interrupt service routine that is invoked for the interval timer is shown in 12, and the interrupt service routine for the pushbutton switches appears in Listing 13.

The source code files shown in Listing 5 to Listing 13 are distributed as part of the Intel FPGA Monitor Program. The files can be found under the heading *sample programs*, and are identified by the name *Interrupt Example*.

4 Media Components

This section describes the audio in/out, video-out, video-in, PS/2, and IrDA.

4.1 Audio In/Out Port

The DE1-SoC Computer includes an audio port that is connected to the audio CODEC (COder/DECoder) chip on the DE1-SoC board. The default setting for the sample rate provided by the audio CODEC is 8K samples/sec. The audio port provides audio-input capability via the microphone jack on the DE1-SoC board, as well as audio output functionality via the line-out jack. The audio port includes four FIFOs that are used to hold incoming and outgoing data. Incoming data is stored in the left- and right-channel *Read* FIFOs, and outgoing data is held in the left- and right-channel *Write* FIFOs. All FIFOs have a maximum depth of 128 32-bit words.

The audio port's programming interface consists of four 32-bit registers, as illustrated in Figure 15. The *Control* register, which has the address 0xFF203040, is readable to provide status information and writable to make control settings. Bit *RE* of this register provides an interrupt enable capability for incoming data. Setting this bit to 1 allows the audio core to generate a Nios II interrupt when either of the *Read* FIFOs are filled 75% or more. The bit *RI* will then be set to 1 to indicate that the interrupt is pending. The interrupt can be cleared by removing data from the *Read* FIFOs until both are less than 75% full. Bit *WE* gives an interrupt enable capability for outgoing data. Setting this bit to 1 allows the audio core to generate an interrupt when either of the *Write* FIFOs are less that 25% full. The bit *WI* will be set to 1 to indicate that the interrupt is pending, and it can be cleared by filling the *Write* FIFOs until both are more than 25% full. The bits *CR* and *CW* in Figure 15 can be set to 1 to clear the *Read* and *Write* FIFOs, respectively. The clear function remains active until the corresponding bit is set back to 0.




Figure 15. Audio port registers.

The read-only *Fifospace* register in Figure 15 contains four 8-bit fields. The fields *RARC* and *RALC* give the number of words currently stored in the right and left audio-input FIFOs, respectively. The fields *WSRC* and *WSLC* give the number of words currently available (that is, *unused*) for storing data in the right and left audio-out FIFOs. When all FIFOs in the audio port are cleared, the values provided in the *Fifospace* register are RARC = RALC = 0 and RARC = RARC = 0 and RARC = 0 a

The *Leftdata* and *Rightdata* registers are readable for audio in, and writable for audio out. When data is read from these registers, it is provided from the head of the *Read* FIFOs, and when data is written into these registers it is loaded into the *Write* FIFOs.

A fragment of C code that uses the audio port is shown in Listing 14. The code checks to see when the depth of either the left or right *Read* FIFO has exceeded 75% full, and then moves the data from these FIFOs into a memory buffer. This code is part of a program that is distributed as part of the Intel FPGA Monitor Program. The source code can be found under the heading *sample programs*, and is identified by the name *Audio*.

4.2 Video-out Port

The DE1-SoC Computer includes a video-out port with a VGA controller that can be connected to a standard VGA monitor. The VGA controller supports a screen resolution of 640×480 . The image that is displayed by the VGA controller is derived from two sources: a *pixel* buffer, and a *character* buffer.

4.2.1 Pixel Buffer

The pixel buffer for the video-out port holds the data (color) for each pixel that is displayed by the VGA controller. As illustrated in Figure 16, the pixel buffer provides an image resolution of 320×240 pixels, with the coordinate 0,0 being at the top-left corner of the image. Since the VGA controller supports the screen resolution of 640×480 , each of the pixel values in the pixel buffer is replicated in both the x and y dimensions when it is being displayed on the VGA screen.




Figure 16. Pixel buffer coordinates.

You can create an image by writing color values into the pixel addresses as described above. A dedicated *pixel buffer controller* continuously reads this pixel data from sequential addresses in the corresponding memory for display on the VGA screen. You can modify the pixel data at any time, simply by writing to the pixel addresses. Thus, an image can be changed even when it is in the process of being displayed. However, it is also possible to avoid making changes to the pixel buffer while it is being displayed, by using the concept of *double-buffering*. In this scheme, two pixel buffers are involved, called the *front* and *back* buffers, described below.

4.2.2 RGB Resampling

The DE1-SoC Computer contains an RGB Resampler for converting video streams between RGB color formats. Reading from the 32-bit *Status* register at address 0xFF203010 provides information about alpha/no alpha, color/grayscale, and mode for the incoming and outgoing formats. The incoming format for the DE1-SoC Com-




Figure 17. Pixel values and addresses.

puter video stream is 0x14, which corresponds to no alpha, color, 16-bit RGB (5-bit Red, 6-bit Green, 5-bit Blue). For more information, the reader should refer to the video module's online documentation, *Video IP Cores for Intel DE-Series Boards*, which is available from Intel's FPGA University Program web site.

4.2.3 Double Buffering

As mentioned above, a pixel buffer controller reads data out of the pixel buffer so that it can be displayed on the VGA screen. This pixel buffer controller includes a programming interface in the form of a set of registers, as illustrated in Figure 18. The register at address 0xFF203020 is called the *Buffer* register, and the register at address 0xFF203024 is the *Backbuffer* register. Each of these registers stores the starting address of a pixel buffer. The Buffer register holds the address of the pixel buffer that is displayed on the VGA screen. As mentioned above, in the default configuration of the DE1-SoC Computer this Buffer register is set to the address 0x08000000, which points to the start of the FPGA on-chip memory. The default value of the Backbuffer register is also 0x08000000, which means that there is only one pixel buffer. But software can modify the address stored in the Backbuffer register, thereby creating a second pixel buffer. The pixel buffer can be located in the SDRAM memory in the DE1-SoC Computer, which has the base address 0x00000000. Note that the pixel buffer cannot be located in the DDR3 memory in the DE1-SoC Computer, because the pixel buffer controller is not connected to the DDR3 memory. An image can be drawn into the second buffer by writing to its pixel addresses. This image is not displayed on the VGA monitor until a pixel buffer *swap* is performed, as explained below.

A pixel buffer swap is caused by writing the value 1 to the Buffer register. This write operation does not directly modify the content of the Buffer register, but instead causes the contents of the Buffer and Backbuffer registers to be swapped. The swap operation does not happen right away; it occurs at the end of a VGA screen-drawing cycle, after the last pixel in the bottom-right corner has been displayed. This time instance is referred to as the *vertical synchronization* time, and occurs every 1/60 seconds. Software can poll the value of the *S* bit in the *Status* register, at address 0xFF20302C, to see when the vertical synchronization has happened. Writing the value 1 into the Buffer register causes *S* to be set to 1. Then, when the swap of the Buffer and Backbuffer registers has been completed *S* is reset back to 0.

In a typical application the pixel buffer controller is used as follows. While the image contained in the pixel buffer that is pointed to by the Buffer register is being displayed, a new image is drawn into the pixel buffer pointed to by




Figure 18. Pixel buffer controller registers.


the Backbuffer register. When this new image is ready to be displayed, a pixel buffer swap is performed. Then, the pixel buffer that is now pointed to by the Backbuffer register, which was already displayed, is cleared and the next new image is drawn. In this way, the next image to be displayed is always drawn in the "back" pixel buffer, and the two pixel buffer pointers are swapped when the new image is ready to be displayed. Each time a swap is performed software has to synchronize with the VGA controller by waiting until the *S* bit in the Status register becomes 0.

As shown in Figure 18 the *Status* register contains additional information other than the *S* bit. The fields *n* and *m* give the number of address bits used for the *X* and *Y* pixel coordinates, respectively. The *B* field specifies the number of bytes used for each pixel, with the minimum being 1 and the maximum 4. The *A* field allows the selection of two different ways of forming pixel addresses. If configured with A = 0, then the pixel controller expects addresses to contain *X* and *Y* fields, as we have used in this section. But if A = 1, then the controller expects addresses to be consecutive values starting from 0 and ending at the total number of pixels-1.


In Figure 17b the default values of the status register fields in the DE1-SoC Computer are used when forming pixel addresses. The defaults are n = 9, m = 8, B = 2, and A = 0. If the pixel buffer controller is changed to provide different values of these fields, then the way in which pixel addresses are formed has to be modified accordingly. The programming interface also includes a *Resolution* register, shown in Figure 18, that contains the X and Y resolution of the pixel buffer(s).

4.2.4 Character Buffer

The character buffer for the video-out port is stored in on-chip memory in the FPGA on the DE1-SoC board. As illustrated in Figure 19a, the buffer provides a resolution of 80 × 60 characters, where each character occupies an 8 × 8 block of pixels on the VGA screen. Characters are stored in each of the locations shown in Figure 19a using their ASCII codes; when these character codes are displayed on the VGA monitor, the character buffer automatically generates the corresponding pattern of pixels for each character using a built-in font. Part b of Figure 19 shows that characters are addressed in the memory by using the combination of a *base* address, which has the value 0x09000000, and an x, y offset. Using this scheme, the character at location 0,0 has the address 0x09000000, the character 1,0 has the address $base + (000001\ 0000000)_2 = 0x09000080$, and the character at location 79,59 has the address $base + (111011\ 10011111)_2 = 0x09001DCF$.



(a) Character buffer coordinates



(b) Character buffer addresses

Figure 19. Character buffer coordinates and addresses.

4.2.5 Using the Video-out Port with C code

A fragment of C code that uses the pixel and character buffers is shown in Listing 15. The first **for** loop in the figure draws a rectangle in the pixel buffer using the color $pixel_color$. The rectangle is drawn using the coordinates x_1 , y_1 and x_2 , y_2 . The second **while** loop in the figure writes a null-terminated character string pointed to by the variable $text_ptr$ into the character buffer at the coordinates x, y. The code in Listing 15 is included in the sample program called *Video* that is distributed with the Intel FPGA Monitor Program.

4.3 Video-in Port

The DE1-SoC Computer includes a video-in port for use with the composite video-in connector on the DE1-SoC board. The video analog-to-digital converter (ADC) connected to this port is configured to support an NTSC video source. The video-in port provides frames of video at a resolution of 320 x 240 pixels. These video frames can be displayed on a VGA monitor by using the video-out port described in Section 4.2. The video-in port writes each frame of the video-in data into the pixel buffer described in Section 4.2.1. The video-in port can be configured to provide two types of images: either the "raw" image provided by the video ADC, or a version of this image in which only "edges" that are detected in the image are drawn.

The video-in port has a programming interface that consists of two registers, as illustrated in Figure 20. The *Control* register at the address 0xFF20306C is used to enable or disable the video input. If the *EN* bit in this register is set to 0, then the video-in core does not store any data into the pixel buffer. Setting *EN* to 1 and then changing *EN* to 0 can be used to capture a still picture from the video-in port.

The register at address 0xFF203070 is used to enable or disable edge detection. Setting the E bit in this register to 1 causes the input video to passed through hardware circuits that detect edges in the images. The image stored in the pixel buffer will then consist of dark areas that are puctuated by lighter lines along the edges that have been detected. Setting E = 0 causes a normal image to be stored into the pixel buffer.




Figure 20. The video-in port programming interface.

4.3.1 DMA Controller for Video

The data provided by the Video-In core is stored into memory using a DMA Controller for Video. When operating in *Stream to Memory* mode, the DMA stores the incoming frames to memory. Figure 21 describes the registers used in the DMA Controller.




Figure 21. Register map for the Video DMA Controller.

The incoming video is stored to memory, starting at the address specified in the *Buffer* register. The *BackBuffer* register is used to store an alternate memory location. To change where the video is stored, the new location should first be written into the *BackBuffer*. Then the value in the *BackBuffer* and *Buffer* registers can be switched by performing a write to the *Buffer* register.

Bit 2 of the *Status/Control* register, *EN*, is used to enable or disable the Video DMA controller. In the DE1-SoC Computer, the DMA controller is disabled by default. To enable the DMA controller, write a 1 into this location. The Video DMA Controller will then begin storing the video into the location specified in the *Buffer* register.

The default value stored in the *Buffer* register is 0x08000000. This address is also used as the source for the Video-Out port, as described in Section 4.2, allowing the Video In stream to be displayed on the VGA. If the Video-Out is

intended to display a different signal, than the address stored in the Video DMA Controller's *Buffer* register should be changed.

4.4 Audio/Video Configuration Module

The audio/video configuration module controls settings that affect the operation of both the audio port and the videoout port. The audio/video configuration module automatically configures and initializes both of these ports whenever the DE1-SoC Computer is reset. For typical use of the DE1-SoC Computer it is not necessary to modify any of these default settings. In the case that changes to these settings are needed, the reader should refer to the audio/video configuration module's online documentation, which is available from Intel's FPGA University Program web site.

4.5 PS/2 Port

The DE1-SoC Computer includes two PS/2 ports that can be connected to a standard PS/2 keyboard or mouse. The port includes a 256-byte FIFO that stores data received from a PS/2 device. The programming interface for the PS/2 port consists of two registers, as illustrated in Figure 22. The *PS2_Data* register is both readable and writable. When bit 15, *RVALID*, is 1, reading from this register provides the data at the head of the FIFO in the *Data* field, and the number of entries in the FIFO (including this read) in the *RAVAIL* field. When *RVALID* is 1, reading from the *PS2_Data* register decrements this field by 1. Writing to the *PS2_Data* register can be used to send a command in the *Data* field to the PS/2 device.

The $PS2_Control$ register can be used to enable interrupts from the PS/2 port by setting the RE field to the value 1. When this field is set, then the PS/2 port generates an interrupt when RAVAIL > 0. While the interrupt is pending the field RI will be set to 1, and it can be cleared by emptying the PS/2 port FIFO. The CE field in the $PS2_Control$ register is used to indicate that an error occurred when sending a command to a PS/2 device.




Figure 22. PS/2 port registers.

A fragment of C code that uses the PS/2 port is given in Listing 16. This code reads the content of the *Data* register, and saves data when it is available. If the code is used continually in a loop, then it stores the last three bytes of data received from the PS/2 port in the variables *byte*₁, *byte*₂, and *byte*₃. This code is included as part of a sample program called *PS2* that is distributed with the Intel FPGA Monitor Program.

4.5.1 PS/2 Port Dual

The DE1-SoC Computer includes a second PS/2 port that allows both a keyboard and mouse to be used at the same time. To use the dual port a Y-splitter cable must be used and the keyboard and mouse must be connected to the PS/2 connector on the DE1-SoC board through this cable. The PS/2 port dual has the same registers as the PS/2 port

shown in Listing 16, except that the base address of its *PS2_Data* register is 0xFF200108 and the base address of its *PS2_Control* register is 0xFF20010C.

4.6 IrDA Infrared Serial Port

The IrDA port in the DE1-SoC Computer implements a UART that is connected to the infrared transmit/receive device on the DE1-SoC board. This UART is configured for 8-bit data, one stop bit, and no parity, and operates at a baud rate of 115,200. The serial port's programming interface consists of two 32-bit registers, as illustrated in Figure 23. The register at address 0xFF201020 is referred to as the *Data* register, and the register at address 0xFF201024 is called the *Control* register.




Figure 23. IrDA serial port UART registers.

When character data is received from the IrDA chip it is stored in a 256-character FIFO in the UART. As illustrated in Figure 23, the number of characters RAVAIL currently stored in this FIFO is provided in bits 23–16 of the Data register. If the receive FIFO overflows, then additional data is lost. When the data that is present in the receive FIFO is available for reading, then the value of bit 15, RVALID, will be 1. Reading the character at the head of the FIFO, which is provided in bits 7–0, decrements the value of RAVAIL by one and returns this decremented value as part of the read operation. If no data is available to be read from the receive FIFO, then RVALID will be set to 0 and the data in bits 7–0 is undefined.

The UART also includes a 256-character FIFO that stores data waiting to be sent to the IrDA device. Character data is loaded into this register by performing a write to bits 7–0 of the *Data* register. Writing into this register has no effect on received data. The amount of space *WSPACE* currently available in the transmit FIFO is provided in bits 23–16 of the *Control* register, as indicated in Figure 23. If the transmit FIFO is full, then any additional characters written to the *Data* register will be lost.

The *RE* and *WE* bits in the *Control* register are used to enable Nios II processor interrupts associated with the receive and transmit FIFOs. When enabled, interrupts are generated when *RAVAIL* for the receive FIFO, or *WSPACE* for the transmit FIFO, exceeds 31. Pending interrupts are indicated in the *Control* register's *RI* and *WI* bits, and can be cleared by writing or reading data to/from the UART.

5 Modifying the DE1-SoC Computer

It is possible to modify the DE1-SoC Computer by using Intel's Quartus Prime software and Qsys tool. Tutorials that introduce this software are provided in the University Program section of Intel's web site. To modify the system it is first necessary to make an editable copy of the DE1-SoC Computer. The files for this system are installed as part

of the Monitor Program installation. Locate these files, copy them to a working directory, and then use the Quartus II and Qsys software to make any desired changes.

Table 2 lists the names of the Qsys IP cores that are used in this system. When the DE1-SoC Computer design files are opened in the Quartus Prime software, these cores can be examined using the Qsys System Integration tool. Each core has a number of settings that are selectable in the Qsys System Integration tool, and includes a datasheet that provides detailed documentation.

The steps needed to modify the system are:

- 1. Install the *University Program IP Cores* from Intel's FPGA University Program web site
- 2. Copy the design source files for the DE1-SoC Computer from the University Program web site. These files can be found in the *Design Examples* section of the web site
- 3. Open the DE1-SoC_Computer.qpf project in the Quartus Prime software
- 4. Open the Qsys System Integration tool in the Quartus Prime software, and modify the system as desired
- 5. Generate the modified system by using the Qsys System Integration tool
- 6. It may be necessary to modify the Verilog or VHDL code in the top-level module, DE0-Nano_Computer.v/vhd, if any I/O peripherals have been added or removed from the system
- 7. Compile the project in the Quartus Prime software
- 8. Download the modified system into the DE1-SoC board

The DE1-SoC Computer includes a Nios II/f processor. When using the Quartus Prime Web Edition, compiling a design with a Nios II/s or Nios II/f processor will produce a time-limited SOF file. As a result, the board must remain connected to the host computer, and the design cannot be set as the default configuration, as discussed in Section 6. Designs using only Nios II/e processors and designs compiled using the Quartus Prime Subscription Edition do not have this restriction.

I/O Peripheral	Qsys Core
SDRAM	SDRAM Controller
SRAM	SRAM Controller
On-chip memory character buffer	Character Buffer for VGA Display
SD Card	SD Card Interface
Flash	Intel UP Flash Memory IP Core
Red LED parallel port	Parallel Port
7-segment displays parallel port	Parallel Port
Expansion parallel ports	Parallel Port
Slider switch parallel port	Parallel Port
Pushbutton parallel port	Parallel Port
PS/2 port	PS2 Controller
JTAG port	JTAG UART
Serial port	RS232 UART
IrDA port	IrDA UART
Interval timer	Interval timer
System ID	System ID Peripheral
Audio/video configuration port	Audio and Video Config
Audio port	Audio
Video port	Pixel Buffer DMA Controller
Video In port	DMA Controller

Table 2. Qsys cores used in the DE1-SoC Computer.

6 Making the System the Default Configuration

The DE1-SoC Computer can be loaded into the nonvolatile FPGA configuration memory on the DE1-SoC board, so that it becomes the default system whenever the board is powered on. Instructions for configuring the DE1-SoC board in this manner can be found in the tutorial *Introduction to the Quartus Prime Software*, which is available from Intel's FPGA University Program.

7 Memory Layout

Table 3 summarizes the memory map used in the DE1-SoC Computer.

Base Address	End Address	I/O Peripheral
0x00000000	0x03FFFFFF	SDRAM
0x08000000	0x0803FFFF	FPGA On-chip Memory
0x09000000	0x09001FFF	FPGA On-chip Memory Character Buffer
0x40000000	0x7FFFFFFF	DDR3 Memory
0xFF200000	0xFF20000F	Red LEDs
0xFF200020	0xFF20002F	7-segment HEX3-HEX0 Displays
0xFF200030	0xFF20003F	7-segment HEX5-HEX4 Displays
0xFF200040	0xFF20004F	Slider Switches
0xFF200050	0xFF20005F	Pushbutton KEYs
0xFF200060	0xFF20006F	JP1 Expansion
0xFF200070	0xFF20007F	JP2 Expansion
0xFF200100	0xFF200107	PS/2
0xFF200108	0xFF20010F	PS/2 Dual
0xFF201000	0xFF201007	JTAG UART
0xFF201020	0xFF201027	Infrared (IrDA)
0xFF202000	0xFF20201F	Interval Timer
0xFF202020	0xFF20202F	Second Interval Timer
0xFF203000	0xFF20301F	Audio/video Configuration
0xFF203020	0xFF20302F	Pixel Buffer Control
0xFF203030	0xFF203037	Character Buffer Control
0xFF203040	0xFF20304F	Audio
0xFF203060	0xFF203070	Video-in
0xFF204000	0xFF20401F	ADC
0xFFC04000	0xFFC040FC	HPS I2C0

Table 3. Memory layout used in the DE1-SoC Computer.

8 Intel FPGA Monitor Program Integration

As we mentioned earlier, the DE1-SoC Computer system, and the sample programs described in this document, are made available as part of the Intel FPGA Monitor Program. Figures 24 to 27 show a series of windows that are used in the Monitor Program to create a new project. In the first screen, shown in Figure 24, the user specifies a file system folder where the project will be stored, gives the project a name, and specifies the type of processor that is being used. Pressing Next opens the window in Figure 25. Here, the user can select the DE1-SoC Computer as a pre-designed system. The Monitor Program then fills in the relevant information in the *System details* box, which includes the appropriate system info and fpga configuration files, and preloader. The first of these files specifies to the Monitor Program information about the components that are available in the DE1-SoC Computer, such as the type of processor and memory components, and the address map. The second file is an FPGA programming bitstream for the DE1-SoC Computer, which can downloaded by the Monitor Program into the DE1-SoC board. Any system which contains a Hard Processor System (HPS) component must also specify the preloader to be run immediately following the circuit being downloaded. This preloader is used to configure the components within the HPS with the setting required for the specific board.




Figure 24. Specifying the project folder and project name.

Pressing Next again opens the window in Figure 26. Here the user selects the type of program that will be used, such as Assembly language, or C. Then, the check box shown in the figure can be used to display the list of sample programs for the DE1-SoC Computer that are described in this document. When a sample program is selected in this list, its source files, and other settings, can be copied into the project folder in subsequent screens of the Monitor Program.

Figure 27 gives the final screen that is used to create a new project in the Monitor Program. This screen shows the default addresses of compiler and linker sections that will be used for the assembly language or C program associated with the Monitor Program project. In the figure, the drop-down menu called *Linker Section Presets* has been set to Exceptions. With this setting the Monitor Program uses specific compiler and linker sections for the selected processor. For the Nios II processor, these sections are for reset and exceptions code, and another section for the main program, called *.text*. For the A9 processor, it has a section for the exception table, called *.vectors*, and another section for the main program, called *.text*. It also shows the initial value used to set the main stack pointer for C programs, which is the starting address of the *.stack* section.




Figure 25. Specifying the DE1-SoC Computer system.




Figure 26. Selecting sample programs.




Figure 27. Setting offsets for .text and .data.

9 Appendix

This section contains all of the source code files mentioned in the document.

Parallel Ports

```
"address map nios2.s"
.include
/******************************
 * This program demonstrates use of parallel ports
 * It performs the following:
 * 1. displays a rotating pattern on the LEDs
 * 2. if any KEY is pressed, the SW switches are used as the rotating pattern
 ************************************
                             # executable code follows
.text
.global
          _start
start:
/* initialize base addresses of parallel ports */
                            # SW slider switch base address
       movia r15, SW_BASE
                             # LED base address
       movia r16, LED_BASE
       movia r17, KEY BASE
                               # pushbutton KEY base address
       movia r18, LED bits
       ldwio r6, 0(r18)
                               # load pattern for LED lights
DO_DISPLAY:
       ldwio r4, 0(r15)
                               # load slider switches
       ldwio
             r5, 0(r17)
                                # load pushbuttons
       beq
             r5, r0, NO_BUTTON
             r6, r4
                                # copy SW switch values onto LEDs
       mov
       roli
             r4, r4, 8
                                # the SW values are copied into the upper three
                               # bytes of the pattern register
             r6, r6, r4
                               # needed to make pattern consistent as all
                               # 32-bits of a register are rotated
       roli
              r4, r4, 8
                                # but only the lowest 8-bits are displayed on
                                # LEDs
       or
              r6, r6, r4
              r4, r4, 8
       roli
              r6, r6, r4
       or
WATT:
              r5, 0(r17)
                               # load pushbuttons
       ldwio
       bne
              r5, r0, WAIT
                                # wait for button release
NO BUTTON:
       stwio r6, 0(r16)
                               # store to LED
       roli
            r6, r6, 1
                               # rotate the displayed pattern
```

```
movia r7, 1500000 # delay counter
DELAY:
    subi r7, r7, 1
bne r7, r0, DELAY
    br DO_DISPLAY
.data
             # data follows
LED_bits:
.end
```

Listing 1. An example of ARM assembly language code that uses parallel ports.

```
#include "address_map_nios2.h"
/* This program demonstrates use of parallel ports in the Computer System
 * It performs the following:
 * 1. displays a rotating pattern on the LEDs
 * 2. if a KEY is pressed, uses the SW switches as the pattern
*/
int main(void) {
    /* Declare volatile pointers to I/O registers (volatile means that IO load
    * and store instructions will be used to access these pointer locations,
     * instead of regular memory loads and stores)
                            = (int *) LED_BASE; // LED address
    volatile int * LED_ptr
    volatile int * SW_switch_ptr = (int *)SW_BASE; // SW slider switch address
   volatile int * KEY_ptr = (int *)KEY_BASE; // pushbutton KEY address
    int LED_bits = 0x0F0F0F0F; // pattern for LED lights
    int SW_value, KEY_value;
    volatile int
       delay_count; // volatile so the C compiler doesn't remove the loop
    while (1) {
        SW_value = *(SW_switch_ptr); // read the SW slider (DIP) switch values
        KEY_value = *(KEY_ptr); // read the pushbutton KEY values
        if (KEY_value != 0)  // check if any KEY was pressed
            /* set pattern using SW values */
           LED_bits = SW_value | (SW_value << 8) | (SW_value << 16) |
                       (SW_value << 24);
            while (*KEY_ptr)
                ; // wait for pushbutton KEY release
        *(LED_ptr) = LED_bits; // light up the LEDs
        /* rotate the pattern shown on the LEDs */
        if (LED bits & 0x8000000)
            LED_bits = (LED_bits << 1) | 1;</pre>
        else
            LED_bits = LED_bits << 1;</pre>
        for (delay count = 350000; delay count != 0; --delay count)
            ; // delay loop
    }
}
```

Listing 2. An example of C code that uses parallel ports.

JTAG UART

```
"address_map_nios2.s"
.include
* This program demonstrates use of the JTAG UART port
 * It performs the following:
 * 1. sends a text string to the JTAG UART
 * 2. reads character data from the JTAG UART
  3. echos the character data back to the JTAG UART
 *******************************
.text
          # executable code follows
.global
        _start
_start:
/* set up stack pointer */
      movia sp, SDRAM_END - 3 # starts from largest memory address
      movia r6, JTAG_UART_BASE # JTAG UART base address
/* print a text string */
      movia r8, TEXT STRING
LOOP:
            r5, 0(r8)
      ldb
            r5, zero, GET_JTAG # string is null-terminated
      beq
           PUT_JTAG
      call
      addi
            r8, r8, 1
      br
             LOOP
/* read and echo characters */
GET_JTAG:
      ldwio r4, 0(r6) # read the JTAG UART data register andi r8, r4, 0x8000 # check if there is new data beq r8, r0, GET_JTAG # if no data, wait
             r5, r4, 0x00ff # the data is in the least significant byte
      andi
      call PUT_JTAG
                              # echo character
      hr
             GET_JTAG
/**********************************
 * Subroutine to send a character to the JTAG UART
 * r5 = character to send
     r6 = JTAG UART base address
 *******************************
.global PUT_JTAG
PUT_JTAG:
/* save any modified registers */
      subi sp, sp, 4 # reserve space on the stack stw r4, 0(sp) # save register
```

Listing 3. An example of assembly language code that uses the JTAG UART.

```
#include "JTAG_UART.h"
#include "address_map_nios2.h"
/**********************************
 * Subroutine to send a character to the JTAG UART
 ************************************
void put_jtag(volatile int * JTAG_UART_ptr, char c)
   int control;
   control = *(JTAG_UART_ptr + 1); // read the JTAG_UART control register
                        // if space, echo character, else ignore
   if (control & 0xFFFF0000)
      \star (JTAG\_UART\_ptr) = c;
}
* Subroutine to read a character from the JTAG UART
 * Returns \0 if no character, otherwise returns the character
 ************************************
char get_jtag(volatile int * JTAG_UART_ptr)
   int data;
   data = *(JTAG_UART_ptr); // read the JTAG_UART data register
   if (data & 0 \times 00008000) // check RVALID to see if there is new data
      return ((char) data & 0xFF);
   else
      return ('\0');
}
```

Listing 4. An example of C code that uses the JTAG UART (Part *a*).

```
#include "JTAG_UART.h"
#include "address_map_nios2.h"
* This program demonstrates use of the JTAG UART port
 * It performs the following:
 * 1. sends a text string to the JTAG UART
 * 2. reads character data from the JTAG UART
 * 3. echos the character data back to the JTAG UART
 int main(void)
   /* Declare volatile pointers to I/O registers (volatile means that IO load
     and store instructions will be used to access these pointer locations,
      instead of regular memory loads and stores) */
   volatile int * JTAG_UART_ptr = (int *)JTAG_UART_BASE; // JTAG UART address
   char text_string[] = "\nJTAG UART example code\n> \0";
   char *str, c;
   /* print a text string */
   for (str = text_string; *str != 0; ++str)
      put_jtag(JTAG_UART_ptr, *str);
   /* read and echo characters */
   while (1)
      c = get_jtag(JTAG_UART_ptr);
      if (c != '\0')
          put_jtag(JTAG_UART_ptr, c);
   }
}
```

Listing 4. An example of C code that uses the JTAG UART (Part b).

Interrupts

```
"address_map_nios2.s"
.include
         "globals.s"
.include
/**********************************
 * This program demonstrates use of interrupts. It
 * first starts an interval timer with 50 msec timeouts, and then enables
 * Nios II interrupts from the interval timer and pushbutton KEYs
 * The interrupt service routine for the interval timer displays a pattern
 * on the LEDs, and shifts this pattern either left or right:
      KEY[0]: loads a new pattern from the SW switches
      KEY[1]: toggles the shift direction the displayed pattern
 ********************************
          # executable code follows
.global
          _start
_start:
/* set up the stack */
       movia sp, SDRAM_END - 3 # stack starts from largest memory
                                # address
       movia r16, TIMER BASE
                               # interval timer base address
/* set the interval timer period for scrolling the LED lights */
       movia r12, 5000000 # 1/(100 \text{ MHz}) \times (5 \times 10^{6}) = 50 \text{ msec}
                               # store the low half word of counter
       sthio r12, 8(r16)
                                # start value
             r12, r12, 16
       srli
       sthio r12, 0xC(r16)
                               # high half word of counter start value
/* start interval timer, enable its interrupts */
             r15, 0b0111
                          # START = 1, CONT = 1, ITO = 1
       movi
       sthio
             r15, 4(r16)
/* write to the pushbutton port interrupt mask register */
       movia r15, KEY_BASE # pushbutton key base address
            r7, 0b11
                               # set interrupt mask bits
       movi
       stwio r7, 8(r15)
                               # interrupt mask register is (base + 8)
/* enable Nios II processor interrupts */
                             # get interrupt mask bit for interval
       movia r7, 0x0000001
                                # timer
       movia r8, 0x0000002
                               # get interrupt mask bit for pushbuttons
             r7, r7, r8
       wrctl ienable, r7
                               # enable interrupts for the given mask
                                # bits
       movi
             r7, 1
       wrctl status, r7
                         # turn on Nios II interrupt processing
```

IDLE:

br IDLE # main program simply idles .data /********************************** * The global variables used by the interrupt service routines for the interval * timer and the pushbutton keys are declared below ******************************* PATTERN .global PATTERN: 0x0F0F0F0F # pattern to show on the LED lights .word .global SHIFT_DIR SHIFT_DIR: RIGHT # pattern shifting direction .word .end

Listing 5. An example of assembly language code that uses interrupts.

```
* RESET SECTION
 * Note: "ax" is REQUIRED to designate the section as allocatable and executable.
 * Also, the Debug Client automatically places the ".reset" section at the reset
 * location specified in the CPU settings in SOPC Builder.
 *******************************
.section .reset, "ax"
      movia r2, _start
      jmp
                                  # branch to main program
* EXCEPTIONS SECTION
 * Note: "ax" is REQUIRED to designate the section as allocatable and executable.
 * Also, the Monitor Program automatically places the ".exceptions" section at
 * the exception location specified in the CPU settings in SOPC Builder.
 *******************************
.section .exceptions, "ax"
        EXCEPTION_HANDLER
.qlobal
EXCEPTION HANDLER:
      subi
             sp, sp, 16
                             # make room on the stack
             et, 0(sp)
      stw
      rdctl et, ct14
             et, r0, SKIP_EA_DEC
                                # interrupt is not external
      beq
      subi ea, ea, 4
                                 # must decrement ea by one instruction
                                 # for external interrupts, so that the
                                  # interrupted instruction will be run
SKIP_EA_DEC:
      stw
            ea, 4(sp)
                                # save all used registers on the Stack
      stw
            ra, 8(sp)
                                 # needed if call inst is used
             r22, 12(sp)
      stw
      rdctl et, ct14
             et, r0, CHECK LEVEL 0 # interrupt is an external interrupt
      bne
NOT EI:
                                  # exception must be unimplemented
                                  # instruction or TRAP instruction. This
                                  # code does not handle those cases
      br
             END ISR
CHECK_LEVEL_0:
                                 # interval timer is interrupt level 0
             r22, et, 0b1
      andi
      beq
             r22, r0, CHECK_LEVEL_1
            INTERVAL_TIMER_ISR
      br
             END_ISR
                                  # pushbutton port is interrupt level 1
CHECK_LEVEL_1:
```

```
andi
               r22, et, 0b10
        beq
                r22, r0, END_ISR
                                        # other interrupt levels are not handled in
                                        # this code
        call
               PUSHBUTTON_ISR
END_ISR:
                et, 0(sp)
                                        # restore all used register to previous
        ldw
                                        # values
        ldw
                ea, 4(sp)
        ldw
                ra, 8(sp)
                                        # needed if call inst is used
        ldw
                r22, 12(sp)
        addi
                sp, sp, 16
```

Listing 6. Reset and exception handler assembly language code.

.end

```
.include     "address_map_nios2.s"
.include     "globals.s"
.extern
         PATTERN
                       # externally defined variables
.extern
         SHIFT_DIR
/******************************
* Interval timer - Interrupt Service Routine
 * Shifts a PATTERN being displayed. The shift direction is determined by the
 * external variable SHIFT_DIR.
 ********************************
.global
         INTERVAL_TIMER_ISR
INTERVAL_TIMER_ISR:
      subi sp, sp, 40 # reserve space on the stack
             ra, 0(sp)
      stw
             r4, 4(sp)
      stw
            r5, 8(sp)
      stw
            r6, 12(sp)
      stw
            r8, 16(sp)
      stw
            r10, 20(sp)
       stw
            r20, 24(sp)
      stw
            r21, 28(sp)
      stw
      stw
            r22, 32(sp)
          r23, 36(sp)
       stw
      movia r10, TIMER BASE # interval timer base address
      sthio r0, 0(r10) # clear the interrupt
      movia r20, LED_BASE # LED base address
      movia r21, PATTERN # set up a pointer to the display pattern
      movia r22, SHIFT_DIR # set up a pointer to the shift direction variable
      ldw r6, 0(r21) # load the pattern
      stwio r6, 0(r20)
                          # store to LEDs
CHECK SHIFT:
            r5, 0(r22) # get shift direction
      ldw
      movi r8, RIGHT
      bne
          r5, r8, SHIFT_L
SHIFT R:
             r5, 1
                          # set r5 to the constant value 1
      movi
             r6, r6, r5 # rotate the displayed pattern right
      ror
      br
             STORE PATTERN
SHIFT_L:
      movi r5, 1
                          # set r5 to the constant value 1
             r6, r6, r5
                          # shift left
      rol
STORE_PATTERN:
             r6, 0(r21) # store display pattern
      stw
```

```
END_INTERVAL_TIMER_ISR:
       ldw ra, 0(sp)
                              # restore registers
       ldw
              r4, 4(sp)
               r5, 8(sp)
       ldw
            r6, 12(sp)
       ldw
              r8, 16(sp)
       ldw
       ldw
              r10, 20(sp)
               r20, 24(sp)
       ldw
            r20, 24(sp)
r21, 28(sp)
       ldw
       ldw
              r22, 32(sp)
       ldw
addi
               r23, 36(sp)
               sp, sp, 40
                               # release the reserved space on the stack
```

.end

Listing 7. Interrupt service routine for the interval timer.

```
.include     "address_map_nios2.s"
.include     "globals.s"
.extern PATTERN
                                        # externally defined variables
.extern
         SHIFT_DIR
/*********************************
 * Pushbutton - Interrupt Service Routine
 * This routine checks which KEY has been pressed and updates the global
 * variables as required.
 *************************************
.global
         PUSHBUTTON_ISR
PUSHBUTTON_ISR:
       subi sp, sp, 20
                                            # reserve space on the stack
             ra, 0 (sp)
       stw
       stw r10, 4(sp)
stw r11, 8(sp)
stw r12, 12(sp)
       stw r13, 16(sp)
       movia r10, KEY BASE
                                            # base address of pushbutton KEY
                                            # parallel port
       ldwio r11, 0xC(r10)
                                            # read edge capture register
       stwio r11, 0xC(r10)
                                            # clear the interrupt
CHECK KEY0:
       andi r13, r11, 0b0001
                                            # check KEY0
       beq
              r13, zero, CHECK_KEY1
                                            # base address of SW slider
       movia r10, SW_BASE
                                            # switches parallel port
       ldwio r12, 0(r10)
                                            # load a new pattern from the SW
                                            # switches
       movia r10, PATTERN
                                            # set up a pointer to the pattern
                                            # variable
             r12, 0(r10)
                                            # store the new pattern to the
       stw
                                            # global variable
CHECK KEY1:
       andi r13, r11, 0b0010
                                            # check KEY1
             r13, zero, END_PUSHBUTTON_ISR
       beq
       movia r10, SHIFT DIR
                                            # set up a pointer to the shift
                                            # direction variable
       ldw
             r12, 0(r10)
                                            # load the current shift direction
       xori
             r12, r12, 1
                                            # toggle the direction
              r12, 0(r10)
                                            # store the new shift direction
       stw
END_PUSHBUTTON_ISR:
       ldw ra, 0(sp)
                                            # Restore all used register to
                                            # previous
       ldw r10, 4(sp)
```

```
ldw r11, 8(sp)
ldw r12, 12(sp)
ldw r13, 16(sp)
addi sp, sp, 20
```

.end

Listing 8. Interrupt service routine for the pushbutton KEYs.

```
#include "address_map_nios2.h"
#include "globals.h" // defines global values
#include "nios2_ctrl_reg_macros.h"
/* the global variables are written by interrupt service routines; we have to
 * declare
 * these as volatile to avoid the compiler caching their values in registers */
volatile int pattern = 0x0000000F; // pattern for shifting
volatile int shift_dir = LEFT; // direction to shift the pattern
volatile int shift_enable = ENABLE; // enable/disable shifting of the pattern
* This program demonstrates use of interrupts. It
 * first starts the interval timer with 50 msec timeouts, and then enables
 * Nios II interrupts from the interval timer and pushbutton KEYs
 * The interrupt service routine for the interval timer displays a pattern on
 * the LED lights, and shifts this pattern either left or right. The shifting
 * direction is reversed when KEY[1] is pressed
*******************************
int main(void) {
    /* Declare volatile pointers to I/O registers (volatile means that IO load
     * and store instructions will be used to access these pointer locations,
     * instead of regular memory loads and stores)
     */
    volatile int * interval_timer_ptr =
        (int *)TIMER_BASE;
                                            // interal timer base address
    volatile int * KEY_ptr = (int *)KEY_BASE; // pushbutton KEY address
    /* set the interval timer period for scrolling the LED lights */
    int counter
                               = 2500000; // 1/(50 \text{ MHz}) \times (2500000) = 50 \text{ msec}
    *(interval_timer_ptr + 0x2) = (counter & 0xFFFF);
    *(interval_timer_ptr + 0x3) = (counter >> 16) & 0xFFFF;
    /* start interval timer, enable its interrupts */
    *(interval timer ptr + 1) = 0x7; // STOP = 0, START = 1, CONT = 1, ITO = 1
    *(KEY_ptr + 2) = 0x3; // enable interrupts for all pushbuttons
    /* set interrupt mask bits for levels 0 (interval timer) and level 1
    * (pushbuttons) */
   NIOS2 WRITE IENABLE (0x3);
   NIOS2_WRITE_STATUS(1); // enable Nios II interrupts
   while (1)
       ; // main program simply idles
}
```

Listing 9. An example of C code that uses interrupts.

```
#ifndef ___NIOS2_CTRL_REG_MACROS___
#define ___NIOS2_CTRL_REG_MACROS___
/* Macros for accessing the control registers.
#define NIOS2 READ STATUS(dest) \
   do { dest = __builtin_rdctl(0); } while (0)
#define NIOS2_WRITE_STATUS(src) \
   do { __builtin_wrctl(0, src); } while (0)
#define NIOS2 READ ESTATUS(dest) \
   do { dest = __builtin_rdctl(1); } while (0)
#define NIOS2_READ_BSTATUS(dest) \
   do { dest = __builtin_rdctl(2); } while (0)
#define NIOS2 READ IENABLE(dest) \
   do { dest = __builtin_rdctl(3); } while (0)
#define NIOS2_WRITE_IENABLE(src) \
   do { __builtin_wrctl(3, src); } while (0)
#define NIOS2_READ_IPENDING(dest) \
   do { dest = __builtin_rdctl(4); } while (0)
#define NIOS2_READ_CPUID(dest) \
   do { dest = __builtin_rdctl(5); } while (0)
#endif
```

Listing 10. Macros for accessing Nios II status and control registers.

```
#include "nios2_ctrl_req_macros.h"
/* function prototypes */
void main(void);
void interrupt_handler(void);
void interval_timer_ISR(void);
void pushbutton_ISR(void);
/* The assembly language code below handles CPU reset processing */
void the_reset(void) __attribute__((section(".reset")));
void the_reset(void)
/**********************************
 * Reset code. By giving the code a section attribute with the name ".reset" we
 * allow the linker program to locate this code at the proper reset vector
 * address. This code just calls the main program.
 *******************************
{
   asm(".set
                 noat"); /* Instruct the assembler NOT to use reg at (r1) as
                         * a temp register for performing optimizations */
                 nobreak"); /* Suppresses a warning message that says that
   asm(".set
                             * some
                             * debuggers corrupt regs bt (r25) and ba (r30)
   asm("movia
                 r2, main"); // Call the C language main program
   asm("jmp
                 r2");
}
/* The assembly language code below handles CPU exception processing. This
* code should not be modified; instead, the C language code in the function
 * interrupt_handler() can be modified as needed for a given application.
void the_exception(void) __attribute__((section(".exceptions")));
void the_exception(void)
* Exceptions code. By giving the code a section attribute with the name
 * ".exceptions" we allow the linker program to locate this code at the proper
 * exceptions vector address.
 * This code calls the interrupt handler and later returns from the exception.
 ******************************
{
   asm("subi sp, sp, 128");
             et, 96(sp)");
   asm("stw
   asm("rdctl et, ctl4");
   asm("beg et, r0, SKIP_EA_DEC"); // Interrupt is not external
   asm("subi ea, ea, 4"); /* Must decrement ea by one instruction
                           * for external interupts, so that the
                           * interrupted instruction will be run */
   asm("SKIP_EA_DEC:");
   asm("stw r1, 4(sp)"); // Save all registers
   asm("stw
             r2, 8(sp)");
```

```
asm("stw
            r3,
                 12(sp)");
asm("stw
            r4,
                 16(sp)");
asm("stw
            r5,
                 20(sp)");
asm("stw
            r6,
                 24(sp)");
asm("stw
            r7,
                 28(sp)");
asm("stw
            r8,
                 32(sp)");
asm("stw
            r9,
                 36(sp)");
            r10, 40(sp)");
asm("stw
asm("stw
            r11, 44(sp)");
asm("stw
            r12, 48(sp)");
asm("stw
            r13, 52(sp)");
asm("stw
            r14, 56(sp)");
asm("stw
            r15, 60(sp)");
asm("stw
           r16, 64(sp)");
asm("stw
            r17, 68(sp)");
asm("stw
            r18, 72(sp)");
asm("stw
            r19, 76(sp)");
asm("stw
            r20, 80(sp)");
            r21, 84(sp)");
asm("stw
            r22, 88(sp)");
asm("stw
asm("stw
            r23, 92(sp)");
asm("stw
            r25, 100(sp)"); // r25 = bt (skip r24 = et, because it is saved
                             // above)
asm("stw
            r26, 104(sp)"); // r26 = gp
// skip r27 because it is sp, and there is no point in saving this
asm("stw
            r28, 112(sp)"); // r28 = fp
asm("stw
            r29, 116(sp)"); // r29 = ea
asm("stw
            r30, 120(sp)"); // r30 = ba
            r31, 124(sp)"); // r31 = ra
asm("stw
asm("addi
            fp, sp, 128");
asm("call
            interrupt_handler"); // Call the C language interrupt handler
asm("ldw
            r1,
                 4(sp)"); // Restore all registers
asm("ldw
            r2,
                 8(sp)");
asm("ldw
            r3,
                 12(sp)");
asm("ldw
            r4,
                 16(sp)");
asm("ldw
            r5,
                 20(sp)");
asm("ldw
            r6,
                 24(sp)");
asm("ldw
            r7,
                 28(sp)");
                 32(sp)");
asm("ldw
            r8,
asm("ldw
            r9,
                 36(sp)");
            r10, 40(sp)");
asm("ldw
asm("ldw
            r11, 44(sp)");
asm("ldw
            r12, 48(sp)");
            r13, 52(sp)");
asm("ldw
asm("ldw
            r14, 56(sp)");
asm("ldw
            r15, 60(sp)");
            r16, 64(sp)");
asm("ldw
asm("ldw
            r17, 68(sp)");
asm("ldw
            r18, 72(sp)");
```

```
asm("ldw
            r19, 76(sp)");
   asm("ldw r20, 80(sp)");
   asm("ldw r21, 84(sp)");
   asm("ldw r22, 88(sp)");
   asm("ldw r23, 92(sp)");
   asm("ldw r24, 96(sp)");
   asm("ldw r25, 100(sp)"); // r25 = bt
   asm("ldw r26, 104(sp)"); // r26 = gp
   // skip r27 because it is sp, and we did not save this on the stack
   asm("ldw r28, 112(sp)"); // r28 = fp
   asm("ldw r29, 116(sp)"); // r29 = ea
   asm("ldw r30, 120(sp)"); // r30 = ba
   asm("ldw r31, 124(sp)"); // r31 = ra
   asm("addi sp, sp, 128");
   asm("eret");
}
/********************************
 * Interrupt Service Routine
 * Determines what caused the interrupt and calls the appropriate
 * subroutine.
 * ipending - Control register 4 which has the pending external interrupts
 ************************************
void interrupt_handler(void) {
   int ipending;
   NIOS2_READ_IPENDING(ipending);
   if (ipending & 0x1) // interval timer is interrupt level 0
       interval_timer_ISR();
   if (ipending & 0x2) // pushbuttons are interrupt level 1
       pushbutton_ISR();
   // else, ignore the interrupt
   return;
}
```

Listing 11. Reset and exception handler C code.

```
#include "address_map_nios2.h"
#include "globals.h" // defines global values
extern volatile int pattern, shift_dir, shift_enable;
/******************************
 * Interval timer interrupt service routine
 * Shifts a PATTERN being displayed on the LED lights. The shift direction
 * is determined by the external variable key_dir.
 ********************************
void interval_timer_ISR() {
   volatile int * interval_timer_ptr = (int *)TIMER_BASE;
   volatile int * LEDG_ptr = (int *)LED_BASE; // LED address
   *(interval_timer_ptr) = 0; // clear the interrupt
   *(LEDG_ptr) = pattern; // display pattern on LED
   if (shift enable == DISABLE) // check if shifting is disabled
       return:
   /* rotate the pattern shown on the LEDG lights */
   if (shift_dir == LEFT) // rotate left
       if (pattern & 0x8000000)
          pattern = (pattern << 1) | 1;</pre>
       else
          pattern = pattern << 1;</pre>
   else // rotate right
       if (pattern & 0x0000001)
       pattern = (pattern >> 1) \mid 0x80000000;
       pattern = (pattern >> 1) & 0x7FFFFFFF;
   return;
}
```

Listing 12. Interrupt service routine for the interval timer.

```
#include "address_map_nios2.h"
#include "globals.h" // defines global values
extern volatile int pattern, shift_dir, shift_enable;
/******************************
* Pushbutton - Interrupt Service Routine
 * This routine checks which KEY has been pressed and updates the global
 * variables as required.
 ********************************
void pushbutton_ISR(void) {
                         = (int *)KEY_BASE;
   volatile int * KEY_ptr
   volatile int * slider_switch_ptr = (int *)SW_BASE;
   int
               press;
   press
         = *(KEY_ptr + 3); // read the pushbutton interrupt register
   *(KEY_ptr + 3) = press;
                         // Clear the interrupt
   if (press & 0x1) // KEY0
      pattern = *slider_switch_ptr;
   if (press & 0x2) // KEY1
      shift_dir = shift_dir ^ 1;
   return;
}
```

Listing 13. Interrupt service routine for the pushbutton KEYs.

Audio

```
/* globals */
#define BUF_SIZE 80000 // about 10 seconds of buffer (@ 8K samples/sec)
#define BUF_THRESHOLD 96 // 75% of 128 word buffer
/* function prototypes */
void check_KEYs(int *, int *, int *);
/********************************
 * This program performs the following:
 * 1. records audio for 10 seconds when KEY[0] is pressed. LEDR[0] is lit
      while recording.
 * 2. plays the recorded audio when KEY[1] is pressed. LEDR[1] is lit while
      playing.
 ********************************
int main(void) {
   /* Declare volatile pointers to I/O registers (volatile means that IO load
      and store instructions will be used to access these pointer locations,
      instead of regular memory loads and stores) */
   volatile int * red_LED_ptr = (int *)LED_BASE;
   volatile int * audio_ptr = (int *)AUDIO_BASE;
   /* used for audio record/playback */
   int fifospace;
   int record = 0, play = 0, buffer_index = 0;
   int left_buffer[BUF_SIZE];
   int right buffer[BUF SIZE];
   /* read and echo audio data */
   record = 0;
   play = 0;
   while (1) {
       check_KEYs(&record, &play, &buffer_index);
       if (record) {
           *(red_LED_ptr) = 0x1; // turn on LEDR[0]
           fifospace =
               *(audio_ptr + 1); // read the audio port fifospace register
           if ((fifospace & 0x000000FF) > BUF THRESHOLD) // check RARC
               // store data until the the audio-in FIFO is empty or the buffer
               // is full
               while ((fifospace & 0x000000FF) && (buffer_index < BUF_SIZE)) {</pre>
                   left_buffer[buffer_index] = *(audio_ptr + 2);
                   right_buffer[buffer_index] = *(audio_ptr + 3);
                   ++buffer_index;
                   if (buffer_index == BUF_SIZE) {
                      // done recording
                      record
                               = 0;
```

```
\star (red_LED_ptr) = 0x0; // turn off LEDR
                   }
                   fifospace = *(audio_ptr +
                                1); // read the audio port fifospace register
               }
           }
       } else if (play) {
           *(red\_LED\_ptr) = 0x2; // turn on LEDR_1
           fifospace =
               *(audio_ptr + 1); // read the audio port fifospace register
           if ((fifospace & 0x00FF0000) > BUF_THRESHOLD) // check WSRC
               // output data until the buffer is empty or the audio-out FIFO
               // is full
               while ((fifospace & 0x00FF0000) && (buffer_index < BUF_SIZE)) {</pre>
                   *(audio_ptr + 2) = left_buffer[buffer_index];
                   *(audio_ptr + 3) = right_buffer[buffer_index];
                  ++buffer_index;
                   if (buffer_index == BUF_SIZE) {
                      // done playback
                      play
                              = 0;
                      \star (red_LED_ptr) = 0x0; // turn off LEDR
                   fifospace = *(audio_ptr +
                                1); // read the audio port fifospace register
               }
           }
      }
   }
}
/***********************************
 * Subroutine to read KEYs
*************************************
void check_KEYs(int * KEY0, int * KEY1, int * counter) {
   volatile int * KEY_ptr = (int *)KEY_BASE;
   volatile int * audio_ptr = (int *)AUDIO_BASE;
   int
                 KEY_value;
   KEY_value = *(KEY_ptr); // read the pushbutton KEY values
   while (*KEY ptr)
       ; // wait for pushbutton KEY release
   if (KEY_value == 0x1) // check KEY0
       // reset counter to start recording
       *counter = 0;
       // clear audio-in FIFO
       *(audio_ptr) = 0x4;
       *(audio_ptr) = 0x0;
```

```
*KEY0 = 1;
} else if (KEY_value == 0x2) // check KEY1
{
    // reset counter to start playback
    *counter = 0;
    // clear audio-out FIFO
    *(audio_ptr) = 0x8;
    *(audio_ptr) = 0x0;

*KEY1 = 1;
}
}
```

Listing 14. An example of code that uses the audio port.

Video Out

```
/* function prototypes */
void video_text(int, int, char *);
void video_box(int, int, int, int, short);
int resample_rgb(int, int);
int get_data_bits(int);
#define STANDARD X 320
#define STANDARD_Y 240
#define INTEL BLUE 0x0071C5
/* global variables */
int screen_x;
int screen_y;
int res_offset;
int col_offset;
/*********************************
 * This program demonstrates use of the video in the computer system.
 * Draws a blue box on the video display, and places a text string inside the
 *******************************
int main(void) {
   volatile int * video_resolution = (int *)(PIXEL_BUF_CTRL_BASE + 0x8);
   screen x
                               = *video resolution & 0xFFFF;
   screen_y
                                = (*video_resolution >> 16) & 0xFFFF;
   volatile int * rgb status = (int *)(RGB RESAMPLER BASE);
                         = get_data_bits(*rgb_status & 0x3F);
                 db
   /st check if resolution is smaller than the standard 320 x 240 st/
   res_offset = (screen_x == 160) ? 1 : 0;
   /* check if number of data bits is less than the standard 16-bits */
   col\_offset = (db == 8) ? 1 : 0;
   \slash * create a message to be displayed on the video and LCD displays */
   char text_top_row[40] = "Intel FPGA\0";
   char text_bottom_row[40] = "Computer Systems\0";
   /* update color */
   short background_color = resample_rgb(db, INTEL_BLUE);
   video_text(35, 29, text_top_row);
   video_text(32, 30, text_bottom_row);
   video_box(0, 0, STANDARD_X, STANDARD_Y, 0); // clear the screen
   video_box(31 * 4, 28 * 4, 49 * 4 - 1, 32 * 4 - 1, background_color);
}
* Subroutine to send a string of text to the video monitor
```

```
*******************************
void video_text(int x, int y, char * text_ptr) {
                offset;
   volatile char * character buffer =
       (char *)FPGA_CHAR_BASE; // video character buffer
   /* assume that the text string fits on one line */
   offset = (y \ll 7) + x;
   while (*(text_ptr)) {
       *(character_buffer + offset) =
           *(text_ptr); // write to the character buffer
       ++text_ptr;
       ++offset;
   }
}
/**********************************
 * Draw a filled rectangle on the video monitor
 * Takes in points assuming 320x240 resolution and adjusts based on differences
 * in resolution and color bits.
 ************************************
void video_box(int x1, int y1, int x2, int y2, short pixel_color) {
   int pixel_buf_ptr = *(int *)PIXEL_BUF_CTRL_BASE;
   int pixel_ptr, row, col;
   int x factor = 0x1 << (res offset + col offset);</pre>
   int y_factor = 0x1 << (res_offset);</pre>
               = x1 / x_factor;
   x2
              = x2 / x_factor;
              = y1 / y_factor;
   у1
               = y2 / y_factor;
   v2
   /* assume that the box coordinates are valid */
   for (row = y1; row <= y2; row++)</pre>
       for (col = x1; col <= x2; ++col) {</pre>
          pixel_ptr = pixel_buf_ptr +
                     (row << (10 - res_offset - col_offset)) + (col << 1);</pre>
           *(short *)pixel_ptr = pixel_color; // set pixel color
}
/******************************
 * Resamples 24-bit color to 16-bit or 8-bit color
 *******************************
int resample_rgb(int num_bits, int color) {
   if (num_bits == 8) {
       color = (((color >> 16) & 0x000000E0) | ((color >> 11) & 0x0000001C) |
               ((color >> 6) \& 0x00000003));
       color = (color << 8) | color;</pre>
   } else if (num_bits == 16) {
       color = (((color >> 8) & 0x0000F800) | ((color >> 5) & 0x000007E0) |
               ((color >> 3) \& 0x0000001F));
```

```
return color;
/**********************************
 * Finds the number of data bits from the mode
 *******************************
int get_data_bits(int mode) {
   switch (mode) {
   case 0:
      return 1;
   case 7:
      return 8;
   case 17:
      return 8;
   case 18:
      return 9;
   case 20:
      return 16;
   case 23:
      return 24;
   case 25:
      return 30;
   case 49:
      return 8;
   case 50:
      return 12;
   case 51:
      return 16;
   case 55:
      return 32;
   case 57:
      return 40;
}
```

Listing 15. An example of code that uses the video-out port.

PS/2

```
/* function prototypes */
void HEX_PS2(char, char, char);
/*********************************
 * This program demonstrates use of the PS/2 port by displaying the last three
 * bytes of data received from the PS/2 port on the HEX displays.
 *******************************
int main(void) {
   /* Declare volatile pointers to I/O registers (volatile means that IO load
      and store instructions will be used to access these pointer locations,
      instead of regular memory loads and stores) */
   volatile int * PS2_ptr = (int *)PS2_BASE;
   int PS2_data, RVALID;
   char byte1 = 0, byte2 = 0, byte3 = 0;
   // PS/2 mouse needs to be reset (must be already plugged in)
   *(PS2\_ptr) = 0xFF; // reset
   while (1) {
      PS2_data = *(PS2_ptr); // read the Data register in the PS/2 port
      RVALID = PS2_data & 0x8000; // extract the RVALID field
       if (RVALID) {
          /* shift the next data byte into the display */
          byte1 = byte2;
          byte2 = byte3;
          byte3 = PS2_data \& 0xFF;
          HEX_PS2(byte1, byte2, byte3);
          if (byte2 == (char) 0xAA) && (byte3 == (char) 0x00))
              // mouse inserted; initialize sending of data
              \star (PS2\_ptr) = 0xF4;
       }
   }
}
* Subroutine to show a string of HEX data on the HEX displays
********************************
void HEX_PS2(char b1, char b2, char b3) {
   volatile int * HEX3_HEX0_ptr = (int *)HEX3_HEX0_BASE;
   volatile int * HEX5_HEX4_ptr = (int *)HEX5_HEX4_BASE;
   /* SEVEN_SEGMENT_DECODE_TABLE gives the on/off settings for all segments in
    * a single 7-seg display in the DE1-SoC Computer, for the hex digits 0 - F
    */
   unsigned char seven_seg_decode_table[] = {
       0x3F, 0x06, 0x5B, 0x4F, 0x66, 0x6D, 0x7D, 0x07,
       0x7F, 0x67, 0x77, 0x7C, 0x39, 0x5E, 0x79, 0x71};
```

Listing 16. An example of code that uses the PS/2 port.

Floating Point

```
/***********************************
 * This program demonstrates use of floating-point numbers
 * It performs the following:
       1. reads two FP numbers from the Terminal window
       2. performs +, -, \star, and / on the numbers
       3. prints the results on the Terminal window
       Note: Please enable "Echo input" in the terminal window
 *************************
#include <stdio.h>
int flush()
   while (getchar() != '\n')
   return 1;
}
int main(void)
   float x, y, add, sub, mult, div;
   while (1)
       printf("Enter FP values X: ");
       while ((scanf("%f", &x) != 1) && flush())
           ; // get valid floating point value and flush the invalid input
       printf("%f\n", x); // echo the typed data to the Terminal window
       printf("Enter FP values Y: ");
       while ((scanf("%f", &y) != 1) && flush())
           ; // get valid floating point value and flush the invalid input
       printf("%f\n", y); // echo the typed data to the Terminal window
       add = x + y;
       sub = x - y;
       mult = x * y;
       div = x / y;
       printf("X + Y = f\n", add);
       printf("X - Y = f\n", sub);
       printf("X * Y = f\n", mult);
       printf("X / Y = f\n", div);
}
```

Listing 17. An example of code that uses floating-point variables.

Copyright © Intel Corporation.