

The CS-705 is an application software to set up the IC-705 from your PC. This manual shows system requirements and how to use the software.

System requirements

The following hardware and software are required:

Operating System (OS)

- Microsoft Windows 11 (64bit)
- Microsoft Windows 10 (32/64bit)
- ① Except for Windows on ARM.

① Icom does not guarantee that this software will work correctly on all PCs with the above OS installed.

① The instructions are based on using Microsoft Windows 11.

About an microSD card

NOTE: The microSD, microSDHC, and microSDXC cards are not supplied by Icom. (User supplied)

Icom has checked the compatibility with the following microSD, microSDHC, and microSDXC cards.
(As of August 2025)

Brand	Type	Capacity
SanDisk	microSD	2 GB
	microSDHC	4/8/16/32 GB
	microSDXC	64/128/256 GB

① Through the rest of this document, the microSD card, microSDHC card, and microSDXC card are simply called microSD cards.

① The microSD cards listed above are usable with the IC-705, but their specifications are not guaranteed by Icom.

USB driver installation

To use the USB cable between the transceiver and a PC, you must first install a USB driver.

The latest USB driver and installation guide can be downloaded from the Icom website.

Carefully read the guide, before installing the driver.

<https://www.icomjapan.com/support/>

Icom and the Icom logo are registered trademarks of Icom Incorporated (Japan) in Japan, the United States, the United Kingdom, Germany, France, Spain, Russia, Australia, New Zealand, and/or other countries.

Microsoft and Windows are trademarks of the Microsoft group of companies.

All other products or brands are registered trademarks or trademarks of their respective holders.

Select either of the following programming methods:

Through a USB Cable

- USB Cable
Use a proper cable for data communication according to your PC's USB port.
Micro-B to Type-A: User supplied
Micro-B to Type-C: OPC-2418 (optional)
- USB Port (USB 1.1, 2.0, or 3.0 port)

With a memory card

- microSD card (User supplied)
① A memory card reader or memory card slot is required for reading.

Programming information

- To prevent data loss, you should first read the transceiver setting data into the CS-705, or copy the setting data (ICF file) of the microSD card to the PC, and read the data into the CS-705. Then edit or enter new software parameters.
- Before editing or entering new data, make a backup file onto your PC. A backup file enables easy restoring even if the setting data is accidentally deleted.
- While reading or writing (uploading) the data through the USB cable, **NEVER** turn OFF the transceiver or the PC, and **NEVER** disconnect the USB cable. Otherwise, the data could be lost or deleted.
- While reading or writing the data to or from the microSD card, **NEVER** remove the microSD card or turn OFF the transceiver. Otherwise, the data could be corrupted or the microSD card could be damaged.

Updating the CS-705

The CS-705 may be updated due to its function enhancements, improvements, or the transceiver's firmware updates.


To keep the CS-705 up-to-date, download and install the latest version from the Icom website.

<https://www.icomjapan.com/support/>


① If an error dialog is displayed indicating that the connected transceiver is incompatible with the programming software, update the CS-705 to the latest version.

Installing the programming software


1. Sign in to the PC as the administrator.
① Confirm that no other applications are running.
2. Download the ZIP file from the Icom website and extract it to a new location.
3. Double-click “setup.exe.”
① If the “User Account Control” dialog is displayed, click <Yes>.
• “Choose Setup Language” is displayed.
4. Select “English” (or “Japanese”) and then click <Next>.&br/>① In this document, “English” is selected.




5. On the “Welcome to the InstallShield Wizard for CS-705” screen, click <Next>.




6. On the “Choose Destination Location” screen, click <Next>.
① If desired, click <Browse...> and select another destination folder before clicking <Next >.



7. After the installation has completed, click <Finish>.



- The “CS-705” shortcut icon is added onto the desktop.



TIP:

- See the Help file of the programming software for assistance with the functions or settings. To open the Help file, click “Help” in the top menu of the programming software and select “Contents,” or simply push the [F1] key of the PC’s keyboard.
- You can uninstall the programming software using the “Installed apps” in the “Apps” menu. To get started, click on START (Windows logo) > Settings > Apps > Installed apps.

Setting up from a PC using an microSD card

To set up from a PC using a microSD card, follow the steps described below.

Step 1 Saving the setting data onto a PC

Step 2 Making an Initial setup



Step 3 Editing the parameters (p. 4)

Step 4 Writing the setting data to the transceiver (p. 4)

NOTE: If you use a brand new microSD card, first format the card using the transceiver. See the IC-705 Basic Manual for details on the formatting procedure.

Step 1 Saving the setting data onto a PC

1. Save the transceiver's setting data onto the microSD card.
 - ① Insert a microSD card into the transceiver, and save the setting data from "Save Setting" on the transceiver's MENU screen.
(**MENU** > SET > SD Card > **Save Setting**)
2. Turn OFF the transceiver, and remove the microSD card.
3. Insert the card into the PC's card slot or an external card reader, as shown below.
4. Copy the transceiver's setting data (ICF file), stored in the "Setting" folder of the card to a PC local folder.




Step 2 Making an Initial setup

When you start the CS-705, the Initial Setup window is displayed. Before using the software, follow the steps below to make an initial setup to send the transceiver version information.

1. Click the "microSD" radio button.
2. Click <Open...> to display the data file selection window.
3. Select the setting data (ICF file) copied from the transceiver in step 4 of "Saving the setting data onto a PC," as described above.
4. Click <OK> to open the programming screen and read the selected file.

NOTE:

- When the transceiver version information is not correctly sent to the software, some items may not be displayed on the software.
- If you want to make the initial setup again, select "CS-705 Initial Setup" in the Windows Start menu.
(START (Windows logo) > All > CS-705 > CS-705 Initial Setup)



Step 3 Editing the parameters





1. Enter Memory channels, call signs, repeater list, set scan and other settings using the CS-705.
2. Save the setting data in the Icom Cloning Format (ICF) file format in a folder on your PC.
 - ① See the CS-705 Help file of the for assistance.

TIP: If you have an ICF file to write to the transceiver, click  or select "Open... Ctrl+O" in the <File> menu, and then select the file.

Step 4 Writing the setting data to the transceiver

Copy the saved setting data in Step 3 above to the microSD card, and write it to the transceiver.

1. Copy the setting data (ICF file) into the "Setting" folder in the "IC-705" folder on the microSD card, as shown below:



2. Remove the microSD card from the PC and insert it into the transceiver.
3. Write the setting data to the transceiver.
(**MENU** > SET > SD Card > **Load Setting**)
 - The loaded setting data overwrites the current settings.
 - ① Refer to the Section 6 of the IC-705 Basic Manual for details on loading the setting data.
4. Turn OFF the transceiver, then turn it ON again to operate the transceiver with the loaded settings.

NOTE:

- The loading contents can be selected between "ALL," "Select," and "Repeater List Only." When you want to load only the repeater list into the transceiver, select "Repeater List Only."
- The original Skip settings in your repeater list can be kept when loading. When "Keep 'USE (FROM)' settings in the Repeater List?" is displayed, select <Yes> to keep the Skip settings in the repeater list. See the IC-705 Advanced Manual for details.


Setting up from a PC using a USB cable

To set up from a PC using a USB cable, follow the steps described below.

- Step 1** Connecting the transceiver and PC using a USB cable
- Step 2** Making an Initial setup
- Step 3** Reading the settings from the transceiver (p. 6)
- Step 4** Editing the parameters (p. 6)
- Step 5** Writing the setting data to the transceiver (p. 6)

Step 1 Connecting the transceiver and PC using a USB cable

1. Install the USB driver.
 - ① The latest USB driver and “USB Driver Installation Guide” can be downloaded from the Icom website.
2. Turn OFF the transceiver.
3. Connect the USB cable, as shown below.
4. Turn ON the transceiver.




Step 2 Making an Initial setup

When you start the CS-705, the Initial Setup window is displayed. Before using the software, follow the steps below to make an initial setup to send the transceiver version information.

1. Click the “COM Port” radio button.
2. Click <Search...> to display the IC-705 Search window.
Select the appropriate transceiver and click <OK>.
 - The COM port number will be set in the input field.
3. Click <OK> to open the programming screen.

NOTE:

- When the transceiver version information is not correctly sent to the software, some items may not be displayed on the software.
- If you want to make the initial setup again, select “CS-705 Initial Setup” in the Windows Start menu. (START (Windows logo) > All > CS-705 > CS-705 Initial Setup)



Step 3 Reading the settings from the transceiver

Follow the steps below to write the setting data that is edited with the CS-705 to the transceiver using a USB cable.

- Click , or select “Read ← TR” in the <Clone> menu to read the data from the transceiver.

NOTE: To prevent data loss, you should first read all the transceiver's setting data into the programming software. Before editing or entering, make a backup file onto your PC. A backup file enables easy restoring even if the setting data in the transceiver is accidentally deleted.



While reading from the transceiver

Step 4 Editing the parameters

- Enter Memory channels, call signs, repeater lists, set scan and other settings using the CS-705.
 - ① See the CS-705 Help file for assistance.
 - ① Save the setting data in the Icom Cloning Format (ICF) file format in a folder on your PC.

TIP: If you have an ICF file to write to the transceiver, click  or select “Open... Ctrl+O” in the <File> menu, and then select the file.


Step 5 Writing the setting data to the transceiver

You can write the edited Memory channels, call signs, repeater list, scan and other settings to the transceiver.


NOTE: Writing the setting will overwrite the current setting data on the transceiver.

1. Click , or select “Write → TR” in the <Clone> menu to write the setting data to your transceiver.
2. Check the items you want to write to the transceiver, and then click <OK>.

3. Click <OK> on the confirmation dialog.
 - Starts writing to the transceiver.



While writing to the transceiver



Writing completed

4. After the writing is completed, turn OFF the transceiver, then turn it ON again to operate it with the edited setting data.

Downloading the latest ICF file and CSV files

Download the Zip file containing the latest Comma Separated Values (CSV) files and the ICF file from the Icom website:

https://www.icomjapan.com/support/firmware_driver/

1. Right-click on the downloaded compressed file and select "Extract All..." to unzip it.
 - A "705_USA_YYMMDD" folder, for example, will be created in the same place where the downloaded file is saved.

File name (Example):

705_USA_YYMMDD.zip

↑ ↑
Shows the Shows the
version updated date

2. Save the unzipped file in a folder on your PC.

Contents of the downloaded ZIP file

(as of August 2025)

- **Settings file** (ICF file)
Example: 705_USA_YYMMDD.icf

All setting data of the transceiver is saved in the ICF file. See pages 4 and 6 to set up.
- **GPS memory** (CSV file)
Example: 705_USA_GPS_YYMMDD.csv
- **Repeater list** (CSV file)
Example: 705_USA_Rpt_YYMMDD.csv
- **Connection IP Address list** (CSV file)
Example: RepMoni_sample.csv

The name of a CSV file represents the content.

For GPS memory and Repeater list:

- See page 9 to edit.
- See page 8 to import.
- See page 9 to export.

Importing the Repeater list

Read this section before importing the repeater list in a Comma Separated Values (CSV) format file into the CS-705.


NOTE: When a cable is used, the settings, except the repeater list, can be kept by doing the following procedures.

1. Reading the setting data from the transceiver

- Click , or select “Read ← TR” in the <Clone> menu to read the data from the transceiver.
(pp. 4, 6)
- ① Before editing, make a backup file of all the transceiver's data onto your PC to prevent data loss.

2. Importing a Repeater list


1. Select the “Repeater List” folder or double-click on it to show each repeater group on the tree view screen.



2. Click “Import...” in the <File> menu, and then click “All...”
① The repeater information in a CSV file is imported, and sorted into groups according to the group number.


NOTE: When you select “Group...”, all repeater information in the file is imported into the repeater groups, selected in step 1. If you select the “Repeater List” folder in step 1, “Group...” cannot be selected.

3. Select the CSV file, saved in “Downloading the latest ICF file and CSV files” described on the previous page, and then click <Open>.
4. When the dialog is displayed as shown below, select an import method, and then click <OK>.




- Keep RPT order/USE (FROM) settings:
Replace repeater lists with the contents of the CSV format file while maintaining the existing order and “USE (FROM)” setting.
- Keep USE (FROM) settings:
Replace all repeater lists with the contents of the CSV format file. However, if the same repeater information is set to your original repeater list, the original “USE (FROM)” setting will be kept when importing.
- Rewrite all:
Replace all repeater lists with the contents of the CSV format file.

5. Click <OK> in the dialog to start importing.
When “Keep RPT order/USE (FROM) settings” is selected:



When “Keep USE (FROM) settings” or “Rewrite all” is selected:



TIP:

About the “USE (FROM)” setting

Select whether or not the repeater can be selected as an access repeater (FROM), when you rotate **MAIN DIAL**.

If you select <NO>, the repeater is not displayed in the “FROM” selection, and is skipped during a DR scan.

Importing the GPS Memory (CSV file)

When you import the GPS Memory, select “GPS Memory” folder or each GPS group on the tree view screen in step 1.

Editing and Exporting the Repeater list

Read this section before editing and exporting the repeater list.


1. Editing the Repeater list

1. Select a repeater group in the “Repeater List” folder on the tree view screen of the CS-705.
2. Edit the necessary items in the repeater list.
① See the CS-705 Help file for details.

2. Exporting the Repeater list

1. Select the “Repeater List” folder, or each repeater group on the tree view screen.

<Tree view screen of the CS-705>



2. Click “Export” in the <File> menu, and then click “Group...” or “All...”

NOTE: If you select the “Repeater List” folder in step 1, “Group...” cannot be selected.

- Group...: Exports repeater information entered in only the selected group.
- All...: Exports repeater information entered in all groups.

3. Save the data in a CSV format file to a folder on your PC.

TIP: The “GPS Memory” folder or each GPS group on the tree view screen can be exported in the same procedure.