
## Instruction for CW505 planar H-Field Probe

Use H-Field to collect EM trace

Assemble devices: follow the picture to connect H-Field probe and chipwhisperer



- b. More information can be find here
  - i. <a href="https://rtfm.newae.com/Tools/CW505%20Planar%20H-Field%20Probe/">https://rtfm.newae.com/Tools/CW505%20Planar%20H-Field%20Probe/</a>
- 2. Start collect EM trace

a.

- Once the device is assembled as above, we first to explore where is the best location to place the probe with the help of real-time visualization EM trace. The implementation can be found here,
  - i. <a href="https://github.com/haoliutj/EM\_Trace\_collection/blob/master/probe\_positio">https://github.com/haoliutj/EM\_Trace\_collection/blob/master/probe\_positio</a>
    n exloration em trace.ipynb
- b. Once the best location found for probe to place, we can start automatically collect EM trace. The implementation can be found here,
  - i. <a href="https://github.com/haoliutj/EM\_Trace\_collection/blob/master/probe\_positio">https://github.com/haoliutj/EM\_Trace\_collection/blob/master/probe\_positio</a>
    n exloration em trace.ipynb
- 3. Additional resources:
  - a. <a href="https://github.com/newaetech/chipwhisperer-jupyter/blob/master/demos/H-Field%20Probe%20Demo%201%20(with%20CPA).ipynb">https://github.com/newaetech/chipwhisperer-jupyter/blob/master/demos/H-Field%20Probe%20Demo%201%20(with%20CPA).ipynb</a>