Microstep Driver

细分	S1	S2	S3
2	ON	ON	ON
8	ON	ON	OFF
10	ON	OFF	ON
16	ON	OFF	OFF
20	OFF	ON	ON
32	OFF	ON	OFF
40	OFF	OFF	ON
64	OFF	OFF	OFF

衰减	S4	S5
20%	ON	ON
40%	OFF	ON
60%	ON	OFF
80%	OFF	OFF

电流	S6	S7	S8
0.5A	ON	ON	ON
1.0A	OFF	ON	ON
1.5A	ON	OFF	ON
2.0A	OFF	OFF	ON
2.5A	ON	ON	OFF
3.0A	OFF	ON	OFF
3.5A	ON	OFF	OFF
4.0A	OFF	OFF	OFF

AC1~AC2: 10-30VAC / 12-42VDC

PWR/ALARM

Signal
- ENA-(ENA)
- ENA+(+5V)
- DIR-(DIR)
- DIR +(+5V)
- PUL-(PUL)
- PUL+(+5V)

Setting
- SW8
- SW7
- SW6
- SW5
- SW4
- SW3
- SW2
- SW1

High Voltage
- B -
- B +
- A -
- A +
- GND
- VCC