HOME PLOTS APPS

Search (Ctrl+Shift+Space)

Hariprasath

New Script | New Live Script | New | Open | Go to File | Find Files — FILE

Import Data | Save Workspace | Clean Data | New Variable | Open Variable | Clear Workspace — VARIABLE

Favorites | Clear Commands — CODE

Simulink — SIMULINK

Layout | Set Path | Add-Ons | Settings | Connections | Parallel — ENVIRONMENT

Help | Request Support | Feedback | Learn MATLAB — RESOURCES

Copilot Chat — COPILOT

/ › MATLAB Drive

Editor

adc exp 2.m × | untitled2.m × | untitled.m × | untitled3.m × | +

/MATLAB Drive/untitled3.m

```
clc;
clear;
close all;
Am=1;
Ac=1;
fm=5;
fc=50;
beta=5;
kp=5;
fs=1000;
t=0:1/fs:1;
m = Am*cos(2*pi*fm*t); % Message signal
c = Ac*cos(2*pi*fc*t); % Carrier signal
fm_sig = Ac*cos(2*pi*fc*t + beta*sin(2*pi*fm*t)); % FM
pm_sig = Ac*cos(2*pi*fc*t + kp*m); % PM
Df = beta*fm; % Frequency deviation
fprintf('Frequency Deviation = %d Hz\n',Df);
fprintf('FM Modulation Index = %d\n',beta);
subplot(4,1,1), plot(t,m), title('Message Signal')
subplot(4,1,2), plot(t,c), title('Carrier Signal')
subplot(4,1,3), plot(t,fm_sig), title('FM Signal')
subplot(4,1,4), plot(t,pm_sig), title('PM Signal')
```

Apps

Figure 1 ×

