


## Chapter 4 – Global and Detailed Placement



Original Authors:

Andrew B. Kahng, Jens Lienig, Igor L. Markov, Jin Hu

## Chapter 4 – Global and Detailed Placement

### 4.1 Introduction


### 4.2 Optimization Objectives

### 4.3 Global Placement

- 4.3.1 Min-Cut Placement
- 4.3.2 Analytic Placement
- 4.3.3 Simulated Annealing
- 4.3.4 Modern Placement Algorithms

### 4.4 Legalization and Detailed Placement


## 4.1 Introduction



VLSI Physical Design: From Graph Partitioning to Timing Closure

Chapter 4: Global and Detailed Placement 3

## 4.1 Introduction



© 2011 Springer Verlag


VLSI Physical Design: From Graph Partitioning to Timing Closure

Chapter 4: Global and Detailed Placement 4

## 4.1 Introduction

### Global Placement

### Detailed Placement




## 4.2 Optimization Objectives

### Total Wirelength


### Number of Cut Nets

### Wire Congestion

### Signal Delay



## 4.2 Optimization Objectives – Total Wirelength



© 2011 Springer Verlag

## 4.2 Optimization Objectives – Total Wirelength


### Wirelength estimation for a given placement

Half-perimeter  
wirelength  
(HPWL)


Complete  
graph  
(clique)

Monotone  
chain


Star model




$$\text{HPWL} = 9$$



$$\text{Clique Length} = (2/p)\sum_{e \in \text{clique}} d_M(e) = 14.5$$



$$\text{Chain Length} = 12$$




$$\text{Star Length} = 15$$

## 4.2 Optimization Objectives – Total Wirelength


### Wirelength estimation for a given placement (cont'd.)

Rectilinear minimum spanning tree (RMST)




RMST Length = 11

Rectilinear Steiner minimum tree (RSMT)




RSMT Length = 10

Rectilinear Steiner arborescence model (RSA)



RSA Length = 10

Single-trunk Steiner tree (STST)




STST Length = 10

## 4.2 Optimization Objectives – Total Wirelength


### Wirelength estimation for a given placement (cont'd.)

Preferred method: Half-perimeter wirelength (HPWL)

- Fast (order of magnitude faster than RSMT)
- Equal to length of RSMT for 2- and 3-pin nets
- Margin of error for real circuits approx. 8% [Chu, ICCAD 04]



RSMT Length = 10



$$L_{\text{HPWL}} = w + h$$

## 4.2 Optimization Objectives – Total Wirelength

Total wirelength with net weights (weighted wirelength)


- For a placement  $P$ , an estimate of total weighted wirelength is

$$L(P) = \sum_{net \in P} w(net) \cdot L(net)$$

where  $w(net)$  is the weight of  $net$ , and  $L(net)$  is the estimated wirelength of  $net$ .

- Example:

Nets	Weights
$N_1 = (a_1, b_1, d_2)$	$w(N_1) = 2$
$N_2 = (c_1, d_1, f_1)$	$w(N_2) = 4$
$N_3 = (e_1, f_2)$	$w(N_3) = 1$



$$L(P) = \sum_{net \in P} w(net) \cdot L(net) = 2 \cdot 7 + 4 \cdot 4 + 1 \cdot 3 = 33$$

## 4.2 Optimization Objectives – Number of Cut Nets

Cut sizes of a placement

- To improve total wirelength of a placement  $P$ , separately calculate the number of crossings of global vertical and horizontal cutlines, and minimize

$$L(P) = \sum_{v \in V_P} \psi_P(v) + \sum_{h \in H_P} \psi_P(h)$$

where  $\Psi_P(cut)$  be the set of nets cut by a cutline  $cut$

### Cut sizes of a placement

- Example:

Nets

$$N_1 = (a_1, b_1, d_2)$$

$$N_2 = (c_1, d_1, f_1)$$

$$N_3 = (e_1, f_2)$$

- Cut values for each global cutline

$$\psi_P(v_1) = 1 \quad \psi_P(v_2) = 2$$

$$\psi_P(h_1) = 3 \quad \psi_P(h_2) = 2$$


- Total number of crossings in  $P$

$$\psi_P(v_1) + \psi_P(v_2) + \psi_P(h_1) + \psi_P(h_2) = 1 + 2 + 3 + 2 = 8$$

- Cut sizes


$$X(P) = \max(\psi_P(v_1), \psi_P(v_2)) = \max(1, 2) = 2$$

$$Y(P) = \max(\psi_P(h_1), \psi_P(h_2)) = \max(3, 2) = 3$$



### Routing congestion of a placement

- Ratio of demand for routing tracks to the supply of available routing tracks
- Estimated by the number of nets that pass through the boundaries of individual routing regions



Wire capacities

### Routing congestion of a placement

- Formally, the local wire density  $\varphi_P(e)$  of an edge  $e$  between two neighboring grid cells is

$$\varphi_P(e) = \frac{\eta_P(e)}{\sigma_P(e)}$$


where  $\eta_P(e)$  is the estimated number of nets that cross  $e$  and  $\sigma_P(e)$  is the maximum number of nets that can cross  $e$

- If  $\varphi_P(e) > 1$ , then too many nets are estimated to cross  $e$ , making  $P$  more likely to be unroutable.
- The wire density of  $P$  is  $\Phi(P) = \max_{e \in E}(\varphi_P(e))$   
where  $E$  is the set of all edges
- If  $\Phi(P) \leq 1$ , then the design is estimated to be fully routable, otherwise routing will need to detour some nets through less-congested edges

### Wire Density of a placement

$\eta_P(h_1) = 1$	$\eta_P(v_1) = 1$
$\eta_P(h_2) = 2$	$\eta_P(v_2) = 0$
$\eta_P(h_3) = 0$	$\eta_P(v_3) = 0$
$\eta_P(h_4) = 1$	$\eta_P(v_4) = 0$
$\eta_P(h_5) = 1$	$\eta_P(v_5) = 2$
$\eta_P(h_6) = 0$	$\eta_P(v_6) = 0$

Maximum:  $\eta_P(e) = 2$



$$\Phi(P) = \frac{\eta_P(e)}{\sigma_P(e)} = \frac{2}{3}$$

Routable

### Circuit timing of a placement

- Static timing analysis using actual arrival time ( $AAT$ ) and required arrival time ( $RAT$ )
  - $AAT(v)$  represents the latest transition time at a given node  $v$  measured from the beginning of the clock cycle
  - $RAT(v)$  represents the time by which the latest transition at  $v$  must complete in order for the circuit to operate correctly within a given clock cycle.
- For correct operation of the chip with respect to setup (maximum path delay) constraints, it is required that  $AAT(v) \leq RAT(v)$ .

## Global Placement

4.1 Introduction

4.2 Optimization Objectives

→ 4.3 Global Placement

- 4.3.1 Min-Cut Placement
- 4.3.2 Analytic Placement
- 4.3.3 Simulated Annealing
- 4.3.4 Modern Placement Algorithms

4.4 Legalization and Detailed Placement

## Global Placement


- **Partitioning-based algorithms:**
  - The netlist and the layout are divided into smaller sub-netlists and sub-regions, respectively
  - Process is repeated until each sub-netlist and sub-region is small enough to be handled optimally
  - Detailed placement often performed by optimal solvers, facilitating a natural transition from global placement to detailed placement
  - Example: min-cut placement
- **Analytic techniques:**
  - Model the placement problem using an objective (cost) function, which can be optimized via numerical analysis
  - Examples: quadratic placement and force-directed placement
- **Stochastic algorithms:**
  - Randomized moves that allow hill-climbing are used to optimize the cost function
  - Example: simulated annealing

## Global Placement

Partitioning-based

Analytic

Stochastic




### 4.3.1 Min-Cut Placement


- Uses partitioning algorithms to divide (1) the netlist and (2) the layout region into smaller sub-netlists and sub-regions
- Conceptually, each sub-region is assigned a portion of the original netlist
- Each cut heuristically minimizes the number of cut nets using, for example,
  - Kernighan-Lin (KL) algorithm
  - Fiduccia-Mattheyses (FM) algorithm

### 4.3.1 Min-Cut Placement

Alternating cutline directions



Repeating cutline directions



### 4.3.1 Min-Cut Placement

**Input:** netlist *Netlist*, layout area *LA*, minimum number of cells per region *cells\_min*  
**Output:** placement *P*


```

 $P = \emptyset$ 
regions = ASSIGN(Netlist,LA)                                // assign netlist to layout area
while (regions !=  $\emptyset$ )                                // while regions still not placed
    region = FIRST_ELEMENT(regions)                          // first element in regions
    REMOVE(regions, region)                                 // remove first element of regions
    if (region contains more than cell_min cells)
        (sr1,sr2) = BISECT(region)                         // divide region into two subregions
        ADD_TO_END(regions,sr1)                            // sr1 and sr2, obtaining the sub-
        ADD_TO_END(regions,sr2)                            // netlists and sub-areas
    else
        PLACE(region)                                     // add sr1 to the end of regions
        ADD(P,region)                                    // add sr2 to the end of regions
    else
        PLACE(region)                                     // place region
        ADD(P,region)                                    // add region to P


```


### 4.3.1 Min-Cut Placement – Example

Given:





Task: 4 x 2 placement with minimum wirelength using alternative cutline directions and the KL algorithm









Vertical cut  $cut_1$ :  $L=\{1,2,3\}$ ,  $R=\{4,5,6\}$




Horizontal cut  $cut_{2L}$ :  $T=\{1,4\}$ ,  $B=\{2,0\}$




Horizontal cut  $cut_{2R}$ :  $T=\{3,5\}$ ,  $B=\{6,0\}$



### 4.3.1 Min-Cut Placement – Terminal Propagation



- Terminal Propagation
  - External connections are represented by artificial connection points on the cutline
  - Dummy nodes in hypergraphs



© 2011 Springer Verlag

### 4.3.1 Min-Cut Placement

- Advantages:
  - Reasonably fast
  - Objective function can be adjusted, e.g., to perform timing-driven placement
  - Hierarchical strategy applicable to large circuits
- Disadvantages:
  - Randomized, chaotic algorithms – small changes in input lead to large changes in output
  - Optimizing one cutline at a time may result in routing congestion elsewhere

### 4.3.2 Analytic Placement – Quadratic Placement

- Objective function is quadratic; sum of (weighted) squared Euclidean distance represents placement objective function



$$L(P) = \frac{1}{2} \sum_{i,j=1}^n c_{ij} ((x_i - x_j)^2 + (y_i - y_j)^2)$$

where  $n$  is the total number of cells, and  $c(i,j)$  is the connection cost between cells  $i$  and  $j$ .

- Only two-point-connections
- Minimize objective function by equating its derivative to zero which reduces to solving a system of linear equations

### 4.3.2 Analytic Placement – Quadratic Placement

- Similar to Least-Mean-Square Method (root mean square)
- Build error function with analytic form:  $E(a,b) = \sum (a \cdot x_i + b - y_i)^2$



### 4.3.2 Analytic Placement – Quadratic Placement

$$L(P) = \frac{1}{2} \sum_{i,j=1}^n c_{ij} ((x_i - x_j)^2 + (y_i - y_j)^2)$$

where  $n$  is the total number of cells, and  $c(i,j)$  is the connection cost between cells  $i$  and  $j$ .

- Each dimension can be considered independently:

$$L_x(P) = \sum_{i=1, j=1}^n c(i, j)(x_i - x_j)^2 \quad L_y(P) = \sum_{i=1, j=1}^n c(i, j)(y_i - y_j)^2$$

- Convex quadratic optimization problem: any local minimum solution is also a global minimum
- Optimal  $x$ - and  $y$ -coordinates can be found by setting the partial derivatives of  $L_x(P)$  and  $L_y(P)$  to zero

### 4.3.2 Analytic Placement – Quadratic Placement

$$L(P) = \frac{1}{2} \sum_{i,j=1}^n c_{ij} ((x_i - x_j)^2 + (y_i - y_j)^2)$$

where  $n$  is the total number of cells, and  $c(i,j)$  is the connection cost between cells  $i$  and  $j$ .

- Each dimension can be considered independently:

$$L_x(P) = \sum_{i=1, j=1}^n c(i, j)(x_i - x_j)^2 \quad L_y(P) = \sum_{i=1, j=1}^n c(i, j)(y_i - y_j)^2$$



$$\frac{\partial L_x(P)}{\partial X} = AX - b_x = 0$$



$$\frac{\partial L_y(P)}{\partial Y} = AY - b_y = 0$$

where  $A$  is a matrix with  $A[i][j] = -c(i,j)$  when  $i \neq j$ ,

and  $A[i][i] =$  the sum of incident connection weights of cell  $i$ .

$X$  is a vector of all the  $x$ -coordinates of the non-fixed cells, and  $b_x$  is a vector with  $b_x[i] =$  the sum of  $x$ -coordinates of all fixed cells attached to  $i$ .

$Y$  is a vector of all the  $y$ -coordinates of the non-fixed cells, and  $b_y$  is a vector with  $b_y[i] =$  the sum of  $y$ -coordinates of all fixed cells attached to  $i$ .

## 4.3.2 Analytic Placement – Quadratic Placement

$$L(P) = \frac{1}{2} \sum_{i,j=1}^n c_{ij} ((x_i - x_j)^2 + (y_i - y_j)^2)$$

where  $n$  is the total number of cells, and  $c(i,j)$  is the connection cost between cells  $i$  and  $j$ .

- Each dimension can be considered independently:


$$L_x(P) = \sum_{i=1, j=1}^n c(i, j)(x_i - x_j)^2 \quad L_y(P) = \sum_{i=1, j=1}^n c(i, j)(y_i - y_j)^2$$

$$\frac{\partial L_x(P)}{\partial X} = AX - b_x = 0 \quad \frac{\partial L_y(P)}{\partial Y} = AY - b_y = 0$$

- System of linear equations for which iterative numerical methods can be used to find a solution

## 4.3.2 Analytic Placement – Quadratic Placement

- Mechanical analogy: mass-spring system




- Squared Euclidean distance is proportional to the energy of a spring between these points
- Quadratic objective function represents total energy of the spring system; for each movable object, the  $x$  ( $y$ ) partial derivative represents the total force acting on that object
- Setting the forces of the nets to zero, an equilibrium state is mathematically modeled that is characterized by zero forces acting on each movable object
- At the end, all springs are in a force equilibrium with a minimal total spring energy; this equilibrium represents the minimal sum of squared wirelength

→ Result: many cell overlaps

### 4.3.2 Analytic Placement – Quadratic Placement

- Second stage of quadratic placers: cells are spread out to remove overlaps
- Methods:
  - Adding fake nets that pull cells away from dense regions toward anchors
  - Geometric sorting and scaling
  - Repulsion forces, etc.




### 4.3.2 Analytic Placement – Quadratic Placement

- Advantages:
  - Captures the placement problem concisely in mathematical terms
  - Leverages efficient algorithms from numerical analysis and available software
  - Can be applied to large circuits without netlist clustering (flat)
  - Stability: small changes in the input do not lead to large changes in the output
- Disadvantages:
  - Connections to fixed objects are necessary: I/O pads, pins of fixed macros, etc.

## 4.3.2 Analytic Placement – Force-directed Placement

- Cells and wires are modeled using the mechanical analogy of a mass-spring system, i.e., masses connected to Hooke's-Law springs



- Attraction force between cells is directly proportional to their distance
- Cells will eventually settle in a **force equilibrium** → minimized wirelength

## 4.3.2 Analytic Placement – Force-directed Placement

- Given two connected cells  $a$  and  $b$ , the attraction force  $\overrightarrow{F_{ab}}$  exerted on  $a$  by  $b$  is

$$\overrightarrow{F_{ab}} = c(a,b) \cdot (\vec{b} - \vec{a})$$

where

- $c(a,b)$  is the connection weight (priority) between cells  $a$  and  $b$ , and
- $(\vec{b} - \vec{a})$  is the vector difference of the positions of  $a$  and  $b$  in the Euclidean plane


- The sum of forces exerted on a cell  $i$  connected to other cells  $1 \dots j$  is

$$\overrightarrow{F_i} = \sum_{c(i,j) \neq 0} \overrightarrow{F_{ij}}$$

- Zero-force target (ZFT):** position that minimizes this sum of forces

## 4.3.2 Analytic Placement – Force-directed Placement

Zero-Force-Target (ZFT) position of cell  $i$



$$\min \vec{F}_i = c(i,a) \cdot (\vec{a} - \vec{i}) + c(i,b) \cdot (\vec{b} - \vec{i}) + c(i,c) \cdot (\vec{c} - \vec{i}) + c(i,d) \cdot (\vec{d} - \vec{i})$$

© 2011 Springer Verlag

## 4.3.2 Analytic Placement – Force-directed Placement

Basic force-directed placement

- Iteratively moves all cells to their respective ZFT positions
- $x$ - and  $y$ -direction forces are set to zero:

$$\sum_{c(i,j) \neq 0} c(i,j) \cdot (x_j^0 - x_i^0) = 0 \quad \sum_{c(i,j) \neq 0} c(i,j) \cdot (y_j^0 - y_i^0) = 0$$

- Rearranging the variables to solve for  $x_i^0$  and  $y_i^0$  yields

$$x_i^0 = \frac{\sum_{c(i,j) \neq 0} c(i,j) \cdot x_j^0}{\sum_{c(i,j) \neq 0} c(i,j)} \quad y_i^0 = \frac{\sum_{c(i,j) \neq 0} c(i,j) \cdot y_j^0}{\sum_{c(i,j) \neq 0} c(i,j)}$$

Computation of  
ZFT position of cell  $i$   
connected with  
cells 1 ...  $j$

## 4.3.2 Analytic Placement – Force-directed Placement

### Example: ZFT position

Given:

- Circuit with NAND gate 1 and four I/O pads on a  $3 \times 3$  grid
- Pad positions:  $In1(2,2)$ ,  $In2(0,2)$ ,  $In3(0,0)$ ,  $Out(2,0)$
- Weighted connections:  $c(a,In1) = 8$ ,  $c(a,In2) = 10$ ,  $c(a,In3) = 2$ ,  $c(a,Out) = 2$

Task: find the ZFT position of cell  $a$



## 4.3.2 Analytic Placement – Force-directed Placement

### Example: ZFT position

Given:

- Circuit with NAND gate 1 and four I/O pads on a  $3 \times 3$  grid
- Pad positions:  $In1(2,2)$ ,  $In2(0,2)$ ,  $In3(0,0)$ ,  $Out(2,0)$

Solution:

$$x_a^0 = \frac{\sum_{c(i,j) \neq 0} c(a,j) \cdot x_j^0}{\sum_{c(i,j) \neq 0} c(a,j)} = \frac{c(a,In1) \cdot x_{In1} + c(a,In2) \cdot x_{In2} + c(a,In3) \cdot x_{In3} + c(a,Out) \cdot x_{Out}}{c(a,In1) + c(a,In2) + c(a,In3) + c(a,Out)} = \frac{8 \cdot 2 + 10 \cdot 0 + 2 \cdot 0 + 2 \cdot 2}{8 + 10 + 2 + 2} = \frac{20}{22} \approx 0.9$$

$$y_a^0 = \frac{\sum_{c(i,j) \neq 0} c(a,j) \cdot y_j^0}{\sum_{c(i,j) \neq 0} c(a,j)} = \frac{c(a,In1) \cdot y_{In1} + c(a,In2) \cdot y_{In2} + c(a,In3) \cdot y_{In3} + c(a,Out) \cdot y_{Out}}{c(a,In1) + c(a,In2) + c(a,In3) + c(a,Out)} = \frac{8 \cdot 2 + 10 \cdot 2 + 2 \cdot 0 + 2 \cdot 0}{8 + 10 + 2 + 2} = \frac{36}{22} \approx 1.6$$

ZFT position of cell  $a$  is (1,2)


## 4.3.2 Analytic Placement – Force-directed Placement

### Example: ZFT position

Given:

- Circuit with NAND gate 1 and four I/O pads on a 3 x 3 grid
- Pad positions:  $In_1(2,2)$ ,  $In_2(0,2)$ ,  $In_3(0,0)$ ,  $Out(2,0)$

Solution:



## 4.3.2 Analytic Placement – Force-directed Placement

**Input:** set of all cells  $V$

**Output:** placement  $P$

```

 $P = \text{PLACE}(V)$  // arbitrary initial placement
 $\text{loc} = \text{LOCATIONS}(P)$  // set coordinates for each cell in  $P$ 
 $\text{foreach } (\text{cell } c \in V)$ 
     $\text{status}[c] = \text{UNMOVED}$ 
 $\text{while } (\text{ALL\_MOVED}(V) \text{ || !STOP}())$  // continue until all cells have been
    // moved or some stopping
    // criterion is reached
     $c = \text{MAX\_DEGREE}(V, \text{status})$  // unmoved cell that has largest
    // number of connections
     $ZFT\_pos = \text{ZFT\_POSITION}(c)$  // ZFT position of  $c$ 
     $\text{if } (\text{loc}[ZFT\_pos] == \emptyset)$  // if position is unoccupied,
         $\text{loc}[ZFT\_pos] = c$  // move  $c$  to its ZFT position
     $\text{else}$ 
         $\text{RELOCATE}(c, \text{loc})$  // use methods discussed next
         $\text{status}[c] = \text{MOVED}$  // mark  $c$  as moved
    
```

### 4.3.2 Analytic Placement – Force-directed Placement

Finding a valid location for a cell with an occupied ZFT position

( $p$ : incoming cell,  $q$ : cell in  $p$ 's ZFT position)

- If possible, move  $p$  to a cell position close to  $q$ .
- Chain move: cell  $p$  is moved to cells  $q$ 's location.
  - Cell  $q$ , in turn, is shifted to the next position. If a cell  $r$  is occupying this space, cell  $r$  is shifted to the next position.
  - This continues until all affected cells are placed.
- Compute the cost difference if  $p$  and  $q$  were to be swapped.  
If the total cost reduces, i.e., the weighted connection length  $L(P)$  is smaller, then swap  $p$  and  $q$ .

### 4.3.2 Analytic Placement – Force-directed Placement (Example)

Given:

Nets


$$N_1 = (b_1, b_3)$$

$$N_2 = (b_2, b_3)$$

Weight

$$c(N_1) = 2$$

$$c(N_2) = 1$$



### 4.3.2 Analytic Placement – Force-directed Placement (Example)

Given:

Nets


$$N_1 = (b_1, b_3)$$

$$N_2 = (b_2, b_3)$$

Weight

$$c(N_1) = 2$$

$$c(N_2) = 1$$



Incoming cell $p$	ZFT position of cell $p$	Cell $q$	$L(P)$ before move	$L(P)$ / placement after move
$b_3$	$x_{b_3}^0 = \frac{\sum c(b_3, j) \cdot x_j^0}{\sum c(b_3, j)} = \frac{2 \cdot 0 + 1 \cdot 1}{2+1} \approx 0$	$b_1$	$L(P) = 5$	$L(P) = 5$  ⇒ No swapping of $b_3$ and $b_1$

### 4.3.2 Analytic Placement – Force-directed Placement (Example)

Given:

Nets


$$N_1 = (b_1, b_3)$$

$$N_2 = (b_2, b_3)$$

Weight

$$c(N_1) = 2$$

$$c(N_2) = 1$$





Incoming cell $p$	ZFT position of cell $p$	Cell $q$	$L(P)$ before move	$L(P)$ / placement after move
$b_3$	$x_{b_3}^0 = \frac{\sum c(b_3, j) \cdot x_j^0}{\sum c(b_3, j)} = \frac{2 \cdot 0 + 1 \cdot 1}{2+1} \approx 0$	$b_1$	$L(P) = 5$	$L(P) = 5$  ⇒ No swapping of $b_3$ and $b_1$
$b_2$	$x_{b_2}^0 = \frac{\sum c(b_2, j) \cdot x_j^0}{\sum c(b_2, j)} = \frac{1 \cdot 2}{1} = 2$	$b_3$	$L(P) = 5$	$L(P) = 3$  ⇒ Swapping of $b_2$ and $b_3$

### 4.3.2 Analytic Placement – Force-directed Placement

- Advantages:
  - Conceptually simple, easy to implement
  - Primarily intended for global placement, but can also be adapted to detailed placement
- Disadvantages:
  - Does not scale to large placement instances
  - Is not very effective in spreading cells in densest regions
  - Poor trade-off between solution quality and runtime
- In practice, FDP is extended by specialized techniques for cell spreading
  - This facilitates scalability and makes FDP competitive

### 4.3.3 Simulated Annealing



- Analogous to the physical **annealing process**
  - Melt metal and then slowly cool it
  - Result: energy-minimal crystal structure
- Modification of an initial configuration (placement) by moving/exchanging of randomly selected cells
  - Accept the new placement if it improves the objective function
  - If no improvement: Move/exchange is accepted with temperature-dependent (i.e., decreasing) probability

### 4.3.3 Simulated Annealing – Algorithm



**Input:** set of all cells  $V$   
**Output:** placement  $P$

```
T = T0                                // set initial temperature
P = PLACE(V)                            // arbitrary initial placement
while (T > Tmin)
    while (!STOP())                      // not yet in equilibrium at T
        new_P = PERTURB(P)
        Δcost = COST(new_P) - COST(P)
        if (Δcost < 0)
            P = new_P
        else
            r = RANDOM(0,1)                // cost improvement
            if (r < e-Δcost/T)          // accept new placement
                P = new_P
            else                         // no cost improvement
                r = RANDOM(0,1)              // random number [0,1]
                if (r < e-Δcost/T)          // probabilistically accept
                    P = new_P
        T = α · T                          // reduce T, 0 < α < 1
```

### 4.3.3 Simulated Annealing

- Advantages:
  - Can find global optimum (given sufficient time)
  - Well-suited for detailed placement
- Disadvantages:
  - Very slow
  - To achieve high-quality implementation, laborious parameter tuning is necessary
  - Randomized, chaotic algorithms - small changes in the input lead to large changes in the output
- Practical applications of SA:
  - Very small placement instances with complicated constraints
  - Detailed placement, where SA can be applied in small windows (not common anymore)
  - FPGA layout, where complicated constraints are becoming a norm

### 4.3.3 Simulated Annealing



- Analogous to the physical **annealing process**
  - Melt metal and then slowly cool it
  - Result: energy-minimal crystal structure
- Modification of an initial configuration (placement) by moving/exchanging of randomly selected cells
  - Accept the new placement if it improves the objective function
  - If no improvement: Move/exchange is accepted with temperature-dependent (i.e., decreasing) probability

### 4.3.4 Modern Placement Algorithms

- Predominantly analytic algorithms
- Solve two challenges: interconnect minimization and cell overlap removal (spreading)
- Two families:



Quadratic placers

Non-convex  
optimization placers

#### 4.3.4 Modern Placement Algorithms



Quadratic placers



Non-convex  
optimization placers

- Solve large, sparse systems of linear equations (formulated using force-directed placement) by the Conjugate Gradient algorithm
- Perform cell spreading by adding fake nets that pull cells away from dense regions toward carefully placed anchors

#### 4.3.4 Modern Placement Algorithms



Quadratic placers



Non-convex  
optimization placers

- Model interconnect by sophisticated differentiable functions, e.g., log-sum-exp is the popular choice
- Model cell overlap and fixed obstacles by additional (non-convex) functional terms
- Optimize interconnect by the non-linear Conjugate Gradient algorithm
- Sophisticated, slow algorithms
- All leading placers in this category use netlist clustering to improve computational scalability (this further complicates the implementation)

#### 4.3.4 Modern Placement Algorithms



Quadratic  
Placement



Non-convex  
optimization placers

Pros and cons:

- Quadratic placers are simpler and faster, easier to parallelize
- Non-convex optimizers tend to produce better solutions
- As of 2011, quadratic placers are catching up in solution quality while running 5-6 times faster [1]

[1] M.-C.Kim, D.Lee, J.L.Markov: SimPL: An effective placement algorithm, IC CAD 2010: 649-656

### 4.4 Legalization and Detailed Placement

4.1 Introduction

4.2 Optimization Objectives

4.3 Global Placement

- 4.3.1 Min-Cut Placement
- 4.3.2 Analytic Placement
- 4.3.3 Simulated Annealing
- 4.3.4 Modern Placement Algorithms


→ 4.4 Legalization and Detailed Placement

## 4.4 Legalization and Detailed Placement

- Global placement must be legalized
  - Cell locations typically do not align with power rails
  - Small cell overlaps due to incremental changes, such as cell resizing or buffer insertion
- Legalization seeks to find legal, non-overlapping placements for all placeable modules
- Legalization can be improved by detailed placement techniques, such as
  - Swapping neighboring cells to reduce wirelength
  - Sliding cells to unused space
- Software implementations of legalization and detailed placement are often bundled

## 4.4 Legalization and Detailed Placement

Legal positions of standard cells between VDD and GND rails



## Summary of Chapter 4 – Problem Formulation and Objectives

- Row-based standard-cell placement
  - Cell heights are typically fixed, to fit in rows (but some cells may have double and quadruple heights)
  - Legal cell sites facilitate the alignment of routing tracks, connection to power and ground rails
- Wirelength as a key metric of interconnect
  - Bounding box half-perimeter (HPWL)
  - Cliques and stars
  - RMSTs and RSMTs
- Objectives: wirelength, routing congestion, circuit delay
  - Algorithm development is usually driven by wirelength
  - The basic framework is implemented, evaluated and made competitive on standard benchmarks
  - Additional objectives are added to an operational framework

## Summary of Chapter 4 – Global Placement

- Combinatorial optimization techniques: min-cut and simulated annealing
  - Can perform both global and detailed placement
  - Reasonably good at small to medium scales
  - SA is very slow, but can handle a greater variety of constraints
  - Randomized and chaotic algorithms – small changes at the input can lead to large changes at the output
- Analytic techniques: force-directed placement and non-convex optimization
  - Primarily used for global placement
  - Unrivaled for large netlists in speed and solution quality
  - Capture the placement problem by mathematical optimization
  - Use efficient numerical analysis algorithms
  - Ensure stability: small changes at the input can cause only small changes at the output
  - Example: a modern, competitive analytic global placer takes 20mins for global placement of a netlist with 2.1M cells (single thread, 3.2GHz Intel CPU) [1]

- Legalization ensures that design rules & constraints are satisfied
  - All cells are in rows
  - Cells align with routing tracks
  - Cells connect to power & ground rails
  - Additional constraints are often considered, e.g., maximum cell density
- Detailed placement reduces interconnect, while preserving legality
  - Swapping neighboring cells, rotating groups of three
  - Optimal branch-and-bound on small groups of cells
  - Sliding cells along their rows
  - Other local changes
- Extensions to optimize routed wirelength, routing congestion and circuit timing
- Relatively straightforward algorithms, but high-quality, fast implementation is important
- Most relevant after analytic global placement, but are also used after min-cut placement
- Rule of thumb: 50% runtime is spent in global placement, 50% in detailed placement [1]