V3.08d Notes

This version now supports changing channels on the ProHD built in tuner. Grab the ProHD remote file in CustomRemotes. Tested with SMPlayer and FFPLayer. VLC is a little problematic when it sees the new video stream on the channel change. We found that this command line parameter makes it sort of usable "--no-play-and-pause". There may be some other VLC configuration(s) to make it better but I'm going to leave that as an exercise for the user.

I revisited how IR keycodes were queued up for sending to the slingbox due to some user issues with the sending being "too slow". Channel changing should now be much faster with fewer video artifacts.

The code can now eat a raw HTML file for the remote definition. Make your fancy remote page with your favourite web page editor and give it to the server with the ".html" file extension. All the buttons need a unique name= with the keycode in the value= parameter. To send a channel change the name of the input field needs to be "Digits".

The code will now work with older versions of Python. Tested on 3.7

The server will now "logout" when a session with the slingbox ends. You should see fewer "kicked off" messages. This was primarily as issue on the Solo boxes.

You can now send keycodes when specifying the start channel either in the config.ini file or on the streaming URL . Both of these are supported.

?channel=155 #The channel number to tune to ?channel=9+13+13 # The keycodes