

STANDARD OPERATING PROCEDURE

Title: Air Compressor Preventive Maintenance

Document ID: SOP-COMP-001

Procedure

1. Verify discharge pressure.
2. Inspect air filters.
3. Check oil level.
4. Inspect intercooler.
5. Measure motor current.
6. Inspect belts and couplings.
7. Record readings.

Failure Indicators

- High discharge temperature
- Excessive current draw
- Pressure instability
- Oil contamination