

STANDARD OPERATING PROCEDURE

Title: Cooling Pump Preventive Maintenance

Document ID: SOP-CP-001

Purpose

To ensure reliable operation of cooling water pumps.

Procedure

1. Verify suction and discharge pressures.
2. Inspect mechanical seal leakage.
3. Measure vibration levels.
4. Inspect coupling alignment.
5. Check bearing lubrication.
6. Inspect impeller condition.
7. Verify motor current.
8. Record maintenance observations.

Acceptance Criteria

- Vibration below 4 mm/s
- Seal leakage within limits
- Motor current within rated range
- Stable discharge pressure

Common Failure Modes

- Bearing wear
- Mechanical seal failure
- Impeller erosion
- Cavitation