

# Microprocessors & Microcontrollers (ECE3004)

Module - 03

# 8051 Microcontroller [Keil and Proteus Setup]

Dr. Susant Kumar Panigrahi
Assistant Professor
School of Electrical & Electronics Engineering



### HOW TO USE KEIL [Generating .hex File for 8051 μC]

3

- ✓ Finally you have decided to write your own code for the 8051 microcontroller.
- ✓ It doesn't matter whether you have chosen Assembly or C Language for yourself but what matters now is that you need an environment specially designed for 8051.
- Basically you are looking out for IDE (Integrated Development Environment) that will help you build and compile programs.
- ✓ Keil is the solution to generate .hex file for 8051 programming.
- ✓ You can download KEIL from their official website using the link below.


**DOWNLOAD KEIL uVISION FOR 8051** 

### Follow the steps to install Keil.


### Keil: Here We go....




Create a new folder for project to avoid getting mixed up with files




PROJECT -> NEW  $\mu$ VISION PROJECT



Give some name and click SAVE




when prompted, select proper device that you're using ( i-e ATMEL → AT89C51 )



When prompted, select YES


### **Step - 05**



Click NEW button and write your code (Assembly or Clanguage)

10

### **Step - 06**




SAVE the file with proper extension as above

```
code.asm
   org 00H
02
                    Notice how the code gets
   RS BIT P2.0
                 highlighted according to syntax
   EN BIT P2.1
05
   :LCD INITIALIZATION
   START:
           MOV P3, #0EH
           ACALL LCDCONTROL
08
           ACALL DELAY
09
10
   ;DISPLAYING LINE 1 & 2
           MOV DPTR, #line1
           ACALL WRITE
14
           ACALL DELAY
15
           MOV DPTR, #line2
16
17
           ACALL WRITE
18
           ACALL DELAY
19
   CLEARING SCREEN
21
           MOV P3, #01H
           ACALL LCDCONTROL
```


The code you have written gets highlighted

### Step - 08 [Most Important]




Right click SOURCE GROUP 1 as shown

### Step - 09 [Most Important]




Add the code you have written into the Project workspace

### Step - 10 [Most Important]




Go to options for the project

### Step - 11 [Most Important]




**Enable HEX file generation** 

#### **Step - 12**




**Build the project** 

### **Step - 13**




Notice successful build. Ignore the warnings

### **Step** – 14



Use this HEX file to program your IC






## How to Install Proteus Design

Suite [Version 8]







- ✓ Click twice on the installation exe file.
- ✓ Click "Next".
- ✓ On the "License Agreement" page, check "I accept terms of this agreement" and click "Next".
- ✓ Select "Use locally installed license" and click next.




- ✓ Click Next to find the License File.
- ✓ After opening the "Labcenter License Manager" window, click on "Browse For Key file".
- ✓ Go to the specific folder where you have copied all installation folder before starting installation of Proteus.
- ✓ Find the "Crack" named folder there.




- ✓ Click Next to find the License File.
- ✓ After opening the "Labcenter License Manager" window, click on "Browse For Key file".
- ✓ Go to the specific folder where you have copied all installation folder before starting installation of Proteus.
- ✓ Find the "Crack" named folder there.




- ✓ Select the "license.lxk" file in the "Crack" folder and click to "Open" it.
- ✓ Click Yes and then Click "Install".
- ✓ Close the License Manager window.




- ✓ If the license file is installed perfectly, you will see a window like 1.
- ✓ If you have any previous version of Proteus, then check all these 3 boxes and click "Next". If it is the first time of your Proteus using, leave all three box uncheck and Click "next".
- ✓ Click "Typical".
- ✓ Proteus Installation will be started now. After 2/3 minutes, the installation will be done. DO NOT RUN Proteus Now! Click "Close".




- ✓ To crack the installed software, to the "Crack" folder again.
- ✓ There should be a folder named "BIN".
- ✓ Now, go to "C:\Program Files
- ✓ Labcenter Electronics\Proteus 8
  Professional" (32bit) Or,
  "C:\Program Files (x86)\Labcenter
  Electronics\Proteus 8
  Professional" (64 bit)— and pasted
  that BIN folder there.




- ✓ Click "Yes" while pasting the BIN file at "Confirm Folder Replace" window.
- ✓ Check "Do this for the next 4 conflicts" option and click on "Copy and Replace" option.
- ✓ If any other permission seeking window pops up, just click "okay/yes".




- ✓ After being done with copypasting BIN folder, now come to the previous Crack folder and Copy "MODELS" folder.
- ✓ The location of pasting this "MODELS" folder is hidden by default. You will have to make it visible to past MODELS.
- ✓ Go to "Organize>Folder and search option > Folder Option > View".
- ✓ Select "Show hidden files, folder and drives" and click "OK", the close the window.
- ✓ Now if you go to your "C" drive, you will see "Program Data" folder.



- ✓ Now go to this link location "C:\ProgramData\Labcenter Electronics\Proteus 8 Professional" and paste that MODEL folder on there.
- ✓ Click "Yes" if "Confirm Folder Replace" window shows up.



- ✓ Check the "Do this for the next 8 conflicts" box and click on "Copy and Replace".
- ✓ Now you can run the software by clicking on the Shortcut of "Proteus 8 Professional" created on your desktop.
- ✓ You also can lunch is from Start Menu.



## Proteus – Launching Window

✓ Enjoy the Professional Version of Proteus, absolutely in FREE!

