

ZONE 4 PLANT SAFETY INSTRUCTIONS

Safety Procedure: High-Pressure System Isolation & LOTO

Scope: Applies to all maintenance personnel operating in Zone 4 High Pressure Feedwater Loop.

Lockout / Tagout (LOTO) Mandatory Protocol

Prior to opening any pump casing or valve housing in Zone 4, personnel must lock out Valve HV-104 and verify zero hydraulic line pressure on Transducer PT-208. Safety padlocks must remain locked until final clearance.