
COL216 Computer Architecture

Input/Output – 5
USB
28th March 2022

USB: Universal Serial Bus

- Introduced in mid-90's
- Used for a huge variety of devices
- Replaced earlier serial and parallel ports
- Much higher speed than RS232 etc
- Packet oriented, not character oriented
- Clock is recovered from data
- Differential signalling (D+ and D-)
- Upto 127 devices through hubs, each with up to 16 IN and 16 OUT end points

USB connectors



source: wikipedia

USB speed, levels

■ USB 1.0 Low Speed

■ USB 1.0 Full Speed

■ USB 2.0 High Speed

■ USB 3.0 Super Speed

■ USB 3.1 Super Speed+

■ USB 3.2 Super Speed+

■ USB 4 forthcoming

LS, FS: 0.0 to 0.3 V

HS, SS: -10 to 10 mV

1.5 Mb/s

12 Mb/s

480 Mb/s

5 Gb/s

10 Gb/s

20 Gb/s


2.8 to 3.6 V

360 to 440mV

What D+,D- patterns can indicate

- Device found detached
- Device wakes up host
- Host and device idling
- Start of packet
- End of Packet
- Reset device to a known state
- Power down device
- Host wakes up device
- Host wants device to stay awake
- Device wants to wake up

USB NAK packet



source: wikipedia

Packet IDs

- Token packets
 - SPLIT: Split transaction
 - PING
 - OUT, IN: Address for data transfer
 - SOF: start of frame marker
 - SETUP: Device management
- Handshake packets
 - ACK: Packet accepted
 - NAK: Packet not accepted, retransmit
 - NYET: Data not ready yet
 - STALL: Transfer impossible, do recovery
- DATA0, DATA1 etc: data packet