

Day 3 Peripheral Trouble Shooting

1. List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

So here are 5 common issues

1. Device not detected — Unplug it, restart the laptop, then try different USB port.
2. Keyboard or mouse stops responding intermittently — Replace or inspect the USB cable and avoid loose adapters or hubs.
3. Mouse cursor lags or jumps — Clean the mouse sensor and try it on a non-reflective surface.
4. Keyboard types wrong characters — Check the laptop's keyboard language/ layout settings and select the correct layout.
5. USB device has insufficient power — Disconnect other USB accessories or use a powered USB hub.

2. Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

So I would follow these steps

Step 1: Check the battery and power

- Check the headphone charging level.
- If the battery is low, charge the headphones and then try connecting again.
- Check whether the power/Bluetooth indicator light is ON or blinking.

Step 2: Restart the phone and Bluetooth

- Turn Bluetooth OFF and ON from the phone's **Settings → Bluetooth**.
- Restart the phone and try connecting again.

Step 3: Forget and pair the device again

- Open **Settings → Bluetooth**.
- Select the headphones and choose **Forget/Unpair Device**.
- Put the headphones into Bluetooth pairing mode and try to pair them again.

Step 4: Check the distance

- Keep the headphones close to the phone, preferably within **1–2 metres**.
- Make sure there are no major obstacles or interference between them.

Step 5: Check if the headphones are connected to another device

- Make sure the headphones are not already connected to another phone, laptop, or tablet.
- Disconnect them from other devices and try pairing again.

Step 6: Test with another phone

- Try connecting the headphones to another phone.
- If they connect successfully, the problem may be with the original phone's Bluetooth settings.

Step 7: Reset the headphones

- If the headphones still do not connect, reset them according to the manufacturer's instructions.
- Put them back into pairing mode and try connecting again.

3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

So here are checklist for external webcam not detected in windows 10

- 1 check the webcam is properly connected or not via usb port of Computer.
- 2 Try connecting with different usb port of computer
- 3 check windows setting if zoom is allow for webcam/camera or not.
- 4 Open zoom and choose the external webcam from the camera selection dropdown section
- 5 check device manger the external camera is connected or showing or not
- 6 Restart computer and zoom and unplug and plug the external webcam.

4. You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

If my friend's printer is showing **“Offline”** on the PC, I would use the Windows Troubleshooter as follows:

1. Open **Settings** on the Windows 10 PC.
2. Go to **Update & Security → Troubleshoot → Additional troubleshooters**.

3. Select **Printer** and click **Run the troubleshooter**.
4. Windows Troubleshooter will automatically check the printer for common problems, such as **connection issues, printer settings, driver problems, and printer services**.
5. During the process, it will display the **problem it is checking**, whether an issue was **detected**, and whether Windows can **automatically fix** it.
6. If a problem is found, I would follow the recommended solution and then check whether the printer status changes from **Offline to Ready/Online**.

The Troubleshooter provides information about the **problems it finds, the possible causes, and the recommended solutions**. It also shows whether Windows was able to **fix the problem automatically** or if further action is required.