
EE321: Prelab1


Part 1: Download and Install Proteus

- 1. Download proteus from this link: Proteus Download
- 2. Install proteus. Installation steps are as follows:
 - a) Extract the "Proteus_8.6_SP2_Pro.exe" from the zip folder
 - b) Run the "Proteus_8.6_SP2_Pro.exe"
 - Grassington North Yorkshire.lxk
 Proteus_8.6_SP2.zip
 - Proteus_8.6_SP2.zip-20230314T175816Z-...
 - Proteus_8.6_SP2_Pro.exe


c) Select installation location, then click next




d) Select start menu folder, you can keep this as default, then click next



e) Wait for installation to finish



f) When installation is complete click finish



- 3. If you have "No libraries found" error, watch this video : No libraries found error
- 4. We will use it for simulations for PIC microcontroller.

Part 2: Download and Install MPLAB

- 1. Download MPLAB IDE from this link: MPLAB IDE Download 2. Unzip MPLAB_IDE_8_92.zip then install MPLAB_IDE software.
- 3. We will use it for compiling PIC assembly codes.

Part 3: Download and Install MicroC

- 1. Download MikroC from this link: MikroC Download
- 2. Unzip MikroC.zip then install MikroC.