

MIMARSINAN ORGANIZE SAN. BÖL. 19. CAD. NO 32 38350 Kayseri / TÜRKİYE Tel: +90.352.207 84 00 Faks: +90.352. 207 84 20 web: www.ech.com.tr	 ERCIYES ÇELİK HALAT TEL SAN. TİC. A.Ş.	MIMARSINAN ORGANIZED INDUSTRIAL ZONE .19 STREET NO:32 38350 Kayseri / TURKEY Tel: +90.352.207 84 00 Faks: +90.352. 207 84 20 web: www.ech.com.tr
--	---	--

EN 10204 3.1

TEST SERTİFİKASI

MILL'S TEST CERTIFICATE



MÜŞTERİ ADI
ORDERING COMPANY
STANDARD :

GÖVER ÇELİK HALAT
EN 12385-4

TARİH:
DATE : 28.07.2025

KONSTRÜKSİYON CONSTRUCTION	6x36 WS	SERTİFİKA NUMARASI CERTIFICATE NUMBER	32225T0032
KAPLAMA COATING	GALVANIZED	HALAT ÇAPI (mm) DIAMETER (mm)	44,00
ÖZ CORE TYPE	IWRC	BÜKÜM YÖNÜ LAY	s/z
MUKAVEMET SINIFI (N/mm ²) TENSILE STRENGTH (N/mm ²)	1960	YAĞLAMA LUBRICATION	A1
METRE (M) LENGTH (M)	1100	DÖNÜŞ KAYIP FAKTÖRÜ LOST FACTOR	0,78
DÖNÜŞ TİPİ ROTATION TYPE	ROTATING		

TEK TEL TESTLERİ (SINGLE WIRE TESTS)

TEL SAYISI NUMBER OF WIRE	TEL ÇAPI WIRE DIAMETER (mm)	MUKAVEMET TENSILE STRENGTH (N/mm ²)	BURMA TESTİ TORSION TEST	EĞME TESTİ BENDING TEST	GALVANİZ GALVANIZED (gr/m ²)
1	2,8	2003	41	19	----
7	2,08	2005	40	20	----
7	2,02	1996	42	18	----
7	1,56	2007	42	19	----
14	2,51	2006	42	20	----

HAMMADDE ORTALAMA KİMYASAL DEĞERLERİ (AVERAGE CHEMICAL VALUES OF RAW MATERIALS)

C %	Si	Mn %	P %	S %
0,70 - 0,75	0,10 - 0,30	0,50 - 0,80	0,0006 - 0,013	0,003 - 0,006

Minumun Kopma Kuvveti
Minimum Breaking Load

1352 kN

Ölçülen Kopma Kuvveti
Actual Breaking Load

1396 kN

NOTLAR: *** DÜĞÜMLÜ KOPMA İLE ÇEKME TESTİ

NOTES: *** TENSILE TESTING KNOTTED SPECIMEN

ÖNERİLER:

Halatlar korozyonu önlemek için örtü altında saklanmalı ve taşınmalıdır. Montaj aşamasında halata zarar vermemeye dikkat edin. Hasarlı olmasına rağmen yeni halatlar asla kullanılmamalıdır.

Halatlar kullanımı sırasında düzenli olarak yağlanmalıdır. Halatlar, tel kopması, çap azalması, korozyon ve yolun darbe durumları açısından düzenli ve periyodik olarak kontrol edilmelidir.

ve sonuçlar kayıt altına alınmalıdır. Kullanım ömrü biten halatlar önceden belirlenmiş kriterlere bağlı olarak ve dikkate alınarak yerine yenileri ile değiştirilmelidir.

DİKKAT:

Halatın kullanımı sırasında meydana gelebilecek, insan, işçilik, malzeme ve üretim kaybına yol açacak kazalardan firmamız sorumlu değildir.

Garanti ve sorumluluğumuz halatlara uygulanan yük, ilgili standartlarda veya ürün kalite belgesinde belirtilen, kullanılmamış yeni halat üzerinde gerekli kopma yükünün sağlanmasıyla sınırlıdır.

RECOMMENDATIONS:

Ropes should be stored and moved under cover to prevent corrosion. Be careful not to damage to the rope in the assembly stage. Although damaged ropes should never be used in the new.

Ropes must be lubricated regularly during to use. Ropes should be checked regularly and periodically about wire breakage, reduction in diameter, corrosion and impact terms of the way and results should be recorded. The use life completed ropes must be replaced with new ones to instead of depending on predetermined criteria and taking into consideration.

ATTENTION:

Our company are not responsible any accidents occur during the use of the rope and that as resulting in loss of human, labor, material and production. Our warranty and responsibility on the ropes are limited to provided of required breaking load on unused new rope that given to the relevant standards or product quality certificate.

ONAYLAYAN (APPROVED BY)

Murat BAYIR

KALİTE VE YÖNETİM SİSTEMLERİ
Quality Management Systems

