Raspberry Pi Server based on Docker

Node-red, MQTT, Node-red dashboard

Table of contents



01

Pengenalan

GOAL

- Memahami sistem Docker pada RaspberryPi
- Menggunakan headless Rpi
- Instalasi docker dengan IoTStack
- Koneksi ESP32 – Rpi dengan MQTT
- Menampilkan data sensor melalui mqtt dashboard

RASPBERRY PI

Raspberry Pi Boards

Raspberry Pi Zero

Raspberry Pi 4 Model B

Raspberry Pi 3 Model A+

Raspberry Pi 3 Model B+

Raspberry Pi 3 Model B

Raspberry Pi 2 Model B

Raspberry Pi 1 Model B+

Raspberry Pi 1 Model A+

Raspberry Pi Zero W

Raspberry pi 3



4x USB
Power micro usb
HDMI display
Camera interface
Ethernet
GPIO

Mico sd

Install sdcard

- Download image
- Connect sdcard
- Find Raspberry pi *.img
- Flash

Install menggunakan Raspberry Pi Imager



Setting headless Rpi

```
ctrl_interface=DIR=/var/run/wpa_supplicant GROUP=netdev
update_config=1

network={
        ssid="YOUR_SSID"
        psk="YOUR_PASSWORD"
}
```

- Set Open and edit wpa_supplicant.conf
- Scan ip
- Ssh using putty

```
C:\Users\estheim>nmap -PN 192.168.0.1/24

Starting Nmap 7.60 ( https://nmap.org ) at 2019-08-04 22:36 SE Asia Standard Time
Nmap scan report for 192.168.0.101
Host is up (0.013s latency).
Not shown: 998 closed ports
PORT     STATE SERVICE
22/tcp   open  ssh
5900/tcp open  vnc
MAC Address: B8:27:EB:34:DB:6F (Raspberry Pi Foundation)
```

```
estheim@Machina:~$ ssh pi@192.168.0.101
pi@192.168.0.101's password:
Linux raspberrypi 4.14.79-v7+ #1159 SMP Sun Nov 4 17:50:20 GMT 2018 armv7l

The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
Last login: Sun Aug  4 22:40:41 2019 from 192.168.0.100
pi@raspberrypi:~ $ lsb_release -a
No LSB modules are available.
Distributor ID: Raspbian
Description:    Raspbian GNU/Linux 9.4 (stretch)
Release:        9.4
Codename:       stretch
pi@raspberrypi:~ $
```

Docker Rpi

IoT Stack untuk docker pada raspberry pi

DOCKER

Docker adalah platform perangkat lunak yang memungkinkan Anda membuat, menguji, dan menerapkan aplikasi dengan cepat. Docker mengemas perangkat lunak ke dalam unit standar yang disebut **kontainer** yang memiliki semua yang diperlukan perangkat lunak agar dapat berfungsi termasuk **pustaka, alat sistem, kode, dan waktu proses**.





Install dan run docker

Connect to Rpi ssh pi@raspberrypi.local

1. Install curl:
sudo apt install -y curl
Run the following command:
curl -fsSL https://raw.githubusercontent.com/SensorsIot/IOTstack/master/install.sh | bash

2. Run the menu and choose your containers:
cd ~/IOTstack
./menu.sh
Bring up your stack:
cd ~/IOTstack
docker-compose up -d


pi@raspberrypi: ~/IOTstack
IOTstack Main Menu
-> Build Stack <-
Docker Commands
Miscellaneous Commands
Backup and Restore
Native Installs
Exit

Service to install

- Nodered
- Portainer-ce
- Mosquito
- Influxdb
- Grafana

MQTT SERVER

Mosquito

MQTT


Device
Device
Device
BROKER
House/office/lamp
Device
house/kitchen/door
Device
house/room/window
Device
Publish
Subscribe

Tentang Topic

- Struktur dibatasi "/" misal
  - /workshop/esp32/sensor/status
  - /workshop/esp32/sensor/control
  - /workshop/esp32/sensordht11
  - /workshop/room/alarm

- Wild card topic dan subtopic
  - # (hash character) – multi level wildcard
  - + (plus character) -single level wildcard
- Case sensitive

Mosquitto

TOPIC	VALUE
$SYS/broker/version	mosquitto version 1.4.10
$SYS/broker/timestamp	Fri, 22 Dec 2017 08:19:25 +0000
$SYS/broker/uptime	2251623 seconds
$SYS/broker/clients/total	2
$SYS/broker/clients/inactive	0
$SYS/broker/clients/disconnected	0
$SYS/broker/clients/active	2
$SYS/broker/clients/connected	2
$SYS/broker/clients/expired	0
$SYS/broker/clients/maximum	3
$SYS/broker/messages/stored	61
$SYS/broker/messages/received	419773

Node red dashboard

Dashboard mqtt mengunakan node-red dashboard

Install node red in pc

https://nodered.org/docs/getting-started/local



AKSES WEB

Node red flow
http://localhost:1880

Node red UI
http://localhost:1880/ui



Setting Node MQTT

```
client.subscribe(topic);
# dalam callback subscibe
if (payload[0]==1) {
    digitalWrite(18, HIGH);
 } else if (payload[0]==0) {
    digitalWrite(18, LOW);
 }
```

```
sprintf(str, “%i", datasensor );
client.publish(topic, str);
```

THANKS

Do you have any question?

hasbiida@gmail.com