0.1 Strain energy

The energy of a system is the ability of the system to do work.

Energy may exist in many forms and can be transformed from one for to another. All forms of energy can be put into two main categories:

- Kinetic energy motion (of waves, electrons, atoms, molecules, substances and objects)
- Potential energy stored energy

Strain energy is a form of potential energy that is stored within a material which has been subjected to strain (deformation). If the material remains **elastic** whilst the deformation is applied, then it is capable of doing an amount of work equal to the stored strain energy when returning to its original dimensions.




Figure 1:

The work done W by the external actions on the structure as effect of the displacements, is equal to the strain energy U stored by internal reaction forces as effect of the deformations within the structure:




Figure 2:

For a gradually applied load, the work done by a force acting on the structure, is given by the area under the force - displacement curve:

$$W = \int_0^e P \, \mathrm{d}e \tag{2}$$

If displacement is proportional to load (Hookean behaviour)




Figure 3:

For a gradually applied load, the energy stored by the internal actions into the structure, is given by the area under the internal force - deformation curve:

$$U = \int_0^e P \, \mathrm{d}e \tag{4}$$

If deformation is proportional to load (Hookean behaviour):

$$U = \frac{1}{2}Pe \tag{5}$$

0.1.1 Bending moment




Figure 4:

We can determine through various methodologies the distribution of the bending moment. If we want to determine the strain energy at a particular point along the beam, we can extract an elemental portion of the beam with length dx from a position x in our coordinate system. This is subjected to a certain bending moment and this will produce a $d\theta$ with radius R.




Figure 5:

We then know that:

$$dU_M = \frac{1}{2}M d\theta \tag{6}$$

It is inconvenient to use θ in our equations and we would like to substitute this for x. We know that:

$$d\theta = \frac{dx}{R} \text{ and } \frac{1}{R} = \frac{M}{EI}$$
 (7)

(from theory of bending). Therefore:

$$d\theta = \frac{M}{EI} dx \tag{8}$$

Substituting:

$$dU_M = \frac{1}{2} \frac{M^2}{EI} dx \tag{9}$$

$$U_M = \int_0^L \frac{M^2}{2EI} \, \mathrm{d}x \tag{10}$$

0.2 Castigliano's Theorem

Castigliano stated in his engineering thesis that:

... the partial derivative of the strain energy, considered as a function of the applied forces acting o na linear elastic structure, with respect to one of these forces, is equal to the displacement in the direction of the force of its point of application.

This simply means that if we want to know the displacement from an applied force at the point of application, we can simply take the partial derivative of the strain energy.




Figure 6:

$$\delta_A = \frac{\partial U}{\partial P_A}, \ \delta_B = \frac{\partial U}{\partial P_B} \tag{11}$$

$$\delta_C = \frac{\partial U}{\partial P_C}, \ \theta_D = \frac{\partial U}{\partial M_D} \tag{12}$$

In practice, the displacement δ_i at any load P_i acting upon a system is given by:

$$\delta_i = \frac{\partial U}{\partial P_i} \tag{13}$$

where U is the strain energy of the system due to all loads including P_i . The load may be a force, in which case a linear displacement is obtained; or a rotational moment, in which case an angular displacement is obtained. The displacement (linear or angular) will result positive in the same sense as the applied action (force or moment).




Figure 7:

0.2.1 Application of Castigliano's theorem

We know that:

$$\delta_i = \frac{\partial U_M}{\partial P_i} \tag{14}$$

We also know that:

$$U_M = \int_0^L \frac{M^2}{EI} \, \mathrm{d}x \tag{15}$$

Substituting:

$$\delta_i = \frac{\partial}{\partial P_i} \int_0^L \frac{M^2}{2EI} \, \mathrm{d}x \tag{16}$$

$$\delta_i = \int_0^L \frac{\partial}{\partial P_i} \left(\frac{M^2}{2EI} \right) \, \mathrm{d}x \tag{17}$$

An alternative expression using the chain rule can be derived as:

$$\delta_i = \frac{\partial U_M}{\partial P_i} = \frac{\partial U_M}{\partial M} \cdot \frac{\partial M}{\partial P_i} = \int_0^L \frac{\partial}{\partial M} \left(\frac{M^2}{2EI}\right) \frac{\partial M}{\partial P_i} dx \tag{18}$$

This leads to:

$$\frac{\partial}{\partial M} \frac{\partial M^2}{2EI} = \frac{M}{EI} \tag{19}$$

$$\delta_i = \int_0^L \frac{M}{EI} \frac{\partial M}{\partial P_i} \, \mathrm{d}x \tag{20}$$

0.3 Examples and applications

0.3.1 Example 1

Determine the deflection of the free end of the beam in the direction of P.




Figure 8:

Bending moment:

$$M = -Px (21)$$

Castigliano's theorem:

$$\delta = \int_0^L \frac{\partial}{\partial P} \left(\frac{M^2}{2EI} \right) dx = \int_0^L \frac{\partial}{\partial P} \left(\frac{P^2 x^2}{2EI} \right) dx = \int_0^L \frac{P x^2}{EI} dx = \frac{PL^3}{3EI}$$
(22)

$$\delta = \frac{PL^3}{3EI} \tag{23}$$




Figure 9:

We can utilise dummy loads in order to analyse our system. The bending moment is:

$$M = -\frac{wx^2}{2} - P_0x - M_0 (24)$$

Castigliano's theorem (alternative equation):

$$\delta = \int_0^L \frac{M}{EI} \frac{\partial M}{\partial P_0} dx \text{ with } \frac{\partial M}{\partial P_0} = \frac{\partial}{\partial P_0} \left(-\frac{wx^2}{2} - P_0 x - M_0 \right) = -x \qquad (25)$$

Substituting:

$$\delta = \int_0^L \frac{1}{EI} \left(-\frac{wx^2}{2} \right) (-x) \, dx = \frac{w}{2EI} \int_0^L x^3 \, dx = \frac{wL^4}{8EI}$$
 (26)

Note: as P_0x and M_0 are dummy loads, they do not need to be included in our final equation for δ .