

AssemblerDebugHelp

00

4 00

0 00

0 00

0 00

2 0C

F FF

00

Flag

S 0

Z 1

AC 0

P 1

C 0

Load me at

1 LDA 8050

2 MOV B,A

3 LDA 8051

4 SUB B

5 STA 8052

6 HLT

7

Hex Conversion

Hex

0

x

To Dec

+

00

Update Port Value

DataStackKeyPadMemoryI/O

Start 8050

Address (Hex)	Address	Data
1F72	8050	4
1F73	8051	4
1F74	8052	0
1F75	8053	0
1F76	8054	0
1F77	8055	0
1F78	8056	0
1F79	8057	0
1F7A	8058	0
1F7B	8059	0
1F7C	8060	0
1F7D	8061	0
1F7E	8062	0
1F7F	8063	0

Line No	Assembler Message
0	Program assembled successfully

File Reset Assembler Debug Help



Registers

A	00	
BC	01	00
DE	00	00
HL	00	00
PSW	00	00
PC	42	06
SP	FF	FF
Int-Reg	00	

Flag

S 0
Z 1
AC 1
P 1
C 1

Load me at

```
1 MVI A, 0FFH  
2 MVI B, 01H  
3 ADD B  
4 HLT
```

Decimal - Hex Conversion

Decimal

Hex

0

0

→ To Hex

← To Dec

I/O Ports

0

-

+

00

⌂ Update Port Value

Memory

0

-

+

00

⌂ Update Memory



Registers

<i>A</i>	7F	
<i>BC</i>	3A	00
<i>DE</i>	00	00
<i>HL</i>	00	00
<i>PSW</i>	00	00
<i>PC</i>	42	06
<i>SP</i>	FF	FF
<i>Int-Reg</i>	00	

Flag

<i>S</i>	0
<i>Z</i>	0
<i>AC</i>	0
<i>P</i>	0
<i>C</i>	0

Load me at

```
1  MVI A, 45H
2  MVI B, 3AH
3  ADD B
4  HLT
```

Decimal - Hex Conversion

Decimal	Hex
0	0
To Hex	To Dec

I/O Ports

0	-	+	00
Update Port Value			

Memory

0	-	+	00
Update Memory			

Load me at

1

LDA 8050

2

MOV B, A

3

LDA 8051

4

MOV C, A

5

MVI D, 00

6

LOOP: MOV A, B

7

CMP C

8

JC STORE

9

SUB C

10

MOV B, A

11

INR D

12

JMP LOOP

13

STORE: MOV A, D

14

STA 8052

15

MOV A, B

16

STA 8053

17

HLT

DataStackKeyPadMemoryI/O Ports

Start8050OK

Address (Hex)	Address	Data
1F72	8050	16
1F73	8051	4
1F74	8052	4
1F75	8053	0
1F76	8054	0
1F77	8055	0
1F78	8056	0
1F79	8057	0
1F7A	8058	0
1F7B	8059	0
1F7C	8060	0
1F7D	8061	0
1F7E	8062	0
1F7F	8063	0

Line No	Assembler Message
0	Program assembled successfully

Flag

S 0

Z 1

AC 0

P 1

C 0

tion

ex

Dec

Load me at

1 LDA 8050

2 MOV B, A

3 LDA 8051

4 MOV C, A

5 MVI A, 00

6 LOOP

7 ADD B

8 DCR C

9 JNZ LOOP

10 STA 8052

11 HLT

12

DataStackKeyPadMemoryI/O Ports

Start8050OK

Address (Hex)	Address	Data
1F72	8050	4
1F73	8051	4
1F74	8052	16
1F75	8053	0
1F76	8054	0
1F77	8055	0
1F78	8056	0
1F79	8057	0
1F7A	8058	0
1F7B	8059	0
1F7C	8060	0
1F7D	8061	0
1F7E	8062	0