Directions for Ventura Mirror

CORTECH

- Please remove the front mirror protective film after the mirror is installed.
- Removal of protective film on the back of mirror is optional. Leaving it on may protect the mirror from rough wall surfaces.
- Hold the mirror to the wall and mark the wall where the screws will be attached. It is very important to align the holes properly. Misaligning the holes could damage the mirror upon installation.
- Use a ¼ inch drill bit for the anchors and drill the hole 1" – 1 1/8" deep.
- Screw head part #: torx button head screw # 10. Grainger # 1Q723
- Please install mirror with the protective "O" ring between the screw and mirror.
- Do not over tighten screws during installation. It may damage the acrylic.
- Clean mirror with a micro-fiber cloth and non-abrasive soap and water, do not use glass cleaner.