

Aurora X1 — Electric Bike Owner's Manual

1. Overview & Specifications

The Aurora X1 is an electric commuter bicycle manufactured by Aurora Mobility. It was released on September 3, 2024, as the company's first consumer model.

Key specifications: the X1 has a top speed of 28 mph (45 km/h) and a range of up to 60 miles on a single charge. It is powered by a 500-watt rear-hub motor and a 720 Wh removable lithium-ion battery. The bike weighs 24 kg and supports a maximum rider weight of 120 kg. A full charge takes about 4.5 hours.

2. Ride Modes & Features

The X1 offers three ride modes. Eco mode maximizes range, delivering the full 60 miles. City mode balances range and power for everyday commuting. Turbo mode maximizes acceleration but reduces range to about 35 miles.

The bike provides five levels of pedal assist. It includes integrated front and rear LED lights, built-in GPS tracking, and pairs with the Aurora Ride mobile app over Bluetooth.

3. Charging & Battery Care

The 720 Wh battery is removable and charges fully in about 4.5 hours from empty. A partial charge to 80 percent takes roughly 3 hours.

For longevity, store the battery charged between 10 and 90 percent. Do not charge the battery below 0 degrees Celsius. The battery is rated for approximately 800 full charge cycles before capacity noticeably declines.

4. Safety & Maintenance

Always wear a certified helmet when riding. Keep the tire pressure at 55 psi. The Aurora X1 is fitted with hydraulic disc brakes on both the front and rear wheels.

Aurora Mobility recommends a full service every 1,000 miles or every six months, whichever comes first. Do not attempt to open the motor housing yourself; doing so voids the warranty.

5. Warranty & Support

Aurora Mobility provides a two-year warranty on the frame and a one-year warranty on the battery and electronic components. The warranty does not cover accidental damage or normal wear of tires and brake pads.

For support, email support@auroramobility.example, available Monday to Friday from 9am to 5pm. The bike's serial number is printed on a label under the down tube.

6. Troubleshooting

If the bike will not power on, hold the power button for 10 seconds to force a reset. If the display shows error code E3, the motor is overheating; stop riding and let it cool for 15 minutes before continuing.

If the bike will not connect over Bluetooth, remove (forget) the device in the Aurora Ride app and pair it again. If problems persist, contact support.