
XTS TRANSPORT LAYER

ST_STATION_PARAMETER: placement of single XtsStation with PosWait, PosStop[1] > 0, Release Distance > 0

Direction ————— forward


Ex01



ST_STATION_PARAMETER: placement of single XtsStation with PosWait, PosStop[1] = 0, Release Distance > 0

Direction ————— forward

Ex02



ST_STATION_PARAMETER: placement of single XtsStation with PosWait, PosStop[1] = 0, Release Distance < 0

Direction ————— forward

Ex03

