

Allplan in the home-office

Technical Support FAQ

Category: Technical Services->Network

Programs: Allplan 2020
Allplan 2019
Allplan 2018

Document ID: 20200313091506

Internet: <https://connect.allplan.com/en/faqid/20200313091506.html>

Question:

How can you use Allplan with access to a common data storage in the home-office without a direct LAN connection?

Answer:

1. Home-office with simultaneous access to the central data.

Allplan Share, the Allplan cloud solution, can be used to use Allplan without a LAN connection to the central data storage and with the requirement to continue working together in projects. Of course, Allplan must be installed on a computer in the home-office as a single workstation without access to a central file storage folder (otherwise Allplan will not start). Or as a member of a workgroup installation, the computer must be checked out and used outside of the LAN, like a single workstation. Data access works via the cloud. That means: The project must be in the Allplan Cloud (Allplan Share)

Working is as easy as in a normal single workstation. You can access a project with several users at the same time and work simultaneously.

You can find information on Allplan Share under the following link or from your sales partner:

<https://www.allplan.com/en/add-ons/allplan-share/>

Note:

We cannot recommend the use of VPN for a common project storage. Allplan exchanges a large number of files with the data server. The associated encryption of the files via a VPN Internet line leads to speed losses. A connection via VPN is not approved by us, since even the smallest connection fluctuations can destroy data during transmission. In addition, working over the Internet is extremely slow if you do not have a sufficiently fast Internet connection (up / down min. 100 Mbit). Furthermore, a VPN connection with IPv6 is not supported by Allplan, Allplan only recognizes IPv4. It must also be ensured that the VPN connection remains permanent and does not fall into sleep mode.

Please note that no support can be provided for this constellation.

2. Home office without access to the central file storage (local work):

2.1 Allplan with workgroup manager:

If you have a license for the workgroup manager, you can check out a computer / laptop with a menu-driven project from the workgroup environment and work in the home office without access to the server. The projects on the checked-out computer are blocked for the CAD engineers in the network. These users will see the comment you provided when you checked out.

You can find a manual here:

<https://connect.allplan.com/en/faqid/20140428143638.html>

2.2 Allplan without workgroup manager:

Use of the office computer:

When installing without a workgroup manager and without network access, Allplan must be uninstalled if you want to use the office computer and reinstalled using the local paths. A corresponding project must be imported into the local installation via data backup.

Use of a new (private computer):

If a new computer is used in the home office, the license must be returned to the office computer and thus installed in the home office.

Please note, that this method of working should avoid parallel processing of data in both installations, since the subsequent merging is complex.

Allplan GmbH and affiliated sales organizations not assume any responsibility or liability for the reliability and usefulness of the articles offered and any information provided. You assume sole responsibility for use of the articles offered and the information provided. Terms and conditions of license of Allplan GmbH and / or the general terms and conditions of the sales organizations rendering the service apply.

© 2020 Allplan GmbH. All rights reserved.