



[Lab is Simple](#)


Contents

Export and Import startup Configuration

1. Export Startup Configuration.

Step 1: Export Configuration of Nodes in LAB refer: <https://pnetlab.com/pages/documentation?slug=how-to-save-configuration-of-lab>


Step 2: Go to Left **Menu > Start-up Configuration**, now you can see configuration of nodes.



Step 3: Click on ➡ **Export** button. Zip file contain all configuration will be downloaded.

2. Import Startup configuration.

Step 1: Create a Folder contain all configuration file. Files name in the folder have format: **[node id].txt**. You can get node id in **Left menu > System Status**



Step 2: Click on Import Button. Fill import name and select folder in Step 1

Import Start-up Config

Start-up Config Name :

Config folder : 2 files
(Select Folder contain all config files of Lab)

Now you can see new Startup Configuration that you imported.

Startup config

Select config to Edit:

Change All

R1

R2

Config 1

```

!
! Last configuration change at 03:10:52 UTC Sat Jun 5 2021
!
version 15.2
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
service compress-config
!
  
```



Lab is Simple



CONTACT INFO

✉ pnetlabs@gmail.com

📌 [Join support group chat](#)

